



Manuals.plus /

› HZDHCLH /

› HZDHCLH 10-inch Modern Silent Wall Clock Instruction Manual

HZDHCLH 10

HZDHCLH 10-inch Modern Silent Wall Clock

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the HZDHCLH 10-inch Modern Silent Wall Clock. This clock is designed to provide accurate timekeeping with a silent, non-ticking quartz movement, making it suitable for various indoor environments such as living rooms, bedrooms, kitchens, offices, and nurseries. Its modern design features 3D numbers and a durable ABS plastic frame with HD glass.



Image: The HZDHCLH 10-inch Modern Silent Wall Clock in its gray color variant.

2. Safety Information

- Use only AA carbon batteries or used alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the clock will not be used for an extended period to prevent leakage.
- Keep batteries out of reach of children.
- Do not expose the clock to extreme temperatures or direct sunlight.
- Handle the clock with care to avoid damaging the glass or internal components.

3. Package Contents

The package includes:

- 1 x HZDHCLH 10-inch Modern Silent Wall Clock (Gray)

Note: 1 AA battery is required and not included in the package.

4. Product Features

- **Size:** 10 x 10 x 1.5 inches (25.4 x 25.4 x 3.8 cm)
- **Frame:** Sturdy ABS plastic frame
- **Glass:** HD transparent glass, non-fragile, dust-proof
- **Movement:** Silent quartz movement (non-ticking)
- **Numbers:** 3D raised numbers for enhanced readability
- **Power Source:** Battery Powered (1 AA battery required, not included)
- **Display Type:** Analog
- **Mounting Type:** Wall Mount



Image: Detailed view of the clock face, highlighting the 3D numbers and hands.



Silent Wall Clock Without Annoying Ticks

It will provide you with quiet throughout the day, allowing you to fall asleep undisturbed at any time.



Security



Mute



Precise



Image: Illustration emphasizing the silent operation of the wall clock, ideal for quiet environments.

Your browser does not support the video tag.

Video: An official product video showcasing the HZDHCLH 10-inch Small Wall Clock, highlighting its features and design.

Your browser does not support the video tag.

Video: An official product video demonstrating the HZDHCLH Modern Wall Clock, focusing on its aesthetic and silent operation.

5. Setup

5.1 Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Insert one (1) AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings in the compartment.
3. Close the battery compartment cover securely.

5.2 Setting the Time

1. Locate the time adjustment knob on the back of the clock, usually a small wheel or dial.

2. Gently turn the knob in either direction to move the clock hands to the correct time.
3. Avoid moving the hands directly, as this may damage the movement mechanism.

5.3 Mounting the Clock

1. Choose a suitable location on a wall for mounting.
2. Use a nail or screw (not included) appropriate for your wall type. Ensure it is securely fastened and can support the clock's weight (approximately 1.06 pounds / 0.48 kg).
3. Hang the clock using the integrated hanging slot on the back.



Image: The HZDHCLH wall clock displayed in a living room, demonstrating its decorative appeal.

6. Operating Instructions

Once the battery is installed and the time is set, the HZDHCLH wall clock will operate continuously. The silent quartz movement ensures that the clock runs without any audible ticking sounds, providing a peaceful environment.

The large 3D numbers and clear hands allow for easy readability from a distance.

7. Maintenance

7.1 Cleaning

- Wipe the clock's surface and glass with a soft, dry cloth.
- Do not use abrasive cleaners or chemical sprays, as these may damage the finish or glass.

7.2 Battery Replacement

- When the clock starts losing time or stops functioning, it is time to replace the battery.
- Follow the battery installation steps (Section 5.1) to replace the AA battery.
- Dispose of used batteries responsibly according to local regulations.

8. Troubleshooting

Problem	Possible Cause	Solution
Clock not working	Battery is dead or incorrectly installed.	Check battery polarity or replace with a new AA battery.
Time is inaccurate	Low battery power.	Replace the AA battery.
Clock makes no ticking sound	This is a feature of the silent quartz movement.	No action required; the clock is designed to be silent.

9. Specifications

Feature	Detail
Brand	HZDHCLH
Model Number	10
Color	Gray
Display Type	Analog
Style	Modern
Special Feature	Silent Clock
Product Dimensions	10"W x 10"H (25.4 cm x 25.4 cm)
Power Source	Battery Powered (1 AA battery required)
Room Type	Bedroom, Kitchen, Living Room, Nursery, Office
Shape	Round
Indoor/Outdoor Usage	Indoor
Material	Plastic
Frame Material	Plastic
Are Batteries Included	No
Mounting Type	Wall Mount
Item Weight	1.06 pounds (0.48 Kilograms)

10. Warranty and Support

HZDHCLH is committed to providing high-quality products and customer satisfaction. If you have any questions or encounter any issues with your quartz clock, please contact us directly for assistance.

Return Policy: This product is eligible for a refund or replacement within 30 days of purchase, subject to the retailer's return policy.

Manufacturer: HZDHCLH