

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [AMZCHEF](#) /

> [AMZCHEF 2-Burner Induction Hob Instruction Manual \(Model CE-SK-33IHB2T4\)](#)

AMZCHEF CE-SK-33IHB2T4

AMZCHEF 2-Burner Induction Hob Instruction Manual

MODEL: CE-SK-33IHB2T4

1. Introduction

Thank you for choosing the AMZCHEF 2-Burner Induction Hob. This domino-style cooktop features a polished black crystal surface, intuitive touch controls, and advanced safety features, including child safety lock and automatic pan detection. With 10 power levels and a 0-99 minute timer, it offers versatile cooking options. This appliance is designed for both built-in and portable use, providing flexibility for various kitchen setups. Please read this manual thoroughly before use to ensure safe and efficient operation.

Your browser does not support the video tag.

Video: Overview of the AMZCHEF 2-Burner Induction Hob in use, demonstrating its features and cooking capabilities.

2. Safety Information

Always prioritize safety when operating electrical appliances. This induction hob incorporates several safety features, but proper usage is essential.

- **Hot Surface Warning:** The induction surface may retain residual heat after cooking. **Do not touch the hot surface immediately after use.**
- **Cookware Detection:** The hob automatically detects suitable magnetic cookware. If no cookware or inappropriate cookware is placed on the zone for 1 minute, the appliance will automatically switch off.
- **Child Safety Lock:** To prevent unintended operation, activate the child safety lock. Press and hold the 'LOCK' symbol for 3 seconds to unlock.
- **Overheat Protection:** The appliance is equipped with surface and internal overheat protection. If overheating occurs, the hob will display an error code (E5 or E6) and shut down. Allow the unit to cool before resuming use.
- **Voltage Requirements:** Ensure the appliance is connected to a 220V-240V power supply. Incorrect voltage (too low or too high) may trigger error codes (E1 or E2).
- **Do Not Disassemble:** Do not attempt to disassemble or repair the appliance yourself. This can lead to hazards and damage. Contact customer service for any issues.

EASY TO OPERATE ELECTRIC COOKTOP WITH 2 BURNER

Gifts for the elderly, no pressure to use



Over-Temperature Protection



Residual Heat Warning



9 Power Levels Setting



2 Burners Can Work Together



Image: The AMZCHEF induction hob highlighting safety features such as over-temperature protection and residual heat warning.

3. Setup

The AMZCHEF 2-Burner Induction Hob is versatile, allowing for both countertop and built-in installation. Ensure proper ventilation around the unit regardless of the installation type.

3.1 Unpacking

Carefully remove the induction hob from its packaging. Inspect the appliance for any signs of damage. Retain the packaging for future transport or storage.

3.2 Placement

For countertop use, place the hob on a stable, flat, heat-resistant surface, ensuring adequate space around the unit for ventilation. For built-in installation, refer to the specific cutout dimensions provided in the separate installation guide (if applicable) to ensure a proper fit into your kitchen counter. The hob dimensions are approximately 62.2 cm (L) x 39.5 cm (W) x 14.1 cm (H).

3.3 Power Connection

Connect the VDE plug to a grounded 220V-240V electrical outlet. Ensure the outlet is capable of handling the hob's maximum power output of 3300W.



Image: The AMZCHEF induction hob illustrating its suitability for both countertop and built-in use, ideal for RVs and indoor kitchens.

Your browser does not support the video tag.

Video: Demonstrates the ultra-slim design of the AMZCHEF induction hob and its ease of placement in various kitchen settings.

4. Operating Instructions

The AMZCHEF induction hob features a user-friendly touch control panel for precise cooking.

4.1 Control Panel Overview

The hob is equipped with a digital touch control panel. Each cooking zone has independent controls for power/temperature and timer settings. The main controls include ON/OFF, Power/Temp selection, Increase/Decrease buttons, Timer, and Lock function.

TOUCH CONTROL

Two High Power Burners



Image: Detailed diagram of the touch control panel, showing ON/OFF, Timer, Lock, Increase, Decrease, and Power/Temp controls for each zone.

4.2 Power Levels and Temperature Control

The hob offers 10 power levels, allowing for precise temperature control from keeping warm to deep frying. Use the Increase (+) and Decrease (-) buttons to adjust the power or temperature setting for the selected cooking zone.

9 LEVELS PRECLISE TEMPERATURE CONTROL



Keep Warm



Stir Fry



Deep Fry



Image: Illustrates the 9 precise temperature control levels, suitable for various cooking methods like keeping warm, stir-frying, and deep-frying.



Image: Visual representation of the 10 power levels, ideal for various cooking tasks from simmering to boiling.

4.3 Timer Function

Each cooking zone has a timer function that can be set from 0 to 99 minutes. Press the 'Timer' button and use the Increase (+) and Decrease (-) buttons to set the desired cooking duration. The hob will automatically switch off once the timer expires.

4.4 Child Safety Lock

To activate the child safety lock, press and hold the 'LOCK' symbol for 3 seconds. This will disable the control panel to prevent accidental changes to settings or activation. To deactivate, press and hold the 'LOCK' symbol again for 3 seconds.

CHILD SAFETY LOCK & TIMER

Make the taste of love with children.



Child lock

Lock the controls to prevent unintended use



Timer

Timer range from 1-99mins



Material

Surface material does not heat



Image: Highlights the child safety lock and timer features, emphasizing safe and convenient cooking.

4.5 Compatible Cookware

This induction hob is compatible with magnetic cookware, such as cast iron pans, iron dishes, iron plates, or cookware with magnetic bottoms. Cookware should be between 4.7 and 10.2 inches in diameter for optimal performance. Non-magnetic materials like aluminum, ceramic, copper, or glass cookware are not suitable.



Image: A visual guide to compatible magnetic cookware (cast iron, stainless steel, enameled cast iron) and incompatible types (aluminum, ceramic, copper, glass, concave base).

Your browser does not support the video tag.

Video: A close-up view of the induction hob's controls and cooking process, demonstrating ease of use.

5. Maintenance

The AMZCHEF induction hob features a high-quality polished black crystal glass surface that is easy to clean and resistant to scratches.

5.1 Cleaning the Surface

After each use, allow the hob to cool completely. Wipe the glass surface with a soft, damp cloth and a mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic or induction cooktops. Avoid using abrasive sponges, scouring pads, or harsh chemicals, as these can scratch or damage the surface.

5.2 General Care

Regularly check the ventilation openings for any blockages and clean them if necessary to ensure proper airflow. Do not immerse the appliance in water or any other liquid.



Image: Demonstrates the easy maintenance and scratch-resistant properties of the high-quality black polished crystal glass surface.

6. Troubleshooting

If an anomaly occurs, the induction hob will automatically enter a protective state and display a corresponding error code. Refer to the table below for common issues and solutions.

Error Code	Description	Solution
E0	No cookware or unsuitable cookware detected.	Place appropriate magnetic cookware on the cooking zone.
E1	Voltage too low.	Verify that the voltage used is 220V-240V.
E2	Voltage too high.	Verify that the voltage used is 220V-240V.
E3	Surface sensor open or short circuit.	Contact the supplier for assistance.
E4	IGBT sensor open or short circuit.	Contact the supplier for assistance.
E5	Surface temperature overheat protection.	Allow the appliance to cool down before using it again.
E6	Internal temperature overheat protection.	Allow the appliance to cool down before using it again.
Ec	Control panel wiring not connected.	Contact the supplier for assistance.

Note: Please do not attempt to disassemble the appliance yourself to avoid any danger or damage. If the appliance encounters problems not listed here, please contact the supplier.

7. Specifications

Feature	Detail
Brand	AMZCHEF
Model Number	CE-SK-33IHB2T4 (also FS-IRC119)
Product Dimensions (L x W x H)	62.2 x 39.5 x 14.1 cm
Weight	5.29 kg
Installation Type	Built-in / Countertop
Special Features	Timer, Touch Controls, Child Safety Lock, Automatic Pan Detection
Heating Element Type	Induction Coil
Number of Burners	2
Color	Black
Voltage	220-240 Volts
Power Source	Electric (3300W total, 1800W max per zone)
Material	Cast Iron, Glass (Vitreoceramic Surface)
Components Included	Induction Hob

8. Warranty and Support

AMZCHEF is committed to providing high-quality products and excellent customer service.

- **Warranty:** This AMZCHEF induction hob comes with a two-year warranty.
- **Technical Support:** We offer lifetime technical support for all our products.
- **Customer Service:** Should you encounter any problems or require assistance, please do not hesitate to contact our professional customer service team. We are dedicated to ensuring your satisfaction and providing prompt support.