

## Aokitsink 01

# Aokitsink Model 01 Hanging Handbag Organizer Instruction Manual

Model: 01 | Brand: Aokitsink

## 1. INTRODUCTION

The Aokitsink Model 01 Hanging Handbag Organizer is designed to help you efficiently store and organize your bags, keeping your home and closet tidy. This versatile rack can accommodate various types of bags, including shoulder bags, handbags, bucket bags, clutches, underarm bags, tote bags, and even small backpacks. It can also be utilized for organizing towels or yoga mats, offering flexible storage solutions for different spaces.



Image 1.1: The Aokitsink Model 01 Hanging Handbag Organizer, showcasing its capacity to hold various bag types on adjustable shelves.



Image 1.2: The organizer mounted on a closet door, demonstrating its space-saving design within a bedroom setting.

## 2. SAFETY INFORMATION

- Ensure the organizer is securely installed using the appropriate mounting method (over-door hooks or wall screws/adhesive) to prevent accidental falls.
- Do not overload the shelves beyond their intended capacity. Refer to the specifications for weight limits (if available, otherwise use general caution).
- Keep small parts (screws, stickers) out of reach of children.
- Verify door compatibility before over-door installation (door thickness and gap requirements).

## 3. PACKAGE CONTENTS

Please check the package to ensure all components are present:

- Main Rack Sections (can be assembled as one unit or two separate units)
  - Adjustable Baskets (3 different sizes)
  - Over-Door Hooks (for door mounting)
  - Non-Marking Screw Stickers (2 pieces)
  - Double-Sided Adhesive Tapes (5 pieces)
  - Nameplates (for basket labeling)
- 

## 4. SETUP AND INSTALLATION

The Aokitsink Model 01 organizer offers two primary installation methods: over-the-door hanging or wall mounting. It can also be used as a single unit or split into two sections.

### 4.1 Over-the-Door Installation

1. **Assemble the Rack:** If using as a single unit, connect the rack sections securely.
2. **Attach Over-Door Hooks:** Slide the provided over-door hooks onto the top of the assembled rack.
3. **Check Door Compatibility:** Ensure your door thickness is less than 45 mm. The hook thickness is 2 mm; verify that your door gap is less than 2 mm to allow the door to close properly. You can test this by checking if a \$1 coin fits in the door gap.
4. **Hang the Organizer:** Carefully place the hooks over the top edge of your door.
5. **Secure (Optional):** For added stability and to prevent rocking, use the non-marking screw stickers or double-sided adhesive tapes to secure the rack against the door.



Image 4.1: Visual guide for checking door thickness and gap before over-door installation.

## Non-Marking Screw Stickers To Help Secure Products

Makes shelves fit more snugly  
against doors to prevent rocking and tipping.



Image 4.2: Illustration of non-marking screw stickers used to stabilize the organizer against the door.

### 4.2 Wall Mounting Installation

This method is ideal for saving space or if you prefer a permanent fixture. You can use the entire rack or split it into two sections.

1. **Assemble Rack Sections:** Decide whether to use the full rack or split it into two smaller sections.
2. **Choose Location:** Select a suitable wall location.
3. **Mark Drilling Points:** Hold the rack against the wall and mark the desired drilling points for the non-marking screw stickers or other suitable wall anchors (not included).
4. **Install Fasteners:** Apply the non-marking screw stickers or use appropriate screws/anchors for your wall type.
5. **Mount the Rack:** Securely attach the rack to the installed fasteners.

# Can Use Together Or Separate



Image 4.3: The organizer configured as a single over-door unit and as two separate wall-mounted units, demonstrating versatility.

## 5. OPERATING INSTRUCTIONS

### 5.1 Adjusting Basket Height

The baskets are designed to be removable and adjustable. This allows you to customize the spacing between shelves to fit bags of various sizes.

- To adjust, simply lift a basket from its current position.
- Re-insert the basket into the desired slots on the rack to achieve the optimal height for your items.
- For larger bags, increase the distance between baskets. For smaller bags or clutches, reduce the distance.

### 5.2 Using Different Basket Sizes

The organizer includes three different basket sizes to accommodate various bag widths.

- Smallest basket: Fits bags less than 5.1 inches wide.
- Medium basket: Fits bags less than 5.9 inches wide.


- Largest basket: Fits bags less than 6.8 inches wide.

## *Different baskets fit bags of different widths*



# 1

*Fits bags less than  
5.1 inch wide.*



# 2

*Fits bags less than  
5.9 inch wide.*



# 3

*Fits bags less than  
6.8 inch wide.*

Image 5.1: Guide to the three distinct basket sizes and their corresponding maximum bag widths.

### **5.3 Utilizing Nameplates**

Each basket features a nameplate design. You can write on these nameplates to label the contents of each basket, helping you to quickly identify and return bags to their designated spots after use.

## **6. MAINTENANCE**

- **Cleaning:** Wipe the metal frame and baskets with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all connections and mounting points to ensure they remain secure. Tighten any loose screws or re-apply adhesive if necessary.
- **Storage:** If disassembling for storage, keep all components together in a dry place to prevent loss or damage.

## **7. TROUBLESHOOTING**

- **Rack is wobbly:** Ensure all connections are tight. If over-door mounted, use the non-marking screw stickers or adhesive tapes to secure it against the door. Check door gap compatibility.
- **Door does not close properly:** Verify that your door gap is sufficient (less than 2 mm) for the over-door hooks. If not, consider wall mounting.
- **Bags do not fit:** Adjust the height of the baskets by moving them to different slots on the rack. Utilize the appropriate basket size for the width of your bag.
- **Adhesive not holding:** Ensure the surface is clean, dry, and smooth before applying adhesive tapes or screw stickers. Allow sufficient curing time if specified by the adhesive product.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Aokitsink
Model Number	01
Color	Black
Material	Metal
Overall Rack Dimensions (L x W x H)	29 x 17 x 120 cm (11.4 x 6.7 x 47.2 inches)
Item Weight	3.31 Kilograms (7.3 lbs)
Number of Shelves	6 (adjustable baskets)
Mounting Type	Over-door or Wall Mount
Door Thickness Compatibility (Over-door)	Less than 45 mm (1.8 inches)
Door Gap Compatibility (Over-door)	Less than 2 mm (0.08 inches)
Basket Dimensions (L x W x H)	28 x 13 x 5.8 cm (11 x 5.1 x 2.3 inches) 27.9 x 15.9 x 7.6 cm (11 x 6.25 x 3 inches) 27.9 x 17.6 x 16.3 cm (11 x 6.9 x 6.4 inches)




Image 8.1: Comprehensive diagram displaying the dimensions of the organizer and its individual baskets.

## 9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Aokitsink Model 01 Hanging Handbag Organizer, please refer to the retailer's return policy or contact Aokitsink customer service through the platform where the product was purchased. Please retain your proof of purchase for warranty claims.