

WLIVE ASNG072DHS2

WLIVE 3-Drawer Fabric Dresser Instruction Manual

Model: ASNG072DHS2

1. INTRODUCTION

Thank you for choosing the WLIVE 3-Drawer Fabric Dresser. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new furniture. Please read these instructions thoroughly before beginning assembly and retain them for future reference.


This versatile storage unit features a sturdy steel frame, a durable wood top, and three removable fabric drawers, designed for organizing items in various rooms such as bedrooms, hallways, entryways, and closets.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 35 lbs (15.9 kg) for the wooden top and 6.6 lbs (3 kg) for each drawer. Overloading can compromise stability and cause damage.
- **Anti-Tilt Device:** For enhanced safety, especially in households with children or pets, it is highly recommended to install the included anti-tilt device to secure the dresser to a wall.
- **Stable Placement:** Always place the dresser on a flat, level surface to prevent tipping.
- **Children's Safety:** Do not allow children to climb on or play with the dresser. Keep small parts away from children during assembly.
- **Assembly:** Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.

ANTI-TILT DEVICE

Prevent incidents



Easy-Pull Handle

STORAGE CAPACITY

Figure 1: Illustration of the anti-tilt device for secure installation and the easy-pull handles on the drawers.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact WLIVE customer support.

- Dresser Frame (Steel)
- Wood Top
- Fabric Drawers (3 units)
- Assembly Guide
- Installation Tool (Hex Key)
- Hardware Pack (screws, adjustable feet, anti-tilt kit)

4. ASSEMBLY INSTRUCTIONS (SETUP)

Assembly is required for this product. Please follow these steps carefully. It is recommended to have a Phillips head screwdriver on hand for attaching the drawer handles, as the included tool may not be sufficient for this specific task.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the Steel Frame:** Connect the steel frame components according to the diagrams in the included assembly guide. Ensure all connections are secure.
3. **Attach Adjustable Feet:** Screw the four adjustable plastic feet into the bottom of the steel frame. These feet protect your floor from scratches and allow for minor leveling adjustments.
4. **Install Wood Top:** Secure the wood top to the assembled steel frame using the provided screws.
5. **Prepare Fabric Drawers:** Unfold each fabric drawer and insert the bottom support panel. Attach the easy-pull handles to the front of each drawer using a Phillips head screwdriver.
6. **Insert Drawers:** Slide the assembled fabric drawers into the designated slots within the steel frame.
7. **Install Anti-Tilt Device:** Follow the specific instructions in the assembly guide to securely attach the anti-tilt device to the back of the dresser and to a wall stud. This step is crucial for safety.

STEEL FRAME & WOODEN BOARD

Stronger & Sturdier



SMOOTH SLIDE



ADJUSTABLE FEET

Figure 2: Detailed view of the steel frame, smooth slide mechanism, and adjustable feet for stability.

5. OPERATION

The WLIVE 3-Drawer Fabric Dresser is designed for organizing various household items. Its compact size makes it suitable for multiple room types.

- **Drawer Usage:** The three removable fabric drawers are ideal for storing clothes, blankets, scarves, socks, and other accessories. The easy-pull handles facilitate smooth opening and closing.
- **Top Surface:** The sturdy wood top provides a hard surface for displaying lamps, clocks, books, glasses, and other decorative or functional items.
- **Placement:** This dresser is suitable for use in bedrooms, living rooms, closets, entryways, and college dorms.



Figure 3: The dresser in a bedroom setting, demonstrating its use as a nightstand with accessible storage.

LARGE STORAGE SPACE



Each one
can hold:



10-13



6-9

Figure 4: Visual representation of the storage capacity per drawer, capable of holding 10-13 shirts or 6-9 pairs of pants.



Figure 5: Capacity details: The wooden top supports up to 35 lbs, and each fabric drawer holds up to 6.6 lbs.

6. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your WLIVE dresser.

- **Cleaning the Wood Top:** Wipe the wood top with a dry cloth to remove dust and spills. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cleaning Fabric Drawers:** The high-quality non-woven fabric drawers are easy to clean. Spot clean with a damp cloth and mild soap if necessary. Allow to air dry completely. Do not machine wash or tumble dry.
- **Frame Care:** Wipe the steel frame with a dry or slightly damp cloth.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.

SUPERIOR FABRIC



Wear-resistant



Easy to clean



Non-deforming



Figure 6: Features of the fabric drawers, emphasizing durability and ease of maintenance.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

- **Dresser is Unstable/Wobbly:**
 - Ensure the dresser is placed on a flat, level surface.
 - Adjust the leveling feet at the bottom of the frame until stability is achieved.
 - Verify that all assembly screws are fully tightened.
- **Drawers Do Not Slide Smoothly:**
 - Check if the drawers are overloaded. Reduce the weight if necessary.
 - Ensure the drawer is correctly inserted into its slot and not obstructed.
 - Inspect the fabric drawers for any deformation that might hinder movement.
- **Missing Parts:**
 - Double-check the packaging and all contents against the package contents list.

- If parts are genuinely missing, contact WLIVE customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Model Name	ASNG072DHS2
Product Dimensions (L x W x H)	15.7" x 11.8" x 29.5" (39.9 cm x 30 cm x 74.9 cm)
Item Weight	10.56 lbs (4.79 kg)
Color	Rustic Brown Wood Grain Print
Material	Steel Frame, Wood Top, Non-woven Fabric Drawers
Number of Drawers	3
Wood Top Capacity	35 lbs (15.9 kg)
Each Drawer Capacity	6.6 lbs (3 kg)
Assembly Required	Yes



Figure 7: Detailed dimensions of the dresser.

9. WARRANTY AND SUPPORT

This WLIVE dresser comes with a Full Warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty information provided with your purchase or visit the official WLIVE website.

For customer support, assistance with assembly, or to report missing/damaged parts, please contact WLIVE customer service through the retailer where the product was purchased or via the contact information available on the WLIVE official website.

© 2025 WLIVE. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question