

WLIVE ASNG058DHS2

WLIVE ASNG058DHS2 6-Drawer Fabric Dresser and TV Stand User Manual

Model: ASNG058DHS2 | Brand: WLIVE

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and safety of your WLIVE ASNG058DHS2 6-Drawer Fabric Dresser and TV Stand. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.



Image 1.1: The WLIVE ASNG058DHS2 6-Drawer Fabric Dresser and TV Stand in Rustic Brown.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- **Anti-Tip Device:** Always install the included anti-tip device to securely fix the dresser to the wall. This prevents accidental tipping, which can cause serious injury, especially to children and pets.
- **Weight Distribution:** Place heavier items in the lower drawers to maintain stability and reduce the risk of the furniture becoming top-heavy.
- **Intended Use:** Use this furniture for its intended purpose as a dresser and TV stand. Avoid climbing on or hanging from the unit.
- **Drawer Safety:** Install locking devices on drawers if necessary to prevent children from opening drawers and using them as steps to climb.
- **Maximum Load:** Do not exceed the maximum weight capacity of the top surface (100 lbs) or individual drawers.



Image 2.1: Illustration of the anti-tilt device and adjustable feet for enhanced stability and safety.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Wooden Top Panel
- 6 Fabric Drawers with Handles
- Adjustable Feet (5 units)
- Anti-Tip Device
- Assembly Hardware (screws, bolts, etc.)
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically takes less than one hour. Follow the detailed assembly guide provided in the package. All screw parts are clearly marked, and reserved holes are pre-drilled for convenience.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Metal Frame:** Connect the metal frame components according to the diagrams in the assembly guide. Ensure all connections are secure but do not overtighten screws until the frame is fully assembled.
3. **Attach Wooden Top:** Secure the wooden top panel to the assembled metal frame using the provided hardware.
4. **Install Adjustable Feet:** Screw the 5 adjustable feet into the bottom of the frame. Adjust them as needed to ensure the dresser is level on any surface.
5. **Prepare Fabric Drawers:** Insert the bottom panel into each fabric drawer and attach the curved handles.
6. **Insert Drawers:** Slide the assembled fabric drawers into their respective slots in the frame. The smooth slide tracks ensure easy operation.
7. **Install Anti-Tip Device:** Follow the specific instructions in the assembly guide to attach the anti-tip

device to the back of the dresser and securely fasten it to a wall stud.

5. OPERATING INSTRUCTIONS (USAGE)

The WLIVE ASNG058DHS2 dresser is designed for versatile storage and media display.

- **Drawer Functionality:** The 6 detachable fabric drawers provide ample space for organizing clothing, accessories, and other household items. The curved handles and smooth slide tracks allow for easy opening and closing.
- **TV Stand Capability:** The spacious wooden top surface is designed to accommodate a TV up to 50 inches. Ensure the TV's base fits within the dimensions of the top surface (42.3" L x 15.6" W) and its weight does not exceed 100 lbs.
- **Display Surface:** The wooden top also serves as an ideal display area for decorative items, lamps, books, or other small ornaments.




Image 5.1: The dresser top is suitable for TVs up to 50 inches.



PLENTY OF STORAGE SPACE

Image 5.2: The six fabric drawers offer generous storage capacity for diverse items.

6. MAINTENANCE AND CARE

Proper care will help maintain the appearance and functionality of your dresser.

- **Cleaning the Wooden Top:** Wipe the wooden top surface with a dry cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. The P2 grade artificial wood is scratch-resistant and easy to clean.
- **Cleaning Fabric Drawers:** For light cleaning, use a soft, dry cloth. For spills or stains, gently blot with a damp cloth and mild soap, then air dry completely. Do not machine wash the fabric drawers.
- **Frame Care:** The metal frame can be wiped clean with a dry or slightly damp cloth.
- **Adjustable Feet:** Periodically check and adjust the feet to ensure the dresser remains level and stable, protecting your floor from scratches.



Image 6.1: The 4.4-inch clearance beneath the dresser allows for easy cleaning.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common solutions:

Problem	Possible Cause	Solution
Dresser is wobbly or unstable.	Uneven floor; loose frame connections.	Adjust the 5 adjustable feet until the dresser is level. Check and tighten all frame screws. Ensure the anti-tip device is properly installed.
Drawers do not slide smoothly.	Drawer not inserted correctly; obstruction in the slide track.	Remove the drawer and reinsert it, ensuring it aligns with the slide tracks. Check for any debris or obstructions in the tracks.
Fabric drawers appear misshapen.	Bottom panel not fully inserted or shifted.	Remove items from the drawer, ensure the bottom panel is fully and correctly inserted.

Problem	Possible Cause	Solution
Missing parts during assembly.	Packaging error.	Contact WLIVE customer support with your purchase details and the specific missing parts.

8. SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Model Name	ASNG058DHS2
Product Dimensions (L x W x H)	42.3" x 15.6" x 29.8"
Color	Rustic Brown
Item Weight	29.8 Pounds
Number of Drawers	6
Material	Metal Frame, P2 Grade Artificial Wood Top, Fabric Drawers (3-tier fiberboard and non-woven fabric)
Assembly Required	Yes
TV Size Compatibility	Up to 50 inches
Special Features	Anti-tip device, Adjustable feet, Curved handles, Smooth slide tracks

PRODUCT SIZE



Image 8.1: Detailed product dimensions.

9. WARRANTY AND SUPPORT

WLIVE is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For any questions, missing parts, assembly assistance, or other support needs, please contact the WLIVE professional after-sales team. Refer to the contact information provided with your purchase or visit the official WLIVE website for support options.