

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE ASNG102DHS2 4-Drawer Fabric Dresser Instruction Manual

WLIVE ASNG102DHS2

WLIVE ASNG102DHS2 4-Drawer Fabric Dresser Instruction Manual

Model: ASNG102DHS2

1. INTRODUCTION

Thank you for choosing the WLIVE ASNG102DHS2 4-Drawer Fabric Dresser. This instruction manual provides essential information for the safe assembly, operation, and maintenance of your new storage unit. Please read this manual thoroughly before beginning assembly and retain it for future reference.

This vertical storage tower is designed to provide organized storage for various items such as clothing, blankets, and accessories. Its compact design makes it suitable for use in bedrooms, hallways, entryways, and closets.





This image displays the WLIVE 4-drawer fabric dresser in its rustic brown wood grain finish. The top drawer is slightly open, revealing the interior storage space. The dresser features a sturdy black steel frame and a wood-look top surface.

2. SAFETY INFORMATION

To ensure safe use of this product, please adhere to the following guidelines:

- **Weight Limits:** Do not exceed the maximum weight capacity of 6.6 pounds (3 kg) per drawer. The total weight on the wood top should not exceed 10 pounds (4.5 kg). The overall unit capacity is 66 pounds (30 kg). Overloading can cause instability and damage.
- **Anti-Tip Device:** If an anti-tip device is included, it is highly recommended to install it to prevent accidental tipping, especially in households with children or pets.
- **Stable Placement:** Always place the dresser on a flat, level, and stable surface. Adjust the feet as necessary to ensure stability.
- **Assembly:** Follow all assembly instructions carefully. Do not use power tools for assembly unless specifically

instructed, as this may overtighten screws and damage components.

- **Children:** Do not allow children to climb on or play with the dresser. Keep small parts and packaging materials away from children.
- **Maintenance:** Regularly check all connections and fasteners to ensure they remain tight. Retighten as needed.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all parts and hardware are present and undamaged. Refer to the detailed parts list provided in the separate assembly guide included with your product for a complete inventory.

Typically, your package will include:

- Steel frame components
- Wood top panel
- Fabric drawers (4 units)
- Adjustable feet
- Assembly hardware (screws, wrench, etc.)
- Assembly instruction manual

4. SETUP AND ASSEMBLY


Assembly of the WLIVE ASNG102DHS2 dresser is designed to be straightforward. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Compare them with the parts list in your assembly guide.
2. **Assemble Frame:** Connect the steel frame components according to the diagrams in the assembly guide. Ensure all screws are securely tightened, but do not overtighten.
3. **Attach Wood Top:** Secure the wood top panel to the assembled steel frame.
4. **Install Adjustable Feet:** Screw the adjustable plastic feet into the bottom of the frame. Adjust them to ensure the dresser is level and stable on your floor.
5. **Prepare Drawers:** Unfold each fabric drawer and insert the bottom support panel to give it shape.
6. **Insert Drawers:** Slide the prepared fabric drawers into their designated slots within the frame.



The dresser is shown in a bedroom setting, positioned beside a bed. Several fabric drawers are pulled open, illustrating their capacity for storing various items like clothing and accessories. A lamp and decorative items are placed on the wood top.



This image illustrates the structural components of the dresser, including the steel frame and the attachment points for the wood top and drawers, providing a visual aid for assembly.



A close-up view of the 360-degree adjustable feet, which allow for leveling the dresser on uneven floor surfaces to enhance stability.

5. OPERATING INSTRUCTIONS

The WLIVE ASNG102DHS2 dresser is designed for simple and efficient storage.

Using the Drawers:

- Each drawer features an easy-pull handle for smooth opening and closing.
- The fabric drawers are foldable and removable, allowing for flexible storage solutions or easy transport.
- Organize clothes, blankets, scarves, socks, and other accessories within the drawers. Ensure items are evenly distributed and do not exceed the 6.6 lb (3 kg) weight limit per drawer.

Utilizing the Wood Top:

- The sturdy wood top provides a hard surface suitable for displaying lamps, clocks, books, glasses, or other decorative items.
- Do not place excessively heavy items on the wood top; adhere to the 10 lb (4.5 kg) weight limit.



6.6 LBS

Each drawer
capacity



12-15



7-10



LARGE STORAGE CAPACITY



A detailed view of one of the fabric drawers, demonstrating its internal storage space. The drawer contains folded garments, indicating its suitability for organizing clothing items. The rustic brown wood grain print of the drawer front is clearly visible.

PRODUCT SIZE



This diagram provides key measurements for the dresser: 15.7 inches length, 11.8 inches width, and 38.7 inches height. It also indicates that each drawer has a capacity of 6.6 pounds and the overall unit can hold up to 66 pounds. A visual representation of a drawer filled with folded clothes is included.

6. MAINTENANCE AND CARE

Proper care will extend the lifespan and maintain the appearance of your WLIVE dresser.

- **Cleaning the Wood Top:** The wood top is water-resistant and wear-resistant. Wipe it clean with a dry cloth. For spills, wipe immediately with a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning Fabric Drawers:** The high-quality non-woven fabric drawers are easy to clean. Spot clean with a damp cloth and mild soap if necessary. Allow to air dry completely before reinserting into the frame. Do not machine wash or tumble dry.
- **Frame Care:** Wipe the steel frame with a dry or slightly damp cloth to remove dust.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they are tight. Retighten any loose fasteners to maintain structural integrity.

This composite image highlights several functional aspects of the dresser. It shows the water-resistant and wear-resistant properties of the wood top, the 360-degree adjustable feet for stability on uneven surfaces, and the ergonomic design of the easy-to-pull handles on the drawers.

This image breaks down the construction of the dresser drawers, showing three distinct layers: an outer Oxford Fabric layer, an MDF board for structural support, and an inner non-woven fabric lining. This design contributes to the drawer's durability and shape retention.

7. TROUBLESHOOTING

If you encounter any issues with your WLIVE dresser, please refer to the following common solutions:

Problem	Possible Cause	Solution
Dresser is wobbly or unstable.	Uneven floor surface; loose connections.	Adjust the plastic feet at the bottom of the frame until the dresser is stable. Check and tighten all screws.
Drawers do not slide in smoothly or fit properly.	Drawer not fully unfolded; items inside are obstructing; frame assembled incorrectly.	Ensure the bottom support panel is fully inserted into each drawer. Check for any items blocking the drawer path. Review assembly instructions to confirm the frame is correctly put together.
Missing parts or damaged components.	Packaging error or transit damage.	Do not proceed with assembly. Contact WLIVE customer support immediately for assistance and replacement parts.
Chemical smell from fabric drawers.	New product odor from manufacturing process.	Allow drawers to air out in a well-ventilated area for a few days before use. The smell should dissipate.

8. PRODUCT SPECIFICATIONS

- **Brand:** WLIVE
- **Model Name:** ASNG102DHS2
- **Product Dimensions:** 15.7" L x 11.8" W x 38.7" H
- **Item Weight:** 13.75 pounds (6.24 kg)
- **Color:** Rustic Brown Wood Grain Print
- **Room Type:** Bedroom, Hallway, Entryway, Closets
- **Number of Drawers:** 4
- **Drawer Type:** Fabric, Removable, Foldable
- **Drawer Capacity:** 6.6 pounds (3 kg) per drawer
- **Overall Weight Capacity:** 66 pounds (30 kg)
- **Materials:** Steel frame, Wood top (textured, water-resistant), Oxford Fabric, MDF Board, Non-Woven Fabric
- **Assembly Required:** Yes
- **Product Care Instructions:** Wipe with Dry Cloth

9. WARRANTY AND SUPPORT

The WLIVE ASNG102DHS2 4-Drawer Fabric Dresser comes with a**Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty documentation included with your purchase or visit the official WLIVE website.

If you require assistance with assembly, have questions about product functionality, or need to report missing/damaged parts, please contact WLIVE customer support. Contact information can typically be found on the product packaging, the WLIVE brand store on Amazon, or their official website.

When contacting support, please have your model number (ASNG102DHS2) and purchase information readily available to expedite the process.

© 2025 WLIVE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09SH38JRR>

More documents and user manuals: <https://manuals.plus/>