

IBELL IBLFM700BT

iBELL FM700BT Portable FM Radio Instruction Manual

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your iBELL FM700BT Portable FM Radio. This versatile device combines an FM radio with a Bluetooth speaker, USB, SD card slot, and MP3 player, offering multiple audio playback options. Please read these instructions carefully before using the product and retain them for future reference.

Key Features:

- Multi-functional: FM Radio, Bluetooth Speaker, USB, SD Slot, MP3 Player.
- Dynamic 3-band speaker for clear audio.
- Bluetooth connectivity with up to 10 meters range.
- Built-in rechargeable battery for portability.
- High sensitivity receiver and telescopic antenna for enhanced radio reception.

2. PRODUCT OVERVIEW

Components and Controls

Familiarize yourself with the various parts and controls of your iBELL FM700BT radio:

AM/FM/SW
3 BAND RADIO



Front view of the iBELL FM700BT radio, highlighting the telescopic antenna, TF SD card slot, USB port, and tuning knob.

WoodenFinish


*Built in
Dynamic Speaker*



Power Cord



Stylish Handle



*Stylish Tuning
Knob*



Telescopic Antenna

Detailed view of the iBELL FM700BT controls, including the power cord input, stylish handle, tuning knob, and telescopic antenna.

- **Telescopic Antenna:** Extend for improved FM/SW radio reception.
- **Tuning Knob:** Rotate to select radio frequencies.
- **Mode Selector Switch:** Toggle between FM, AM, SW, Bluetooth (BT), USB, and SD card modes.
- **Volume Control / Power Switch:** Rotate to adjust volume; push to turn the device ON/OFF.
- **USB Port:** Insert USB flash drives for MP3 playback.
- **TF SD Card Slot:** Insert SD/TF memory cards for MP3 playback.
- **Power Cord Input:** Connect the AC power cord for direct power or charging.
- **Battery Compartment:** Located at the back, for UM-1 size batteries.

3. SETUP

Powering the Device

The iBELL FM700BT can be powered by AC electricity or internal batteries.



Power cord

AC220V / 50HZ
DC:3V (UM-1Size Batteries X2)
Batteries Not Included



Side view of the iBELL FM700BT, showing the AC power input, battery compartment details, and power/volume switch.

- **AC Power:** Connect the provided power cord to the AC power input on the side of the radio and then to a standard 220V/50Hz wall outlet. The internal rechargeable battery will charge automatically when connected to AC power.
- **Battery Power:** For portable use, the device operates on its built-in rechargeable battery. For extended use or if the internal battery is depleted, you can also insert two UM-1 size batteries (not included) into the battery compartment. Ensure correct polarity when inserting batteries.

4. OPERATING INSTRUCTIONS

4.1. FM Radio Operation

1. Turn the Volume/Power knob clockwise to power on the device.
2. Set the mode selector switch to FM, AM, or SW (Shortwave) as desired.
3. Extend the telescopic antenna for optimal reception.
4. Rotate the Tuning knob to scan for radio stations. The frequency display will indicate the current station.
5. Adjust the Volume/Power knob to your preferred listening level.

4.2. Bluetooth Mode

1. Turn on the device and set the mode selector switch to BT (Bluetooth).
2. The device will enter pairing mode, indicated by an audible prompt or flashing LED.
3. On your smartphone, tablet, or other Bluetooth-enabled device, search for available Bluetooth devices.
4. Select "iBELL FM700BT" from the list to pair. Once paired, you will hear a confirmation sound.
5. You can now stream audio from your connected device to the radio.

4.3. USB and SD Card Playback

1. Turn on the device.
2. Insert a USB flash drive into the USB port or an SD/TF memory card into the SD card slot.
3. Set the mode selector switch to USB or SD. The device will automatically detect and begin playing MP3 audio files from the inserted media.
4. Use the playback control buttons (if available) to skip tracks or pause playback.

5. MAINTENANCE

- Keep the device dry. Avoid exposure to water or high humidity.
- Clean the exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the device to direct sunlight or extreme temperatures.
- When not in use for extended periods, disconnect from AC power and remove external batteries (if applicable).

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Device is off; AC cord not connected; Battery depleted or incorrectly inserted.	Turn on the device. Connect AC power. Check battery charge/insertion.
No sound	Volume too low; Incorrect mode selected; Media not playing.	Increase volume. Select correct mode (FM, BT, USB/SD). Ensure media is playing.
Poor radio reception	Antenna not extended; Weak signal area.	Fully extend the telescopic antenna. Reposition the radio for better signal.
Bluetooth not connecting	Device not in pairing mode; Bluetooth disabled on source device; Out of range.	Ensure radio is in BT mode. Enable Bluetooth on your source device. Move source device closer to the radio (within 10m).

7. SPECIFICATIONS



Image displaying the dimensions of the iBELL FM700BT radio: 18.5 cm (L) x 6.5 cm (W) x 12 cm (H).

Feature	Detail
Brand	IBELL
Model Number	IBLFM700BT
Colour	Brown
Product Dimensions (L x W x H)	18.5 x 6.5 x 12 Centimeters
Item Weight	860 Grams
Connectivity Technology	Bluetooth
Tuner Type	FM
Radio Bands Supported	3-Band (FM, AM, SW)
Power Source	Battery Powered, AC 220V/50HZ DC:3V

Feature	Detail
Batteries Required	2 x UM-1 Size Batteries (not included)
Hardware Interface	USB
Special Feature	Portable
Display Type	LED
Compatible Devices	Headphone, Speaker

8. WARRANTY AND SUPPORT



Image showing the '1 Year Warranty' sticker on the iBELL FM700BT radio.

Warranty Information:

The iBELL FM700BT comes with a 1-year warranty from the date of purchase. For warranty claims or service, please retain your purchase receipt.

Customer Support:

For any queries, technical assistance, or service requests, please contact iBELL customer support:

- **Phone:** 1800 2020 260
- **Email:** connect@ibellstore.com
- **Address:** Innovative Technologies, Fida's Building, Thottumugham P.O, Aluva, Kerala - 683105