

[Manuals.plus](#) /

› [SOMIC](#) /

› SOMIC GS510 Pro Cat Ear Headphones User Manual

SOMIC GS510 Pro

SOMIC GS510 Pro Cat Ear Headphones User Manual

Model: GS510 Pro

1. INTRODUCTION

The SOMIC GS510 Pro Cat Ear Headphones offer versatile audio connectivity and immersive sound for gaming, music, and communication. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.

What's in the Box

- Wireless Headset
- Wireless USB Transmitter
- 3.5mm Auxiliary Cable



Image: SOMIC GS510 Pro Cat Ear Headphones and included accessories.

2. SETUP

Charging the Headset

Connect the headset to a power source using the provided USB Type-C charging cable. A full charge takes approximately 2 hours and provides up to 8 hours of playtime (at 50% volume).

Connectivity Options

The GS510 Pro offers three connection modes: 2.4GHz Wireless, Bluetooth, and Wired (3.5mm auxiliary cable).

2.4GHz Wireless Connection (USB Dongle)

This mode provides a stable, low-latency connection ideal for gaming on PS4, PS5, laptops, and PCs.

1. Plug the 2.4GHz wireless USB transmitter into an available USB port on your device.
2. Power on the headset by holding the power button for 2 seconds.
3. The headset will automatically connect to the dongle. A successful connection is indicated by a steady light on the dongle.

Bluetooth Connection

Use Bluetooth for convenient wireless audio with smartphones, tablets, and other Bluetooth-enabled devices.

1. Ensure the 2.4GHz USB dongle is disconnected from your device.
2. Power on the headset by holding the power button for 2 seconds.
3. Activate Bluetooth on your device and search for "SOMIC STINCOO GS510" in the available devices list.
4. Select the headset to pair. A voice prompt will confirm the connection.

Wired Connection (3.5mm Auxiliary Cable)

For universal compatibility with any device featuring a 3.5mm audio jack, including Xbox controllers, Nintendo Switch, and other gaming/audio devices.

1. Plug the detachable 3.5mm auxiliary cable into the headset's 3.5mm port.
2. Connect the other end of the cable to your device's 3.5mm audio jack.
3. The headset will operate in wired mode. Note that RGB lighting is not supported in wired mode.

WIDE COMPATIBILITY

Support wireless/wired/Bluetooth three modes, suitable for various scenarios



Image: Wide compatibility options for the SOMIC GS510 Pro headset.

Video: Unboxing and initial setup of the SOMIC GS510 Pro Wireless Gaming Headset, demonstrating components and connection methods.

3. OPERATING INSTRUCTIONS

Headset Controls

The left earcup houses all primary controls:

- **ON/OFF Button:** Press and hold for 2 seconds to power on/off.
- **Mode Button:** Cycles through sound effect modes (Game, Music, Movie).
- **Microphone Mute Switch:** Toggle to mute/unmute the microphone. The microphone's LED indicator will show its

status.

- **Volume Wheel:** Adjusts the audio volume up or down.



Image: Detailed view of the headset controls.

RGB Lighting Effects

The headset features seven RGB light options and a multicolor cycling mode. To change the lighting:

- Press and hold the light touch key on the earcup for 3 seconds to cycle through colors.
- Tap the light touch key three times to turn off the lights entirely.

DIY MAGNETIC FACE COVERS

Sweet design that are detachable to change up your style & mood.



Image: Headset showcasing its RGB lighting effects.

Video: Demonstration of the headset's RGB lights changing colors by touch.

Retractable Microphone

The omnidirectional microphone can be retracted and rotated 120 degrees for clear communication or stowed away when not in use.



RETRACTABLE MICROPHONE CAN BE STOWED AWAY WHEN NOT IN USE

Precision Pickup Mic Reduces Background Noise For Crystal Clear Communication

Image: The retractable and adjustable microphone feature.

Sound Effect Modes

Customize your audio experience with three distinct sound effect settings:

- **Game Mode:** Optimized for immersive gaming audio.
- **Music Mode:** Enhanced for music listening.
- **Movie Mode:** Tailored for cinematic experiences.

Switch between modes using the dedicated Mode button on the left earcup. A voice prompt will indicate the current mode.

THREE SOUND EFFECT MODES

Scene change, sound isn't compromised.



When switching sound effects, the headset is accompanied by voice prompt.

Image: Sound effect modes selection.

Customizable Magnetic Face Covers

The headset features magnetic face covers on the earcups that can be easily detached and replaced to personalize your style.

BLUETOOTH WIRELESS CONNECTION

Up to
10

Hour Working Time

Up to
33ft.

of Range

LOW-LATENCY 2.4GHz WIRELESS

Image: Magnetic face covers for customization.

4. COMPATIBILITY

The SOMIC GS510 Pro headset is compatible with a wide range of devices:

- PC
- PS4
- PS5
- Nintendo Switch
- Laptop
- Mac
- Smartphone

5. MAINTENANCE

To ensure the longevity and optimal performance of your SOMIC GS510 Pro headset, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headset. For the leather and plastic surfaces, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Handle cables gently. Avoid sharp bends or excessive pulling to prevent damage.
- **Avoid Moisture:** The headset is not water-resistant. Keep it away from liquids to prevent internal damage.

6. TROUBLESHOOTING

Connection Issues (2.4GHz Wireless)

If the headset fails to connect via the 2.4GHz USB dongle:

1. Ensure the headset is powered on and fully charged.
2. Try plugging the USB dongle into a different USB port on your device.
3. **Resetting the Dongle:** Locate the small reset hole next to the LED indicator on the USB dongle. Insert a small pin (e.g., a paperclip) and push in for at least one second until the LED rapidly blinks blue. Ensure the headset is powered on during this process.

RGB Lights Not Working in Wired Mode

When using the 3.5mm auxiliary cable for a wired connection, the RGB lights will turn off. This is normal behavior as RGB lighting is not supported in 3.5mm wired mode. The audio functionality will remain active.

Microphone Clarity Issues

If your voice is unclear or too quiet:

- Ensure the microphone mute switch is in the unmute position.
- Adjust the microphone's position closer to your mouth.
- Check and increase the microphone input volume settings on your connected device (PC, console, smartphone).

Short Battery Life

If you experience shorter than expected battery life:

- Ensure the headset is fully charged before use.
- Turning off the RGB lighting can significantly extend battery life.
- Reduce the volume level, as higher volumes consume more power.

Video: Troubleshooting guide for SOMIC GS510 Pro Wireless Headset, addressing common issues.

7. SPECIFICATIONS

Feature	Detail
Model Name	GS510 Pro
Connectivity Technology	2.4G Wireless, Bluetooth 5.0, 3.5mm Wired
Audio Driver Size	50 Millimeters
Frequency Response	20 KHz
Battery Life	8 Hours (at 50% volume)
Charging Time	2 Hours
Microphone	Retractable, 120° Rotating, Omnidirectional
Special Features	RGB Lighting, Volume Control, Microphone Included
Material	Leather, Plastic
Item Weight	386 Grams (13.6 ounces)
Product Dimensions	3.94 x 6.3 x 1.69 inches

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact SOMIC customer service directly. Keep your purchase receipt for any warranty claims.

© 2023 SOMIC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09SKXMRM5>

More documents and user manuals: <https://manuals.plus/>