

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Fodsports](#) /

› [Fodsports FX10C Motorcycle Bluetooth Mesh Intercom Speaker & Microphone Instruction Manual](#)

Fodsports FX10C



Fodsports FX10C Motorcycle Bluetooth Mesh Intercom Speaker & Microphone Instruction Manual

Model: FX10C

1. PRODUCT OVERVIEW

This kit provides replacement speaker and microphone components for the Fodsports FX10C Motorcycle Bluetooth Mesh Intercom system. It is designed to ensure clear audio communication and is compatible with the V6S Bluetooth intercom.

The components are made with high-quality materials, offering clear sound with noise reduction functionality. The design allows for simple installation in various helmet types.



This image displays the Fodsports FX10C intercom unit, packing box, speaker and microphone kits, USB cable, wrench and screw, clip mounting bracket, 3M tape bracket, Velcro, and user manual. It also illustrates two common

2. SETUP AND INSTALLATION

Proper installation of the speaker and microphone is crucial for optimal performance and comfort.

Follow these steps carefully:

- Prepare Your Helmet:** Carefully remove the inner lining and cheek pads of your helmet to access the ear pockets and chin bar area.
- Attach Velcro Pads:** Apply the provided Velcro pads to the inside of the helmet's ear pockets where the speakers will sit. Ensure the surface is clean and dry before applying.
- Install Speakers:** Securely attach the speakers to the Velcro pads in the ear pockets. Position them directly over your ears for the best audio experience.
- Install Microphone:** Choose between the hard tube microphone (for open-face/flip-up helmets) or the soft microphone (for full-face helmets). Attach the microphone to the chin bar area using its adhesive base, ensuring it is close to your mouth for clear voice pickup.
- Route Cables:** Carefully route all cables under the helmet's lining and padding to keep them tidy and prevent interference with comfort or safety. Ensure cables do not obstruct helmet removal or emergency release systems.
- Reassemble Helmet:** Once all components are securely in place and cables are routed, reinstall the helmet's inner lining and cheek pads.

Installation Video Guides:

This video provides a step-by-step guide on how to install a Fodsports FX8 PRO intercom headset onto a motorcycle helmet. It covers removing helmet lining, installing Velcro, placing speakers and microphone, and reassembling the helmet. The process is similar for the FX10C model.

This video illustrates the installation procedure for the Fodsports T1 PRO intercom. It shows how to prepare the helmet, attach the mounting clamp, and connect the speaker and microphone components. The installation principles apply to the FX10C model.

3. OPERATING INSTRUCTIONS

The Fodsports FX10C intercom is designed for intuitive operation, even with gloves on. Key functions are controlled via the multi-function button and rotary dial.

Basic Functions:

- Power On/Off:** Press and hold the ON/OFF button for 3 seconds.
- Pairing Mode:** Press and hold the function button for 3 seconds until the red and blue indicator lights flash.
- Answer/End Call:** Short press the function button.
- Reject Call:** Long press the function button for 1 second.
- Volume Adjustment:** Rotate the dial forward or backward for 1 second to adjust volume.

- **Next/Previous Song:** Rotate the dial forward or backward once.
- **Play/Pause Music:** Short press the function button.
- **FM Radio On/Off:** Double-click the ON/OFF button.
- **Next/Previous FM Channel:** Rotate the dial forward or backward once.

Operation Video Guides:

This video guides users through connecting their mobile phone to the Fodsports intercom via Bluetooth, managing phone calls (answering, rejecting), playing music, and operating the FM radio feature. It highlights the use of the function button and rotary dial for various controls.

This video provides an overview of the Fodsports FX6S intercom's key features and how to operate them, including power on/off, pairing, volume adjustment, and mode switching. The operational principles are largely consistent across Fodsports intercom models like the FX10C.

4. MAINTENANCE

To ensure the longevity and optimal performance of your Fodsports FX10C components, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to clean the intercom unit and speakers. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the intercom in a dry, cool place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cables to prevent damage.
- **Water Exposure:** While designed with some water resistance, avoid submerging the unit in water. Ensure the USB port cover is securely closed.

5. TROUBLESHOOTING

If you encounter issues with your Fodsports FX10C components, try the following troubleshooting steps:

- **No Power:** Ensure the unit is fully charged. Check the USB charging cable and power source.
- **Pairing Issues:** Make sure the intercom is in pairing mode (flashing red and blue lights). Ensure Bluetooth is enabled on your mobile device and try restarting both devices.
- **No Sound/Low Volume:** Check that the speakers are correctly positioned over your ears. Verify the volume level on both the intercom and your connected device. Ensure the microphone cable is securely connected.
- **Distorted Audio:** Reduce the volume level on both the intercom and your connected device. Check for any loose connections.
- **Intermittent Connection:** Ensure your mobile device is within the Bluetooth range (up to 10 meters). Avoid physical obstructions between the intercom and your device.

6. SPECIFICATIONS

Feature	Detail
Model Name	FX10C
Brand	Fodsports
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Version	4.0
Bluetooth Range	10 Meters
Compatible Devices	V6S Bluetooth Intercom
Special Feature	Microphone Included, Noise Cancellation
Noise Control	Adaptive Noise Cancellation
Material	Plastic
Item Weight	1.76 ounces (50 Grams)
Headphones Jack	3.5 mm Jack
Included Components	Cable

7. WARRANTY & SUPPORT

Fodsports offers a 6-month warranty free of charge for this product. You can extend your warranty by an additional 6 months by registering your product via the Fodsports Office Website. For any problems during your use, you can reach out to Fodsports technical support.

For more information or to register your product, please visit the official [Fodsports Store](#).