

Pemberly Row PR-4753-2352709

Pemberly Row Farmhouse Wood Breakfast Nook Set

Model: PR-4753-2352709

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and care of your Pemberly Row Farmhouse Wood Breakfast Nook Set. Please read all instructions carefully before assembly and use to ensure safe and proper installation and longevity of your furniture. This set is designed to offer a comfortable and functional dining solution, especially suitable for smaller spaces, featuring convenient storage and versatile configuration options.

2. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included parts list in your packaging. If any parts are missing or damaged, please contact Pemberly Row customer support.

Typical components include:

- Dining Table
- Long Bench with Storage
- Short Bench with Storage
- Corner Connector Piece
- Assembly Hardware (screws, bolts, tools)

3. ASSEMBLY INSTRUCTIONS

Assembly is required for this breakfast nook set. It is recommended to have at least two adults for assembly. Follow the step-by-step instructions provided in the separate assembly manual included with your product. Ensure all connections are secure before use.

3.1 Reversible Benches

The benches are designed to be reversible, allowing you to configure the long and short sections to fit either a left-hand or right-hand corner orientation in your space. Carefully plan your desired layout before attaching the benches to the corner piece.

3.2 Tools Required

Standard household tools such as a Phillips head screwdriver and an Allen wrench (often included) may be required. Do not overtighten screws to avoid damaging the wood.



Image: Fully assembled breakfast nook set, showcasing the table, corner bench, and standalone bench.

4. FEATURES AND OPERATION

4.1 Lift Seats and Hidden Storage

Both the long and short benches feature lift-up seats that reveal hidden storage compartments. These are ideal for stowing away dining accessories, board games, or other household items, helping to keep your space tidy.



Image: The benches with their seats lifted, showing the internal storage compartments.

4.2 Space Optimization

The L-shaped design of the nook set is specifically crafted to maximize seating in compact dining areas, fitting snugly into a corner to save floor space while accommodating multiple people comfortably.

Your browser does not support the video tag.

Video: A demonstration of the breakfast nook set in a kitchen corner, highlighting its space-saving design and aesthetic appeal.

Your browser does not support the video tag.

Video: A detailed look at the table, benches, and corner piece, emphasizing the quality and functionality of the set.

5. CARE AND MAINTENANCE

To maintain the beauty and longevity of your Pemberly Row Breakfast Nook Set, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean spills immediately to prevent staining.
- **Heat and Moisture:** Use coasters and placemats to protect the table surface from heat and moisture.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Assembly:** Periodically check and tighten all hardware to ensure stability.

6. TROUBLESHOOTING

If you encounter any issues with your breakfast nook set, consider the following common solutions:

- **Wobbling:** Ensure all assembly hardware is securely tightened. Check that the furniture is placed on a level surface.
- **Stiff Lift Seats:** If the lift seats are stiff, check for any obstructions in the hinge mechanism. A small amount of silicone spray on the hinges may help.
- **Scratches/Dents:** Minor scratches or dents on wood surfaces can often be touched up with a wood repair kit or furniture marker matching the finish.

For persistent issues or concerns not addressed here, please contact Pemberly Row customer support.

7. SPECIFICATIONS

Attribute	Detail
Brand	Pemberly Row
Model Number	PR-4753-2352709
Product Dimensions	56 x 75 x 36 inches
Item Weight	260 pounds
Material	Wood (Mahogany)
Finish	Buckskin - Taupe Brown
Special Features	Lift seats, Hidden storage in benches, Reversible benches
UPC	195493330991

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or additional support, please refer to the documentation included with your purchase or contact Pemberly Row customer service directly. Keep your proof of purchase for any warranty claims.