

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 24V AC/DC Adapter Instruction Manual

UPBRIGHT Geek Aire CF2 16" Fan Power Supply

UpBright 24V AC/DC Adapter Instruction Manual

For Geek Aire CF2 Rechargeable Outdoor High Velocity Floor Fan

1. PRODUCT OVERVIEW

The UpBright 24V AC/DC Adapter is designed to provide reliable power to your Geek Aire CF2 Rechargeable Outdoor High Velocity Floor Fan. This adapter ensures efficient charging and operation, featuring multiple safety protections for secure use.



Image: The UpBright 24V AC/DC Adapter, a compact black power supply unit with a standard US plug and a barrel connector cable.

Key Features:

- **Universal Compatibility:** World Wide Input Voltage 100-240VAC 50/60Hz.
- **Safety Protections:** Equipped with OVP (Over Voltage output Protection), OCP (Over Current output Protection), and SCP (Short Circuit output Protection) for enhanced safety.
- **Durable Design:** Constructed with high-quality, environmentally friendly TPE material for flexibility and resistance to aging.
- **Space-Saving:** Designed to use only one outlet, leaving adjacent outlets free for other devices.

2. SETUP INSTRUCTIONS

2.1 Unpacking

Carefully remove the AC/DC adapter from its packaging. Inspect the adapter and cable for any visible damage. If any damage is observed, do not use the product and contact customer support.

2.2 Connecting the Adapter

1. Locate the power input port on your Geek Aire CF2 Rechargeable Outdoor High Velocity Floor Fan.
2. Insert the barrel connector of the UpBright AC/DC adapter firmly into the fan's power input port. Ensure a snug fit.



Image: A close-up view of the barrel connector end of the adapter cable, showing its cylindrical shape.

3. Plug the AC plug of the adapter into a standard 100-240VAC wall outlet.

UpBright AC Adapter Power Supply Compatible with:



Image: The UpBright AC/DC adapter connected to a yellow Geek Air CF2 fan, illustrating the setup.

3. OPERATION

3.1 Powering Your Device

Once connected to a power source, the UpBright AC/DC adapter will supply the necessary 24V power to your Geek Air CF2 fan. If the fan has a rechargeable battery, the adapter will simultaneously charge the battery while powering the fan.

3.2 Safety Features

The adapter incorporates multiple safety circuits to protect both the adapter and your connected device from electrical hazards.



Image: A diagram illustrating the safety features of the UpBright AC/DC adapter, including overcharge, overcurrent, shortage, lightning, overvoltage, and temperature protection.

3.3 Efficient Design

The compact design of the UpBright adapter ensures that it occupies minimal space on your wall outlet, allowing other outlets to remain accessible.

One Outlet Design

UpBright

Uses One Outlet



VS

Typical Charger:

Uses Two Outlets



- Did YOU know ?

UpBright chargers has one outlet design to keep other outlets free for your other devices!

UpBright

Image: A comparison showing the UpBright charger using one outlet and leaving space, versus a typical charger that blocks two outlets.

4. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your UpBright AC/DC adapter, follow these maintenance guidelines:

- **Keep Dry:** Avoid exposing the adapter to moisture or liquids.
- **Clean Gently:** Use a dry, soft cloth to clean the adapter. Do not use harsh chemicals or abrasive cleaners.
- **Proper Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handle Cable with Care:** Avoid sharp bends, kinks, or excessive pulling on the cable.

Flexible Wire More Durable

Selected high-quality environmentally friendly TPE material, toughness, anti-aging, not easy to break




Image: A visual representation of the adapter's flexible and durable wire, highlighting its resistance to bending and pulling.

5. TROUBLESHOOTING

If you encounter issues with your UpBright AC/DC adapter, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Fan not powering on or charging.	Adapter not properly connected; Wall outlet not active; Fan's battery is old/bad.	Ensure adapter is fully plugged into both the fan and the wall outlet. Test the wall outlet with another device. Note: Rechargeable batteries have a limited lifespan (typically 1-3 years) and may not accept a charge if old or faulty. This is not an adapter issue.
Adapter feels warm during use.	Normal operation; Overload.	A slight warmth is normal. If the adapter becomes excessively hot, disconnect it immediately and ensure it is used within its specified wattage.
Visible damage to adapter or cable.	Physical stress or impact.	Discontinue use immediately. Contact UpBright customer support for assistance.

6. TECHNICAL SPECIFICATIONS

Detailed specifications for the UpBright 24V AC/DC Adapter:

Specification	Value
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	24VDC
Wattage	24 watts
Connector Type	Barrel Connector
Compatible Devices	Geek Aire CF2 Rechargeable Outdoor High Velocity Floor Fan
Product Dimensions	4 x 3 x 2 inches
Item Weight	2.39 ounces
Included Components	1 x AC Adapter
Safety Features	OVP, OCP, SCP Protection
Certification	CE

7. WARRANTY AND CUSTOMER SUPPORT

UpBright stands behind the quality of its products. Your UpBright 24V AC/DC Adapter comes with the following:

- **30 Days Refund Policy:** If you are not satisfied with your purchase, you may be eligible for a refund within 30 days.
- **24 Months Exchange Policy:** UpBright offers a 24-month exchange policy for defective units.



Image: A representation of the UpBright Limited Warranty Certificate.

Customer Support:

For any inquiries, technical assistance, or warranty claims, please visit the official UpBright store or contact their customer service directly.

Visit the [UPBRIGHT Store on Amazon](#).

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question