

## ChooChoo EUR-ST180005-BR-NA

# ChooChoo Console Table with Drawers

Model: EUR-ST180005-BR-NA | Brand: ChooChoo

[Safety Information](#)   [Package Contents](#)   [Assembly Instructions](#)   [Usage](#)   [Maintenance](#)   [Troubleshooting](#)  
[Specifications](#)   [Warranty & Support](#)

## 1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **General Stability Warning:** Ensure the console table is placed on a flat, level surface. For added safety, it is recommended to anchor the table to the wall to prevent tipping, especially in households with children or pets.
- Do not stand on the table or allow children to climb on it.
- Do not exceed the recommended weight capacity for the tabletop or shelves.
- Keep small parts and hardware away from children to prevent choking hazards.

## 2. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- Assembly instructions
- All necessary hardware (screws, dowels, etc.)
- 2 Drawers
- 1 Shelf
- Tabletop and frame components

### 3. ASSEMBLY INSTRUCTIONS

Detailed instructions are provided to guide you through the assembly process step by step. All parts and accessories are numbered for easy identification. A screwdriver is recommended for assembly.

#### Overview of Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts using the provided numbering in the instruction manual.
3. Assemble the main frame of the console table.
4. Attach the bottom storage shelf to the frame.
5. Assemble the two drawers and install the drawer glides.
6. Insert the assembled drawers into the table frame.
7. Attach the retro handles to the drawers.
8. Ensure all connections are secure and the table is stable.

#### Visual Guide:




Figure 3.1: Detailed dimensions of the ChooChoo Console Table, including height, width, depth, and drawer measurements.




Figure 3.2: Exploded view highlighting key features such as environmental water-base paint, retro handles, two drawers for storage, classic X-design, anti-tip brackets, and a stable bottom shelf.

#### 4. USAGE

The ChooChoo Console Table is designed for versatile use in various indoor settings. Its narrow design and storage options make it a practical addition to your home.

- **Entryway Table:** Ideal for placing keys, mail, and decorative items upon entering your home.
- **Sofa Table:** Position behind a sofa to hold lamps, books, or beverages.
- **Accent Table:** Suitable for displaying plants, photo frames, or other decorative objects in living rooms, studies, or dining rooms.
- **Storage:** Utilize the two drawers for concealed storage of small items and the bottom shelf for magazines, baskets, or delicate objects.



Figure 4.1: The console table used in an entryway, featuring a lantern and a decorative box on top, and plants on the bottom shelf.



Figure 4.2: The console table adorned with a plant, books, an alarm clock, and a decorative lamp, showcasing its use as a functional and aesthetic piece.

## 5. MAINTENANCE

Proper care will ensure the longevity and appearance of your ChooChoo Console Table.

- **Cleaning:** Wipe the table surfaces with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the painted finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Heat:** Do not place hot items directly on the table surface. Use coasters or protective pads.

## 6. TROUBLESHOOTING

If you encounter any issues during assembly or use, refer to the following common solutions:

- **Difficulty with Drawer Assembly/Glides:**

- Ensure the assembly drawings for drawers and drawer slides are carefully reviewed.
- If screws for drawer glides (e.g., 9mm length for a 15mm thick divider) do not tighten properly, consider using slightly longer screws or securing the glides in offset locations to avoid interference and stripping the wood.
- Confirm that the wheels on the drawer glides are positioned correctly: wheels typically go on the back of the drawer, and on the divider, the wheels should be on the front with the largest opening in the glide facing up.

- **Table Wobbles:**

- Check that all screws and fasteners are tightened securely.
- Ensure the table is on a level surface. Adjust any leveling feet if present.
- Consider using the anti-tip brackets to secure the table to a wall for enhanced stability.

- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, do not proceed with assembly. Contact ChooChoo customer service immediately for assistance.

## 7. SPECIFICATIONS

<b>Brand</b>	ChooChoo
<b>Model Name</b>	ChooChoo Console Table
<b>Model Number</b>	EUR-ST180005-BR-NA
<b>Product Dimensions (D x W x H)</b>	11.8"D x 39.4"W x 31.5"H
<b>Color</b>	Espresso
<b>Frame Material</b>	Wood
<b>Top Material Type</b>	Rubber Wood
<b>Furniture Finish</b>	Painted
<b>Number of Drawers</b>	2
<b>Included Components</b>	Assembly instructions, hardware, 2 drawers, 1 shelf
<b>Required Assembly</b>	Yes
<b>Recommended People for Assembly</b>	2
<b>Product Care Instructions</b>	Wipe with Damp Cloth
<b>Warranty Type</b>	Limited

## 8. WARRANTY AND SUPPORT

The ChooChoo Console Table comes with a limited warranty. For specific details regarding warranty

coverage, please refer to the documentation included with your product or contact customer service.

**Customer Service:**

If you encounter any problems or have questions about your product, you can contact ChooChoo customer service. We are committed to helping you solve any issues within 24 hours.

Please visit the [ChooChoo Store on Amazon](#) for more information and contact options.