

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Phomemo](#) /

› [Phomemo Hard Carry Case Instruction Manual for D30, M02, Q31, M110, T02 Label Printers](#)

Phomemo Hard Carry Case

Phomemo Hard Carry Case Instruction Manual

For D30, M02, Q31, M110, T02 Label Printers

1. INTRODUCTION

This manual provides essential information for the proper use and care of your Phomemo Hard Carry Case. This case is designed to offer robust protection and organized storage for your compatible Phomemo label printer and its accessories.

2. COMPATIBLE DEVICES

The Phomemo Hard Carry Case is compatible with the following label printer models:

- Phomemo D30 Label Printer
- Phomemo T02 Label Printer
- Phomemo M110 Label Printer
- Phomemo M02 Label Printer
- Phomemo M02S Label Printer
- Phomemo M02 Pro Label Printer
- Phomemo Q30S Label Printer
- Memoking D30 Label Printer
- Niimbot D11 Label Printer
- Munbyn D110 Label Printer
- Jadens D110 Label Printer
- Nelko P21 Mini Labeler

The case can accommodate one printer, several rolls of label paper, and a USB charging cable.

3. PRODUCT FEATURES

- **Durable Construction:** The hard shell design provides protection against impacts and pressure.
- **Waterproof Exterior:** The outer material is designed to repel water, protecting contents from spills and light rain.

Stretch mesh bag

Sturdy and not easy to scratch



Wear-resistant and waterproof

Peace of mind when traveling outdoors

Image: Demonstrates the waterproof capability of the case exterior.

- **Dustproof Design:** Helps keep dust and debris away from your printer and supplies.
- **Internal Organization:** Features a built-in mesh pocket for accessories and an elastic strap to secure the printer.

Large capacity design



Make your items visible at a glance

Image: View of the case interior, showing the mesh pocket for label rolls and the elastic strap securing a label printer.

- **Smooth Zipper:** Equipped with a customized Phomemo logo zipper for easy and reliable opening and closing.
- **Carabiner Clip:** Includes a carabiner for convenient attachment to bags or hooks, enhancing portability.



With carabiner
easy to carry

Elastic strap

Firm without sliding
Not afraid of falling



Image: The case shown with its attached carabiner, highlighting its portability feature.

4. USAGE INSTRUCTIONS

- Opening the Case:** Unzip the case completely using the smooth zipper.
- Placing the Printer:** Gently place your compatible Phomemo label printer into the main compartment. Secure it with the elastic strap to prevent movement during transport.

Your browser does not support the video tag.

Video: Demonstrates how to place various Phomemo label printers (D30, Q30S, M02, M02S, M110, T02) into the hard carry case and secure them with the elastic strap, along with storing label rolls and charging cables.

- Storing Accessories:** Utilize the mesh pocket on the lid to store label paper rolls, USB cables, or other small accessories.

Plan the space reasonably Double the result with half the effort

Storage is easier



Image: Illustrates the organized storage capacity for a mini printer, consumables (paper rolls), and a data line within the case.

- Closing the Case:** Ensure all items are securely placed and then zip the case closed.
- Portability:** Use the attached carabiner to clip the case to a backpack, belt loop, or other convenient location for easy transport.

5. CARE AND MAINTENANCE

- Cleaning:** Wipe the exterior of the case with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- Drying:** If the case gets wet, allow it to air dry completely before closing or storing.
- Storage:** Store the case in a cool, dry place away from direct sunlight when not in use.
- Zipper Care:** If the zipper becomes stiff, a small amount of zipper lubricant can be applied to ensure smooth operation.

6. TROUBLESHOOTING

This section addresses common concerns related to the Phomemo Hard Carry Case.

Issue	Possible Cause	Solution
Case does not close properly.	Overfilling the case or items are not positioned correctly.	Ensure only compatible items are stored and arranged neatly. Do not force the zipper.
Zipper is stiff or stuck.	Dirt or lack of lubrication.	Clean the zipper teeth with a small brush. Apply a small amount of zipper lubricant or wax.
Printer moves inside the case.	Printer not secured by the elastic strap.	Always use the internal elastic strap to hold the printer firmly in place.

7. PRODUCT SPECIFICATIONS

- **Dimensions:** Approximately 150mm (L) x 100mm (W) x 60mm (H) (5.91 x 3.94 x 2.36 inches)

**Plan the space reasonably
Double the result with half the effort**

Storage is easier



Image: Visual representation of the case dimensions (150mm x 100mm x 60mm).

- **Weight:** Approximately 3.2 ounces (90.7 grams)
- **Material:** Durable Hard Shell Material
- **Closure Type:** Zipper
- **Color:** Grey (for this specific variant)

8. WARRANTY AND SUPPORT

For warranty information, product support, or to contact customer service, please refer to the official Phomemo website or the documentation included with your original product purchase. Keep your purchase receipt for warranty claims.