Dreo DR-HFV001 2022

Dreo Cordless Vacuum Cleaner

User Manual

1. Product Overview and Included Components

The Dreo Cordless Vacuum Cleaner is designed for efficient cleaning across various surfaces. Before beginning, ensure all components are present.



Figure 1: Dreo Cordless Vacuum Cleaner and all included accessories.

The package includes the main vacuum unit, extension wand, motorized brush head, 2-in-1 crevice tool, soft dusting

brush, flexible hose, wall-mount charging dock, power adapter, and two HEPA filters.



Figure 2: Detailed view of all accessories provided with the vacuum.

For a visual guide on unboxing and identifying components, please refer to the official video below.

Video 1: Official unboxing and overview of included components for the Dreo Cordless Vacuum Cleaner.

2. Setup and Charging

Assembly

To assemble the vacuum, connect the extension wand to the main unit until it clicks into place. Then, attach the motorized brush head to the other end of the extension wand, ensuring a secure connection.

Battery Installation and Charging

The Dreo Cordless Vacuum Cleaner features a detachable 3000mAh Lithium-Ion battery. Insert the battery into the main unit until it clicks. For initial use, fully charge the battery, which typically takes 6 hours.



Figure 3: The detachable battery slides into the main unit for power.

The vacuum comes with a wall-mount charging dock. Install the dock in a convenient location and connect the power adapter. You can charge the battery while it's attached to the vacuum on the dock, or detach it and charge it separately if you have an additional battery.

3. Operating Instructions

Power Modes and Suction Control

The vacuum offers 4 power levels, including Eco, Turbo, Max, and an Auto Mode. The LED display on the main unit shows the current power mode and remaining battery life.




Figure 4: The vacuum's LED display provides real-time information on battery level and selected suction mode.

In Auto Mode, the vacuum intelligently recognizes the surface type (e.g., hard floor, carpet) and automatically adjusts suction power for optimal cleaning. This feature ensures efficient cleaning without manual adjustments.



Figure 5: RootSense Technology automatically adapts suction power for various floor types.

For a demonstration of the different suction modes, please watch the video below.

Video 2: Demonstration of the vacuum's powerful suction and three different power modes.

Headlights

The motorized brush head is equipped with headlights that illuminate dust and debris in dimly lit areas, such as under furniture, ensuring thorough cleaning.




Figure 6: Headlights on the brush head reveal hidden dust for comprehensive cleaning.

Using Attachments

Utilize the various attachments for specialized cleaning tasks:

- **2-in-1 Crevice Tool:** Ideal for narrow gaps, corners, and edges.
- **Soft Dusting Brush:** Perfect for delicate surfaces, blinds, and upholstery.
- **Flexible Hose:** Extends reach for cleaning car interiors, high shelves, or tight spaces.



Figure 7: The vacuum unit with different attachments for versatile cleaning.

4. Maintenance

Emptying the Dustbin

To maintain optimal suction, empty the dustbin regularly. Press the one-click release button to open the dustbin and dispose of collected debris.

HEPA Filter Cleaning and Replacement

The vacuum is equipped with a washable HEPA filter. It is recommended to wash and air-dry the filter monthly. Replace the HEPA filter every three months to ensure peak performance and effective filtration of allergens and fine dust.

Brushroll Maintenance

Periodically check the brushroll for tangled hair or debris. The brushroll can be easily removed for cleaning and detangling to prevent reduced performance.

5. Troubleshooting

Reduced Suction Power

- Check if the dustbin is full and needs emptying.
- Inspect the HEPA filter for clogs; clean or replace if necessary.
- Ensure the brushroll is free of tangled hair or debris.
- Verify that all connections (wand, attachments) are secure.

Battery Not Charging

- Ensure the power adapter is securely plugged into both the wall outlet and the charging dock/vacuum.
- Check the LED display for charging indicators.
- Verify that the power outlet is functional.

Unusual Noises

- Turn off the vacuum and check for any obstructions in the brushroll or air pathways.
- Ensure all parts are correctly assembled and securely fastened.

6. Specifications

Feature	Specification

Brand	Dreo
Model Name	DR-HFV001 2022
Motor Horsepower	550 Watts
Suction Power	25kPa
Battery Type	Lithium-Ion
Battery Capacity	3000mAh
Runtime	Up to 60 minutes
Charging Time	6 Hours
Filter Type	HEPA Filter (Washable)
Dustbin Capacity	0.6 Liters
Noise Level	75 dB
Item Weight	6.1 pounds
Product Dimensions	13.95"L x 8.25"W x 30.75"H

7. Warranty and Support

Dreo offers a 30-month warranty for this product. For any support needs, please contact Dreo customer service.

Contact Information:

- Phone: (888) 520-3736
- Email: support@dreo.com
- Website: www.dreo.com

© 2023 Dreo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question