



Manuals.plus /

› Evolved Novelties /

› Evolved Novelties Pleasing Petal Silicone Rabbit Model 840678 User Manual

## Evolved Novelties 840678

# Evolved Novelties Pleasing Petal Silicone Rabbit

Model: 840678 - User Manual

## 1. INTRODUCTION

---

Thank you for choosing the Evolved Novelties Pleasing Petal Silicone Rabbit. This manual provides essential information for the safe and effective use, care, and maintenance of your product. Please read these instructions thoroughly before first use and retain them for future reference.

This product is designed for adult use only. Discontinue use immediately if any discomfort or irritation occurs. Consult a healthcare professional if you have any health concerns.

## 2. PRODUCT FEATURES

---

- Dual stimulation design with two independent vibrating motors.
- Main shaft features a deeply textured head and gentle curve.
- Smaller petal-shaped shaft includes a central tongue for targeted sensation.
- Flexible construction adapts to body contours.
- Each motor offers 10 powerful speeds and functions.
- Control buttons illuminate with blue LED lights when in use.
- Constructed from creamy smooth silicone.
- Handle base made from durable pearly white ABS plastic.
- Completely waterproof and submersible.
- Phthalate and latex-free materials.
- Rechargeable via included USB cable.

## 3. PACKAGE CONTENTS

---

- Evolved Novelties Pleasing Petal Silicone Rabbit (Model 840678)
- USB Charging Cable
- User Manual

## 4. SETUP AND CHARGING

---

### Initial Charge

Before first use, fully charge the device. Locate the charging port, typically at the base of the handle. Connect the provided USB charging cable to the device and plug the other end into a compatible USB power source (e.g., computer, USB wall adapter). The LED indicator lights will show charging status and turn solid when fully charged. A full charge typically takes 2-3 hours.





Image: Side view of the device, highlighting the charging port at the base.

## First Use Preparation

Clean the device thoroughly before its initial use. Refer to the 'Maintenance and Care' section for detailed cleaning instructions.

## 5. OPERATING INSTRUCTIONS

---

### Power On/Off

Press and hold the main power button (usually indicated by a power symbol) for 2-3 seconds to turn the device on or off. The LED lights will illuminate when the device is active.





Image: Front-side view of the device, illustrating the overall design and button placement.

## Controlling Vibrations

This device features two independent motors. Locate the control buttons for each motor. Typically, there will be separate buttons or a combination of buttons to control the main shaft's vibrations and the petal stimulator's vibrations.

- **Main Shaft Control:** Press the designated button(s) to cycle through 10 different vibration patterns and intensities for the main shaft.
- **Petal Stimulator Control:** Press the separate designated button(s) to cycle through 10 different vibration patterns and intensities for the petal-shaped stimulator.

Experiment with the controls to find your preferred settings. The blue LED lights will indicate which motor is active and its current setting.

## 6. MAINTENANCE AND CARE

---

### Cleaning

Clean the device thoroughly before and after each use. As the device is fully waterproof, it can be rinsed under warm running water. Use a mild soap or a specialized toy cleaner. Avoid harsh detergents, alcohol-based cleaners, or petroleum-based products, as these can damage the silicone material.

### Drying and Storage

Pat the device dry with a lint-free cloth or allow it to air dry completely. Store the device in a cool, dry place, away from direct sunlight and extreme temperatures. To prevent damage or degradation, avoid storing silicone products

with toys made from other materials (e.g., PVC, jelly).

## 7. TROUBLESHOOTING

---

- **Device does not turn on:** Ensure the device is fully charged. Connect it to the USB charging cable and allow sufficient time for charging.
- **Motors not vibrating:** Check if the device is powered on. Ensure the specific motor control buttons are being pressed correctly to activate or change patterns. Recharge the device if the battery is low.
- **LED lights not illuminating:** This may indicate a low battery or that the device is not powered on. Charge the device and attempt to power it on again. If the issue persists, contact customer support.
- **Reduced vibration strength:** A low battery can cause reduced vibration strength. Recharge the device fully.

## 8. SPECIFICATIONS

---

|                               |   |
|-------------------------------|---|
| <b>Model Number</b>           | 840678  |
| <b>Brand</b>                  | Evolved Novelties                               |
| <b>Material</b>               | Silicone, Acrylonitrile Butadiene Styrene (ABS) |
| <b>Dimensions (L x W x H)</b> | 9.65 x 3.54 x 2.36 inches                       |
| <b>Weight</b>                 | Under 0.5 lb (approx. 6.98 ounces)              |
| <b>Insertable Length</b>      | 4.5 inches                                      |
| <b>Waterproof</b>             | Yes, submersible                                |
| <b>Power Source</b>           | Rechargeable (USB cable included)               |





Image: Back view of the device, illustrating its full length and smooth texture.

## 9. SAFETY INFORMATION

---

- This product is intended for adult use only.
- Do not use if the product appears damaged or defective.
- Discontinue use immediately if you experience any pain, discomfort, or irritation.
- Consult a healthcare professional before use if you have any medical conditions or concerns.
- Keep out of reach of children.
- Do not share the device with others for hygiene reasons.
- Use only water-based lubricants with this product. Oil-based lubricants can damage silicone.
- Statements regarding this product have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

## 10. WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact Evolved Novelties customer service. Details can

typically be found on the product packaging or the official Evolved Novelties website. Please have your model number (840678) and purchase information ready when contacting support.