

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Soozier](#) /
- › [Soozier Poolside Basketball Hoop Stand Instruction Manual](#)

Soozier CAA61-0320231

Soozier Poolside Basketball Hoop Stand Instruction Manual

Model: CAA61-0320231

[Contents](#) [Assembly](#) [Introduction](#) [Operation](#) [Safety Information](#) [Maintenance](#) [Troubleshooting](#) [Package](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Soozier Poolside Basketball Hoop Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new basketball system. Please read all instructions carefully before use and retain this manual for future reference.

This portable basketball hoop system is designed for poolside use, offering adjustable height for various age groups and skill levels. It features a durable backboard, a weatherproof net, and a stable, fillable base for secure placement.





Image 1.1: The Soozier Poolside Basketball Hoop Stand, featuring a blue backboard, orange rim, and a blue base with wheels.



Image 1.2: A family enjoying the Soozier Poolside Basketball Hoop Stand in a swimming pool setting.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in serious injury or property damage.

- Always ensure the base is filled with the recommended amount of sand (99 lbs) or water (77 lbs) before use to prevent tipping.
- Do not hang on the rim or backboard. This can cause the unit to tip over, leading to injury.
- Keep children under supervision when using the basketball hoop, especially near water.
- Regularly inspect all components for wear, damage, or loose fasteners. Tighten any loose screws or bolts immediately.
- Do not attempt to move the unit when the base is filled. Drain the base or use the wheels carefully on a flat surface.
- Position the hoop on a stable, level surface away from obstacles.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. (California Proposition 65 Warning)
- Discontinue use if any part of the system becomes damaged or unstable.

3. PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer service.

- Backboard
- Rim and Net
- Main Pole Sections (Upper, Middle, Lower)
- Base with Wheels
- Support Brackets
- Hardware (Screws, Bolts, Washers, Nuts, Adjustment Knobs)
- Assembly Tools (may vary, typically wrenches)

4. ASSEMBLY INSTRUCTIONS (SETUP)

Assembly typically requires two adults. Follow these steps carefully:

1. **Attach Wheels to Base:** Secure the wheels to the designated slots on the underside of the base.
2. **Assemble Pole Sections:** Connect the lower, middle, and upper pole sections. Ensure they are securely fastened with the provided bolts and nuts.
3. **Attach Pole to Base:** Insert the assembled pole into the base. Secure it using the appropriate bolts and support brackets.
4. **Mount Backboard:** Attach the backboard to the upper pole section. Ensure it is centered and firmly secured.
5. **Install Rim and Net:** Fasten the rim to the backboard using the provided hardware. Attach the weatherproof nylon net to the rim.



Image 4.1: Detail of the rim securely attached to the backboard with bolts.



Image 4.2: Visual representation of the durable net, stylish backboard design, and stable base.

5. OPERATING INSTRUCTIONS

5.1. Filling the Base for Stability

Before using the basketball hoop, the base must be filled to ensure stability and prevent tipping. The base can be filled with either sand or water.

- **Sand:** Fill with up to 99 lbs (approximately 45 kg) of dry sand. Sand provides greater stability and is less prone to freezing in colder temperatures.
- **Water:** Fill with up to 77 lbs (approximately 35 kg) of water. Water is easier to fill and empty but may freeze in cold weather, potentially damaging the base.

Ensure the fill cap is securely closed after filling.

STURDY BASE

Can be filled with up to 99lbs sand or 77lbs water



Image 5.1: The sturdy base with its fill cap, indicating options to fill with sand or water for stability.

5.2. Adjusting Height

The basketball hoop's height can be adjusted to suit different users and activities. The adjustable range is from 36.5 inches to 48.5 inches (92.5 cm to 123 cm) at the rim.

1. Locate the adjustment knob on the main pole.
2. Loosen the adjustment knob by turning it counter-clockwise.
3. Carefully slide the upper pole section up or down to the desired height.
4. Once the desired height is reached, tighten the adjustment knob securely by turning it clockwise to lock the pole in place.

HEIGHT ADJUSTABLE

Adjustment Knobs



Adjustable height to
suit different age groups




Image 5.2: The adjustment knob used to modify the hoop's height.



Image 5.3: A closer view of the height adjustment mechanism, showing the knob and bolt.

5.3. Portability

The base is equipped with two wheels for easy relocation. To move the basketball hoop:

1. Ensure the base is empty or partially empty if moving a short distance on a smooth surface. For longer distances or uneven terrain, it is recommended to empty the base completely.
2. Tilt the hoop slightly backward, lifting the front of the base off the ground so that the wheels engage.
3. Roll the unit to the desired location.
4. Carefully lower the base back onto the ground, ensuring it is stable before refilling (if emptied).



Image 5.4: The base features integrated wheels for convenient portability.

6. MAINTENANCE

Regular maintenance will extend the life of your Soozier Poolside Basketball Hoop Stand.

- **Cleaning:** Clean the backboard, rim, and pole with a mild soap and water solution. Rinse thoroughly and dry. Avoid abrasive cleaners.
- **Hardware Check:** Periodically check all bolts, nuts, and screws for tightness. Re-tighten as necessary to maintain structural integrity.
- **Rust Prevention:** The steel frame is powder-coated for rust resistance. However, prolonged exposure to moisture, especially chlorinated pool water, can lead to rust. Wipe down metal parts after use, particularly if used near a pool. Consider applying a rust-inhibiting spray to exposed metal components annually.
- **Net Inspection:** Inspect the net for tears or excessive wear. Replace the net if it becomes damaged to ensure continued play.
- **Base Condition:** Check the base for cracks or leaks. Repair or replace if damage is found.
- **Winter Storage:** If storing outdoors in freezing temperatures, empty the base of water to prevent damage from ice expansion. Store the unit in a dry, sheltered area if possible.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Hoop is unstable or tips easily.	Base not sufficiently filled; uneven ground; loose connections.	Ensure base is filled to maximum capacity (99 lbs sand / 77 lbs water). Place on level ground. Check and tighten all assembly bolts.
Difficulty adjusting height.	Adjustment knob too tight; pole sections stuck.	Loosen the adjustment knob completely. Apply a silicone-based lubricant to the sliding pole sections if they are stiff.
Rust appearing on metal parts.	Prolonged exposure to moisture, especially chlorinated water.	Wipe down metal components after each use. Apply rust-inhibiting paint or spray to affected areas. Store in a dry place when not in use.
Net is tearing or worn out quickly.	Normal wear and tear; exposure to harsh weather.	Replace the net with a new, durable, weatherproof basketball net.

8. SPECIFICATIONS

Brand: Soozier

Model Name: Basketball Hoop Stand

Model Number: CAA61-0320231

Material: Polyethylene (PE) backboard, Alloy Steel frame

Color: Multi (typically blue backboard/base, black pole)

Overall Dimensions: 32" W x 52.25" D x 56.75"-68" H (81cm W x 132.7cm D x 144-173cm H)

Backboard Dimensions: 32" W x 22.75" D (81cm W x 58cm D)

Rim Diameter: 15" (38 cm)

Adjustable Rim Height: 36.5"-48.5" (92.5 cm - 123 cm)

Item Weight (empty): 18.7 lbs (8.5 kg)

Base Capacity (Sand): Up to 99 lbs (45 kg)

Base Capacity (Water): Up to 77 lbs (35 kg)

Indoor/Outdoor Usage: Outdoor

Special Features: Adjustable Height, Portable (with wheels), Rust Resistant (powder-coated frame)

Assembly Required: Yes

Suitable for Basketballs: Size 5 (27.5" circumference) and below



Image 8.1: Detailed dimensions of the basketball hoop stand, including backboard, rim, and overall height ranges.

9. WARRANTY AND SUPPORT

The Soozier Poolside Basketball Hoop Stand comes with a **1-Year Manufacturer's Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover:

- Damage caused by improper assembly or installation.
- Damage resulting from misuse, abuse, neglect, or accidents.
- Normal wear and tear, including nets and cosmetic damage.
- Damage due to extreme weather conditions or natural disasters.
- Unauthorized modifications or repairs.

For warranty claims, missing parts, or technical support, please contact Soozier customer service through the retailer where the product was purchased or visit the official Soozier website for contact information. Please have your model number (CAA61-0320231) and proof of purchase ready.

For more information about Soozier products, visit the [Soozier Store on Amazon](#).