

tectake 800959

tectake Ostuni Rattan Garden Lounge Set - Model 800959 Instruction Manual

1. PRODUCT OVERVIEW

Thank you for choosing the tectake Ostuni Rattan Garden Lounge Set. This set is designed to provide a comfortable and stylish outdoor seating solution, featuring durable materials and practical design elements. Please read this manual carefully before assembly and use to ensure safe and correct operation.



Image 1.1: The tectake Ostuni Rattan Garden Lounge Set, showcasing the two sofas, coffee table, and integrated storage box in an outdoor setting.

Key Features:

- Comfortable seating with thick seat and back cushions.
- Integrated storage box for convenient cushion storage.
- Elegant coffee table with a black safety glass top.
- Durable powder-coated steel frame and weather-resistant polyrattan weave.
- Modular design for flexible arrangement.
- UV-resistant and water-repellent materials for outdoor longevity.

2. SAFETY INSTRUCTIONS

Please observe the following safety guidelines to prevent injury or damage to the product.

- **Weight Limits:** Do not exceed the maximum weight capacities for each component (Sofa: 250 kg, Storage Box: 45 kg, Table: 30 kg).

- **Stable Placement:** Always place the furniture on a flat, stable, and level surface to prevent tipping. Use the adjustable feet to ensure stability.
- **Fire Hazard:** Keep the furniture away from open flames, heaters, and other heat sources.
- **Children:** Supervise children when they are near or on the furniture. Do not allow children to climb on the table or storage box.
- **Glass Top:** Handle the glass table top with care. Avoid placing excessively hot or heavy objects directly on the glass.
- **Assembly:** Ensure all screws and fasteners are securely tightened during assembly and periodically check for tightness.
- **Weather Protection:** While weather-resistant, it is recommended to cover or store the furniture during extreme weather conditions (heavy rain, strong winds, frost) to prolong its lifespan.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged.

- 2-seater Sofa (x2)
- Coffee Table (x1)
- Storage Box (x1)
- Safety Glass Top for Coffee Table (x1)
- Safety Glass Top for Storage Box (x1)
- Seat Cushions (for sofas)
- Back Cushions (for sofas)
- Assembly Hardware (screws, bolts, tools)
- Instruction Manual (this document)



ONVERGETELIJKE Relaxmomenten

Image 3.1: An overview of the product components and their approximate dimensions.

4. SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended to have two people for easier and safer assembly.

1. **Unpack:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list and diagrams (if provided separately) to identify each component.
3. **Assemble Frames:** Begin by assembling the steel frames for the sofas, coffee table, and storage box. Ensure all connections are aligned correctly before tightening screws.
4. **Attach Rattan Panels:** Secure the polyrattan panels to the assembled frames using the provided hardware.
5. **Install Glass Tops:** Carefully place the safety glass tops onto the coffee table and storage box. Ensure they are seated securely.
6. **Place Cushions:** Position the seat and back cushions on the sofas.
7. **Adjust Stability:** Use the adjustable feet located on the bottom of each furniture piece to level the set and ensure maximum stability on uneven surfaces. Turn the feet clockwise to raise and counter-clockwise to lower.




Image 4.1: The coffee table with its black safety glass top, a key component requiring careful placement during assembly.

WIND- &

Weerbestendig



Waterafstotend



100% roestvrijstalen
schroeven



Gepoedercoate
stalen frameconstructie

Image 4.2: Detail of the adjustable feet, crucial for leveling the furniture on various outdoor surfaces.

5. OPERATING INSTRUCTIONS

The tectake Ostuni Rattan Garden Lounge Set is designed for comfortable outdoor relaxation.

- **Seating:** Use the sofas for comfortable seating. Ensure cushions are properly placed for optimal comfort.

- **Coffee Table:** The coffee table provides a convenient surface for drinks, snacks, or decorative items. Avoid placing heavy or sharp objects directly on the glass.
- **Storage Box:** The integrated storage box is ideal for storing cushions when not in use or during inclement weather. To open, lift the lid. To close, gently lower the lid until it is fully seated.



De **opbergbox** creëert opbergruimte & is eenvoudig te openen met het automatische hefmechanisme.



De **superdikke zit- en rugkussens** zorgen voor maximaal comfort & nodigen uit tot lang ontspannen.



De **twee veiligheidsglasplaten** met een luxe uitstraling scoren punten door hun hoge slag- en stootvastheid.



De **onderhoudsvriendelijke hoezen** zijn waterafstotend, gemakkelijk verwijderbaar en wasbaar.

Image 5.1: The storage box shown open, demonstrating its capacity for storing cushions or other outdoor items.

6. MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your garden lounge set.

- **Polyrattan Frame:** Clean the polyrattan weave with a soft cloth, mild soap, and water. Rinse thoroughly and allow to air dry. Avoid harsh chemicals or abrasive cleaners.
- **Glass Top:** Clean the glass table top with a standard glass cleaner and a soft cloth.
- **Cushions:** The cushion covers are water-repellent and can be wiped clean with a damp cloth. For deeper cleaning, remove covers (if removable) and hand wash with mild soap, then air dry. Do not machine wash or tumble dry. Store cushions in the integrated storage box or indoors when not in use or during heavy rain to protect them.

- **Steel Frame:** The powder-coated steel frame is rust-resistant. If any scratches occur, touch up with appropriate rust-preventative paint to prevent corrosion.
- **Seasonal Storage:** During winter months or prolonged periods of non-use, it is recommended to store the furniture indoors or cover it with a protective outdoor furniture cover.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary.

tectake
garden

Productinformatie

AFMETINGEN

Afmetingen per bank
128,5 x 66 x 63,5 cm

Opbergbox
66 x 66 x 63 cm

Tafel
85 x 56 x 34,5 cm

Glasplaat
85 x 56 x 0,5 cm

Zithoogte met kussens
40,5 cm

Hoogte rugleuning
32 cm

TECHNISCHE DETAILS

Draagkracht per bank
250 kg
Gewicht (met kussens)
ca. 18 kg
Draagkracht opbergbox 45 kg
Gewicht opbergbox
ca. 11 kg
Draagkracht tafel 30 kg
Gewicht tafel ca. 10,5 kg
Materiaal gepoedercoat staal, polyethyleen, schuim, 100% polyester, glas

INHOUD

2 banken met zit- & rugkussens
Tafel met glasplaat
Opbergbox met glasplaat
Montagemateriaal
Montagehandleiding



Afmetingen zijn bij benadering

Image 6.1: Detail showing the water-repellent properties of the cushion fabric, making them easy to maintain.

7. TROUBLESHOOTING

If you encounter any issues with your lounge set, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Furniture is wobbly or unstable.	Uneven surface; loose assembly screws; adjustable feet not properly set.	Ensure furniture is on a level surface. Check and tighten all assembly screws. Adjust the leveling feet on each leg until stable.

Problem	Possible Cause	Solution
Cushions feel damp after light rain.	Cushions were exposed to rain for too long; water repellency may be reduced over time.	Wipe cushions dry immediately. Store cushions in the integrated storage box or indoors during rain. Consider reapplying a fabric water-repellent spray if needed.
Difficulty assembling parts.	Incorrect alignment; missing hardware; parts mixed up.	Review the assembly instructions and diagrams carefully. Ensure parts are oriented correctly. Verify all hardware is present. Do not force parts together.
Rattan weave appears damaged.	Impact damage; prolonged exposure to extreme conditions.	For minor damage, small repairs might be possible with appropriate materials. For significant damage, contact customer support.

8. SPECIFICATIONS

Detailed specifications for the tectake Ostuni Rattan Garden Lounge Set, Model 800959.

Model Number: 800959

Brand: tectake

Color: Nature

Materials: Powder-coated steel (frame), Polyethylene (rattan), Foam (cushions), Polyester (cushion covers), Safety Glass (table tops)

Sofa Dimensions (L x W x H): approx. 128.5 x 66 x 63.5 cm

Sofa Seat Height (with cushion): approx. 40.5 cm

Sofa Backrest Height: approx. 32 cm

Sofa Weight Capacity: 250 kg

Storage Box Dimensions (L x W x H): approx. 66 x 66 x 63 cm

Storage Box Internal Dimensions (L x W x H): approx. 64 x 64 x 46.5 cm

Storage Box Weight Capacity: 45 kg

Coffee Table Dimensions (L x W x H): approx. 85 x 56 x 34.5 cm

Coffee Table Glass Top Dimensions (L x W x Thickness): 580 x 560 x 5 mm

Coffee Table Weight Capacity: 30 kg

Total Item Weight: 66 Kilograms

Assembly Required: Yes

Special Features: Comfortable, Easy to clean, UV resistant, Water-repellent cushions, Adjustable feet for leveling.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact your retailer or the manufacturer directly.

Manufacturer: tectake

Seller: tectake nederland (as per purchase information)

Please retain your proof of purchase for any warranty claims.

