

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [tectake](#) /

› [tectake Bar Table with 4 Stools - Industrial Style - Model 404306](#)

### tectake 404306

# tectake Bar Table with 4 Stools - Industrial Style

Model: 404306

## INTRODUCTION

---

Thank you for choosing the tectake Industrial Style Bar Table with 4 Stools. This manual provides important information for the safe assembly, operation, and maintenance of your new furniture set. Please read these instructions carefully before assembly and keep them for future reference.

## SAFETY INSTRUCTIONS

---

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or damaged.
- Assemble the product on a soft, clean surface to prevent scratches.
- Tighten all screws and bolts securely, but do not overtighten to avoid damaging the material.
- Regularly check all connections to ensure they remain tight.
- Do not exceed the maximum load capacity for the table (75 kg) and stools (150 kg per stool).
- Keep small parts and packaging materials away from children to prevent choking hazards.
- This product is designed for indoor use. Avoid prolonged exposure to moisture or direct sunlight.

## PACKAGE CONTENTS

---

Before starting assembly, please verify that all the following components are included in your package:

- 1 x Bar Table
- 4 x Bar Stools
- 1 x Set of Assembly Hardware (screws, bolts, Allen key, etc.)
- 1 x Assembly Manual (this document)

## MEDIDAS

**Medidas totales de la mesa**

100 x 60 x 88,5 cm

**Medidas totales del taburete**

32 x 32 x 58 cm

**Grosor del tablero aglomerado**

1,5 cm

**Ajustabilidad de las patas de plástico**

1,5 cm

## DATOS TÉCNICOS

**Capacidad de carga**

Mesa 75 kg

Taburete 150 kg

**Peso de la mesa** aprox. 11,5 kg**Peso del taburete** aprox. 3,5 kg**Material** MDF revestido de melamina, acero con revestimiento en polvo, polietileno

## CONTENIDO

Mesa de bar

4 taburetes de bar

Material de montaje

Instrucciones de montaje



Las medidas son aproximadas

*Image: Detailed diagram of product dimensions and included components.*

## ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your tectake bar table and stools. It is recommended to have two people for assembly.

- Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to avoid scratches. Identify each component using the parts list in the assembly hardware set.
- Assemble Table Frame:** Attach the table legs to the long and short crossbars using the provided screws and Allen key. Ensure all connections are finger-tight before fully tightening.
- Attach Tabletop:** Place the tabletop upside down on a soft surface. Align the assembled table frame with the pre-drilled holes on the underside of the tabletop. Secure the tabletop to the frame using the appropriate screws.
- Assemble Stool Frames:** For each stool, attach the four legs to the seat frame using the provided screws. Ensure the footrests are correctly oriented.

5. **Attach Stool Seats:** Place each stool seat upside down. Align the assembled stool frame with the pre-drilled holes on the underside of the seat. Secure the seat to the frame.
6. **Install Adjustable Feet:** Screw the adjustable plastic feet into the bottom of each table leg and stool leg. These feet protect your floor and allow for minor height adjustments to ensure stability.
7. **Final Tightening:** Once all components are assembled, carefully place the table and stools upright. Systematically tighten all screws and bolts using the Allen key. Do not overtighten.



Image: Stable feet with screw-in adjusters and resistant MDF tabletops.



Este **conjunto de estilo industrial** se integra perfectamente en cualquier decoración.

Los **piés de plástico antideslizantes** son regulables en altura y garantizan una estabilidad total.



Para ahorrar espacio, los **taburetes** se pueden guardar completamente debajo de la mesa.

Las **sólidas estructuras de acero** con reposapiés garantizan gran estabilidad y comodidad.

*Image: Features including adjustable feet and space-saving stool storage.*

## OPERATING INSTRUCTIONS

The tectake bar table and stools are designed for daily use in your home. Here are some guidelines for optimal use:

- **Stability:** Use the adjustable plastic feet on both the table and stools to compensate for uneven floors. Turn the feet clockwise or counter-clockwise until the furniture is stable and does not wobble.
- **Space Saving:** The stools are designed to fit neatly under the table when not in use, maximizing your floor space.
- **Load Capacity:** Do not place items heavier than 75 kg on the table. Each stool can support a maximum weight of 150 kg.
- **Placement:** Position the furniture on a flat, stable surface. Avoid placing it near heat sources or in direct sunlight for extended periods to prevent material damage.



*Image: tectake bar table and stools in use.*

## MAINTENANCE

---

Proper care will extend the life and appearance of your tectake furniture set:

- **Cleaning:** Wipe surfaces with a dry cloth. For more stubborn marks, use a slightly damp cloth and mild detergent, then dry immediately with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Regular Checks:** Periodically inspect all screws and bolts to ensure they are tight. Retighten if necessary.
- **Protection:** Use coasters or placemats to protect the tabletop from spills, heat, and scratches.
- **Environment:** Keep the furniture in a dry environment. Avoid extreme temperature changes and high humidity.

## TROUBLESHOOTING

---

If you encounter any issues with your tectake bar table and stools, please refer to the following common solutions:

- **Wobbling Table/Stool:**

- Check if all screws and bolts are securely tightened.
- Adjust the plastic feet on the bottom of the legs to level the furniture on uneven surfaces.

- **Difficulty during Assembly:**

- Ensure you are using the correct hardware for each step as indicated in the assembly instructions.
- Do not overtighten screws until all parts are loosely fitted, then tighten them gradually.
- Refer to the assembly diagrams for correct orientation of parts.

- **Scratches or Dents:**

- Minor scratches on the MDF surface can sometimes be minimized with furniture polish or a touch-up pen matching the wood finish.
- Prevent future damage by using protective pads under items placed on the table.

## SPECIFICATIONS

---

### Product Specifications

Feature	Detail
Brand	tectake
Model Number	404306
Table Dimensions (L x W x H)	Approx. 100 x 60 x 88.5 cm
Stool Dimensions (L x W x H)	Approx. 32 x 32 x 58 cm
Total Product Weight	Approx. 28 kg
Table Load Capacity	75 kg
Stool Load Capacity	150 kg (per stool)
Material	MDF board, powder-coated steel, polyethylene
Color	Dark Industrial Wood
Special Features	Adjustable height feet, space-saving stool storage
Care Instructions	Clean with a dry cloth

## WARRANTY AND SUPPORT

---

tectake products are manufactured to high-quality standards. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For technical support, missing parts, or any questions regarding your product, please contact tectake customer service through their official website or the retailer where you purchased the product. Please have your model number (404306) and purchase date ready when contacting support.

You can visit the tectake store for more information: [tectake Official Store](#)

