

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Arteck](#) /
- › [Arteck Backlit USB Wired Full Size Keyboard User Manual](#)

Arteck HA305-3B

Arteck Backlit USB Wired Full Size Keyboard User Manual

Model: HA305-3B

1. INTRODUCTION

The Arteck Backlit USB Wired Full Size Keyboard is designed for use with PCs and laptops, offering a comfortable and efficient typing experience. It features a full-size layout, including a numeric keypad and media hotkeys, along with customizable backlighting to enhance visibility and aesthetics.



Figure 1: Arteck Backlit USB Wired Full Size Keyboard showcasing its red backlighting.

2. KEY FEATURES

- **7 Unique Backlight Colors:** Choose from 7 elegant LED backlight colors to personalize your typing environment.
- **3 Brightness Levels:** Adjust the backlight intensity to suit your preference and ambient lighting conditions.
- **Easy Setup (Plug & Play):** Connect the 1.8-meter (6 feet) USB cable to your computer, and the keyboard is ready for immediate use without driver installation.
- **Ergonomic Design:** Features a Scissors X structure for comfortable typing and low-profile keys for quiet operation.
- **Ultra-Thin and Lightweight:** Compact dimensions (16.7 x 4.5 x 0.24 inches) and light weight (17.4 oz) provide portability while retaining full-size keys, arrow keys, and a numeric pad.
- **Media Hotkeys:** Quick access to common functions such as volume control, playback, and brightness.

1.8 M / 6 Feet Cable Plug & Play



Figure 2: The keyboard's 1.8-meter USB cable, highlighting its simple plug-and-play setup.

3. SETUP

1. **Unpack the Keyboard:** Carefully remove the Artek keyboard from its packaging.

2. **Connect to Computer:** Locate an available USB port on your PC or laptop. Insert the USB connector of the keyboard's cable firmly into the USB port.
3. **Automatic Recognition:** The keyboard is plug-and-play and should be automatically recognized by your operating system (Windows, macOS, Linux). No additional drivers are typically required.
4. **Ready for Use:** Once recognized, the keyboard is ready for immediate use.



Figure 3: The Artek keyboard seamlessly integrated into a desktop computer setup.

4. OPERATING INSTRUCTIONS

4.1 Backlight Control

The Artek keyboard features adjustable backlighting with multiple colors and brightness levels.

- **Turn On/Off Backlight & Adjust Brightness:** Press the **Light Bulb** key (located near the right Alt key) to cycle through 3 brightness levels (Low, Medium, High) and to turn the backlight off.
- **Change Backlight Color:** Press the **RGB** key (located next to the Light Bulb key) to cycle through the 7 available backlight colors: Red, Green, Blue, Yellow, Cyan, Purple, and White.



Figure 4: Dedicated keys for controlling backlight brightness and color selection.

4.2 Media Hotkeys

The keyboard includes dedicated media hotkeys for convenient control of multimedia functions. These are typically accessed by pressing the **Fn** key in combination with the F1-F12 function keys.

Key Combination	Function
Fn + F1	Media Player
Fn + F2	Volume Down
Fn + F3	Volume Up
Fn + F4	Mute
Fn + F5	Previous Track
Fn + F6	Next Track
Fn + F7	Play/Pause
Fn + F8	Stop
Fn + F9	Home Page
Fn + F10	Email
Fn + F11	My Computer

Key Combination	Function
Fn + F12	Calculator

5. MAINTENANCE

To ensure the longevity and optimal performance of your Arteck keyboard, follow these simple maintenance guidelines:

- **Regular Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keys and surface. Avoid excessive moisture.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- **Avoid Spills:** Keep liquids away from the keyboard to prevent damage to internal components.
- **Proper Storage:** When not in use, store the keyboard in a clean, dry environment away from extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your Arteck keyboard, try the following troubleshooting steps:

- **Keyboard Not Responding:**
 - Ensure the USB cable is securely plugged into a working USB port on your computer.
 - Try plugging the keyboard into a different USB port.
 - Restart your computer.
- **Backlight Not Working/Incorrect Color:**
 - Press the **Light Bulb** key to ensure the backlight is turned on and to cycle through brightness levels.
 - Press the **RGB** key to cycle through the available colors.
- **Keys Not Registering:**
 - Check for any debris or obstructions under the affected keys.
 - Gently clean the keyboard as described in the Maintenance section.
- **Numeric Keypad Issues:**
 - Ensure the **Num Lock** indicator light is on. Press the Num Lock key to toggle it if necessary.

7. SPECIFICATIONS

Specification	Detail
---------------	--------

Specification	Detail
Product Dimensions	16.7 x 4.5 x 0.24 inches (42.5 x 11.6 x 0.6 cm)
Item Weight	1.43 pounds (17.4 oz / 500 g)
Manufacturer	Arteck
Connectivity Technology	USB Wired
Cable Length	1.8 meters (6 feet)
Keyboard Description	Backlit, Multimedia, Full Size
Special Features	Ergonomic, Backlit, Hotkeys and Media Keys
Color	Black
Number of Keys	104
Keyboard Backlighting Color Support	RGB (7 unique colors)
Key Structure	Scissors X structure
Compatible Devices	Laptop, PC, Desktop



Figure 5: Physical dimensions and weight of the Arteck keyboard.



COMFORTABLE KEYSTROKES

X structure, exert equal pressure and lower keystrokes in comparison with the clickety keyboard.

Figure 6: Illustration of the comfortable Scissors X key structure.

8. WARRANTY & SUPPORT

Arteck provides comprehensive support for its products:

- **Warranty:** The Arteck Backlit USB Wired Keyboard comes with a 24-month warranty.
- **Customer Service:** For any issues or inquiries, please contact Arteck customer service. Contact information is typically provided in the welcome guide included with your product or on the back of the keyboard.
- **Troubleshooting Tip:** If you experience problems, try unplugging and re-plugging the USB cable into a different USB port. If the issue persists, contact support.

