

Hunter 99814

Hunter Universal Receiver 3 Speed (Model 99814) User Manual

Your guide to installation, operation, and maintenance.

1. INTRODUCTION

The Hunter Universal Receiver 3 Speed (Model 99814) is designed to add remote control functionality to your ceiling fan. This receiver is compatible with most major brands of pull chain ceiling fans and works seamlessly with Hunter's Handheld Control (99813) or Wall Control (99815), sold separately. It enables convenient adjustment of fan speed (low, medium, high) and light dimming (requires dimmable bulbs).

This receiver can be installed and used in both indoor and covered outdoor ceiling fan applications. It offers a control range of up to 75 feet, providing flexibility in operation.






Image: The Hunter Universal Receiver 3 Speed, a compact green electronic device with wires for connection.

2. WHAT'S IN THE BOX

Upon opening the package, verify that all components are present:

- 1 x Hunter Universal Receiver (Model 99814)
- 5 x Wire Caps



WHAT'S IN THE BOX

(1) Receiver (5) Wire caps

Image: The contents of the product box, showing one green receiver unit and five orange wire caps.

3. SETUP AND INSTALLATION

Installation of the Hunter Universal Receiver involves electrical wiring and should only be performed by a qualified electrician or an individual with a thorough understanding of electrical systems. Always ensure power is disconnected at the circuit breaker before beginning any installation work.

3.1. Pre-Installation Checks

- Ensure the ceiling fan is compatible with a universal receiver.
- Confirm that the receiver's dimensions (approximately 5.87 x 3.86 x 2.32 inches) will fit within the fan's canopy.
- Have the necessary tools ready (e.g., screwdriver, wire strippers, electrical tape).




Image: A side view of the Hunter Universal Receiver with measurements indicating its height (4.5 inches) and width (2.1 inches).

3.2. Wiring Instructions

Detailed wiring diagrams and step-by-step instructions are typically provided in the comprehensive user manual available for download from the manufacturer's website or included with the product. It is crucial to follow these specific instructions for safe and correct installation.

In general, the receiver will connect between the household wiring and the ceiling fan motor and light kit. The included wire caps are used to secure electrical connections. Ensure all connections are tight and properly insulated.

3.3. Pairing with Remote Control

After installation, the receiver must be paired with a compatible Hunter Universal Wall Control (99815) or Handheld Control (99813). Refer to the instructions provided with your specific remote control for the pairing procedure. This typically involves a sequence of power cycling and button presses to establish communication between the remote and the receiver.



Image: The Hunter Universal Receiver superimposed on a bedroom scene with a ceiling fan, illustrating its universal compatibility with existing or new ceiling fan installations.

4. OPERATING THE RECEIVER

Once installed and paired, the receiver allows you to control your ceiling fan and light using the paired remote control. The functions typically include:

- **Fan Speed Control:** Adjust the fan speed to low, medium, or high settings.
- **Light Control:** Turn the light on/off. If dimmable bulbs are installed, the remote will also allow dimming functionality.

The receiver is designed to operate reliably within a range of up to 75 feet from the paired remote control.

5. MAINTENANCE

The Hunter Universal Receiver is designed for long-term, maintenance-free operation. No user-serviceable parts are inside. To ensure optimal performance and longevity:

- Keep the receiver dry and away from excessive moisture.
- Do not expose the receiver to extreme temperatures.
- Avoid physical damage or impact to the unit.
- Ensure proper ventilation around the receiver if installed in a confined space.

For cleaning, gently wipe the exterior with a dry, soft cloth. Do not use liquid cleaners or solvents.

6. TROUBLESHOOTING

If you encounter issues with your Hunter Universal Receiver, consider the following common troubleshooting steps:

- **No Response from Remote:**
 - Ensure the remote control has fresh batteries.
 - Verify that the receiver is properly powered (check circuit breaker).
 - Attempt to re-pair the remote control with the receiver according to your remote's instructions.
 - Check all electrical connections to the receiver for tightness and proper insulation.
- **Intermittent Operation:**
 - Ensure the remote control is within the 75-foot operating range.
 - Check for potential interference from other electronic devices.
 - Verify stable power supply to the fan and receiver.
- **Fan or Light Not Functioning:**
 - Confirm that the fan and light themselves are in working order (e.g., test with pull chains if applicable, check light bulbs).
 - Re-check all wiring connections to ensure they match the installation diagram.

For more detailed troubleshooting or complex issues, please refer to the official Hunter user manual (PDF) or contact Hunter customer support.

7. SPECIFICATIONS

| | |
|------------------------|--------------------------------|
| Brand | Hunter |
| Model Name | 1.9 Receiver 3 Speed |
| Part Number | 99814 |
| Item Weight | 3.84 ounces (0.24 Pounds) |
| Product Dimensions | 5.87 x 3.86 x 2.32 inches |
| Power Source | Corded Electric |
| Control Method | Touch (via compatible remote) |
| Number of Power Levels | 3 (for fan speed) |
| Indoor/Outdoor Usage | Indoor, Outdoor Covered (Damp) |
| Included Components | Receiver |

| | |
|-----|--------------|
| UPC | 049694998149 |
|-----|--------------|

8. WARRANTY AND SUPPORT

8.1. Warranty Information

The Hunter Universal Receiver 3 Speed (Model 99814) comes with a **1-year limited warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2. Customer Support





For technical assistance, warranty claims, or further inquiries, please contact Hunter Fan Company customer support. Refer to the official Hunter website or the documentation included with your product for the most current contact information.


You can also visit the [Hunter Store on Amazon](#) for additional product information and resources.

© 2024 Hunter Fan Company. All rights reserved.

This manual is for informational purposes only. Hunter Fan Company is not responsible for any damages or injuries resulting from improper installation or use of this product.

Related Documents - 99814

| | |
|---|---|
|  | <p>Hunter 99814 Universal Ceiling Fan Receiver Installation Guide</p> <p>Comprehensive installation guide for the Hunter 99814 Universal Ceiling Fan Receiver, detailing wiring, safety precautions, warranty information, and troubleshooting steps.</p> |
|  | <p>Hunter Universal 3 Speed Ceiling Fan Remote Model 99119 Installation and Operation Guide</p> <p>Detailed installation, wiring, pairing, operation, maintenance, and troubleshooting guide for the Hunter Universal 3 Speed Ceiling Fan Remote, Model 99119. Includes warranty and safety information.</p> |
|  | <p>Hunter Universal 3 Speed Ceiling Fan Remote Model 99122, 99123 Installation and Operation Guide</p> <p>Comprehensive guide for installing and operating the Hunter Universal 3 Speed Ceiling Fan Remote, models 99122 and 99123. Includes wiring instructions, pairing, operation, maintenance, troubleshooting, and warranty information.</p> |
|  | <p>Hunter Universal Mounting System Installation Guide (Model 99818)</p> <p>This guide provides detailed instructions for installing the Hunter Universal Mounting System (Model 99818), including safety precautions, parts and tools lists, step-by-step assembly, remote pairing, and warranty information.</p> |



[Hunter SIMPLEconnect Add-on Receiver 99106 Installation Guide](#)

Step-by-step installation guide for the Hunter SIMPLEconnect add-on receiver (model 99106) for ceiling fans. Learn how to safely connect the receiver for remote control functionality.



[Hunter Universal Fan and Light Remote Control Installation and Operation Manual](#)

Comprehensive guide for installing and operating the Hunter Universal Fan and Light Remote Control (Model 41797-02). Includes setup, troubleshooting, and warranty information.