

[Manuals.plus](#) /

› [Kingsman](#) /

› KINGSMAN 3000W Gasoline Electric Generator User Manual

Kingsman KING3000

KINGSMAN 3000W Gasoline Electric Generator User Manual

Brand: Kingsman | Model: KING3000

INTRODUCTION

This user manual provides essential information for the safe and efficient operation, setup, maintenance, and troubleshooting of your KINGSMAN 3000W Gasoline Electric Generator. Please read this manual thoroughly before operating the generator to ensure proper use and to prevent injury or damage.

The KINGSMAN portable generator is designed to provide reliable power wherever you need it. Its 4-stroke gasoline engine offers exceptional efficiency and proven durability, capable of continuous operation for up to 10 hours. With its AC outlets, you can power a variety of tools, electronic devices, and small appliances, ensuring you have power available for extended periods.



Figure 1: KINGSMAN 3000W Gasoline Electric Generator.

PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the main components of your generator for safe and effective operation.



**La gasolina y el aceite tienen sus
propios depósitos independientes**
(NO MEZCLAR)



Figure 2: Generator Main Components. Note that the gasoline and oil have independent tanks and should not be mixed.

- **Gasoline Tank:** Holds the fuel for the engine.
- **Oil Tank:** Contains the engine oil. Ensure oil and gasoline are kept separate.
- **Choke:** Used for starting a cold engine.
- **Fuel Valve:** Controls the flow of fuel to the engine.
- **Pull Start:** Manual recoil starter for the engine.

Problema - solución

No arranca o no produce electricidad

1. Verifica el combustible y el interruptor encendido.
2. Revisa la bujía y estrangulador.

El motor se detiene repentinamente

1. Verifica el nivel de combustible.
2. Limpia y despeja el filtro de aire.
3. Inspecciona si hay fugas.

Ruidos extraños

1. Comprueba si hay objetos extraños atrapados.
2. Aprieta los tornillos y las tuercas lo necesario.

Produce electricidad intermitente

1. Revisa que el cableado esté correctamente conectado y no haya cortocircuitos.
2. Comprueba el interruptor de circuito.
3. Verifica si hay sobrecarga en el generador.

Emite humo excesivo

1. Apaga el generador y deja que se enfríe.
2. Verifica si el aceite y el combustible están contaminados y reemplázalos si es necesario.
3. Limpia o reemplaza el filtro de aire.



*Las indicaciones generales pueden variar según sea el modelo y sus componentes.

Figure 3: Control Panel. Understand the functions of each control and outlet.

- **On/Off Button (ENG. SW):** Powers the generator on or off.
- **Voltmeter:** Displays the output voltage.
- **Circuit Breakers:** Protects the generator from overload.
- **AC 220V Outlet (12.7 A):** One outlet for 220V AC power.
- **AC 110V Outlets (25.4 A):** Two outlets for 110V AC power.
- **12V DC Output (5.3A):** For charging batteries.
- **Ground Connection:** For safety grounding.

SPECIFICATIONS

Detailed technical specifications for the KINGSMAN 3000W Gasoline Electric Generator.



Panel de control



Figure 4: Technical Specifications. Key performance and physical characteristics.

Characteristic	Value
AC 110V Output	2200 W (25.4 A)
AC 220V Output	2800 W (12.7 A)
Rated Power	2800 W
Maximum Power	3000 W
Starting Power	3900 W
Noise Level	69 dB
Frequency	60 Hz/50 Hz
Continuous Operation Time	10 Hours

Characteristic	Value
Fuel Consumption per Hour	1.5 Liters
Gasoline Tank Capacity	15 Liters
Oil Capacity	0.6 Liters
Recommended Oil Type	10W30 or 15W40
Recommended Gasoline Type	92 # or 10% ethanol
Weight	44 Kilograms
Dimensions (L x W x H)	59 x 46 x 47 cm
Material	Copper

The KINGSMAN generator features a copper winding, which offers superior performance compared to aluminum generators. This includes higher electrical conductivity, enhanced durability and resistance, better energy efficiency with less power loss, and improved heat dissipation, reducing the risk of overheating. Maintenance is also less frequent with copper windings.

Rendimiento superior, eficiencia y durabilidad.



Nuestro generador
de cobre **KING3000**



Otros generadores
de aluminio

Característica	Cobre	Aluminio
Conductividad eléctrica	✓ Alta conductividad, + Eficiencia	✗ Menor conductividad, - Eficiencia
Durabilidad	✓ Alta durabilidad y resistencia	✗ Menor durabilidad, mayor susceptible a la corrosión
Eficiencia energética	✓ + Eficiencia, menos pérdida de energía	✗ - Eficiencia, más pérdida de energía
Capacidad térmica	✓ Mejor disipación de calor, menor riesgo de sobrecalentar	✗ Menor capacidad térmica, mayor riesgo de sobrecalentar
Mantenimiento	✓ Poco	✗ Frecuente

Figure 5: Copper vs. Aluminum Generator Comparison.

SETUP

Before starting your generator, ensure it is properly set up and prepared for operation.

- Unpacking and Inspection:** Carefully remove the generator from its packaging. Inspect for any visible damage during shipping. Ensure all included components are present: 1 spark plug wrench, 3 grounded plugs, and 1 instruction manual.
- Placement:** Place the generator on a firm, level surface outdoors in a well-ventilated area, away from windows, doors, and vents. Ensure at least 3 feet (1 meter) of clearance on all sides to allow for proper ventilation and exhaust dispersion. Never operate indoors.
- Add Engine Oil:** Locate the oil fill cap/dipstick. Add the recommended engine oil (10W30 or 15W40) up to the full mark on the dipstick. The oil capacity is 0.6 liters. Do not overfill.
- Add Fuel:** Fill the gasoline tank with fresh, unleaded gasoline (92 # or 10% ethanol recommended). The tank

capacity is 15 liters. Do not overfill and ensure the fuel cap is securely tightened.

5. **Grounding:** Connect a grounding wire from the generator's ground terminal to a suitable earth ground. This is crucial for safety.

2 Salidas	2200 W CA 110V (25.4 A)
1 Salida	2800 W CA 220 V (12.7 A)
Potencia nominal:	2800 W
Potencia máxima:	3000 W
Potencia de arranque:	3900 W
Nivel de ruido:	69 dB
Frecuencia 110V/220V:	60 Hz/50 Hz
Trabajo continuo:	10 H
Consumo de combustible x hora:	1.5 Lts
Capacidad del tanque de gasolina:	15 Lts
Capacidad de aceite:	0.6 Lts
Tipo de aceite recomendado:	10W30 o 15W40
Tipo recomendado de gasolina:	92 # o 10% etanol



Figure 6: Generator Dimensions and Included Accessories. The generator weighs 44 kg and measures 59 cm (length) x 42 cm (width) x 35 cm (height).

OPERATING INSTRUCTIONS

Follow these steps to safely start and operate your KINGSMAN generator.

Guía de inicio rápido

1. Verifica el combustible y el aceite

2. Coloca la llave de paso de gasolina en on

3. Coloca el ahogador en off

4. Coloca el switch en on

5. Utiliza el tirón de arranque

6. Una vez encendido coloca el ahogador en on



Figure 7: Quick Start Guide. Visual steps for starting the generator.

- Step 1: Verify Fuel and Oil.** Ensure the gasoline tank is filled and the engine oil level is correct.
- Step 2: Turn Fuel Valve ON.** Locate the fuel valve and turn it to the "ON" position.
- Step 3: Set Choke to OFF (Closed).** For a cold engine, move the choke lever to the "OFF" (closed) position.
- Step 4: Turn Engine Switch ON.** Press the engine switch to the "ON" position.
- Step 5: Use Pull Start.** Firmly pull the recoil starter handle until the engine starts.
- Step 6: Set Choke to ON (Open).** Once the engine has started and warmed up slightly, gradually move the choke lever to the "ON" (open) position.

Connecting Devices

The generator is ideal for domestic use and can power various appliances. It is suitable for connecting one appliance to the 220V AC outlet or two appliances to the 110V AC outlets (not simultaneously for maximum load).



Ideal para uso doméstico.

Generador apto para conectar un aparato en la conexión de 220 V o 2 aparatos en las conexiones de 110 V (NO SIMULTÁNEAMENTE).

Refrigerador



250-500 W

Laptop



20-50 W

Televisión



115-300 W

Microondas



1100 W

Si tu aparato supera las siguientes características no es compatible con este equipo

Tipo de corriente	Voltios (V)	Amperaje (A)	Potencia (W)
CA	220 V	12.7 A	2800 W
CA	110 V	25.4 A	2200 W

Figure 8: Ideal for Domestic Use. Examples of compatible appliances and their power requirements.

Before connecting any device, ensure its power requirements do not exceed the generator's output capacity. Refer to the table below for maximum current and power for each voltage output:

Current Type	Voltage (V)	Amperage (A)	Power (W)
AC	220 V	12.7 A	2800 W
AC	110 V	25.4 A	2200 W

If your appliance exceeds these characteristics, it is not compatible with this equipment.

MAINTENANCE

Regular maintenance is crucial for the longevity and optimal performance of your generator.

- **Check Oil Level:** Regularly check the engine oil level before each use. Add oil if necessary, ensuring it is within the recommended range.
- **Clean/Replace Air Filter:** Inspect the air filter periodically. Clean it if dirty or replace it if heavily soiled or damaged.

A clogged air filter can reduce engine performance and increase fuel consumption.

- **Spark Plug Inspection:** Check the spark plug for wear or carbon buildup. Clean or replace as needed to ensure proper ignition.
- **Fuel System:** If storing the generator for an extended period, drain the fuel tank and carburetor to prevent fuel degradation and carburetor clogging.
- **General Cleaning:** Keep the generator clean from dirt, dust, and debris. Ensure cooling fins are clear for proper heat dissipation.

TROUBLESHOOTING

This section provides solutions to common issues you might encounter with your generator.



Motor de 4 tiempos con 7.0 HP

Incluye:
1 Llave para bujía
3 Clavijas aterrizadas



59 cm

42 cm



35 cm

Peso: 42 kg



Figure 9: Problem-Solution Guide.

Problem	Solution
---------	----------

Problem	Solution
Does not start or produce electricity	1. Verify fuel and that the switch is ON. 2. Check the spark plug and choke.
Engine stops suddenly	1. Verify fuel level. 2. Clean and clear the air filter. 3. Inspect for leaks.
Strange noises	1. Check if there are foreign objects trapped. 2. Tighten screws and nuts as necessary.
Intermittent electricity production	1. Check that the wiring is correctly connected and there are no short circuits. 2. Check the circuit breaker. 3. Verify if there is an overload on the generator.
Emits excessive smoke	1. Turn off the generator and let it cool down. 2. Verify if the oil and fuel are contaminated and replace if necessary. 3. Clean or replace the air filter.

**General indications may vary depending on the model and its components.*

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product at the time of purchase. Typically, manufacturer warranty details and contact information are provided in a separate warranty card or within the full instruction manual.

For additional assistance or to purchase replacement parts, please contact Kingsman customer service or visit their official website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Kingsman. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question