

ONCE FOR ALL JS01

ONCE FOR ALL JS01 Upgrade Safe Mandoline Slicer Instruction Manual

Model: JS01 | Brand: ONCE FOR ALL

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your ONCE FOR ALL Mandoline Slicer. Improper use can result in injury.

- **Always use the food pusher:** The blades are extremely sharp. Never use your bare hands to push food through the slicer.
- **Keep fingers away from blades:** Exercise extreme caution when handling or cleaning the unit.
- **Stable surface:** Ensure the mandoline slicer is placed on a stable, flat surface before operation. The non-slip silicone base and tripod design provide stability.
- **Keep out of reach of children:** This appliance is not a toy and contains sharp components.
- **Food-grade materials:** The slicer is made of durable ABS plastic and 420 stainless steel blades, ensuring safe food contact.

2. PRODUCT COMPONENTS

Your ONCE FOR ALL Mandoline Slicer comes with the following parts:

- Main Slicer Unit with integrated adjustable blades
- Transparent Food Feeder / Slicing Pusher
- Food Container
- Cleaning Brush



Image: All components of the ONCE FOR ALL Mandoline Slicer, including the main unit, food pusher, and collection container.

3. SETUP

1. **Unfold the Slicer:** Gently pull out the legs of the main slicer unit until they click into place, forming a stable tripod.
2. **Attach Food Container:** Slide the food container underneath the slicer opening to collect sliced food.
3. **Install Food Feeder:** Push the transparent food feeder onto the top opening of the slicer until it snaps securely.



✓ Snap

Push the snap up
to install the food feeder

✓ Leg Snap

Pull leg out until they click place

✓ Sucker

Six strong suction cups at the bottom
to ensure that the vegetable cutter
is stable during use

Product Detail (2)

Image: Close-up of the slicer's snap mechanism for the food feeder, the leg snap for stability, and the suction cups on the base.

Storage

The slicer features a collapsible design for compact storage. Simply fold the legs inward and detach the food feeder and container. It can be stored in a drawer or cabinet, occupying minimal space.

FOLDABLE DESIGN SAVE SPACE




Image: The mandoline slicer folded flat, highlighting its space-saving design for easy storage.

Your browser does not support the video tag.

Video: A demonstration of how to clean and store the ONCE FOR ALL Mandoline Slicer, showing its collapsible design and ease of maintenance.

4. OPERATING INSTRUCTIONS

The ONCE FOR ALL Mandoline Slicer offers 4 mode choices (julienne, matchstick, slicing, and dicing) and adjustable thickness from 0.1mm to 8mm without needing to change blades.

1. **Adjust Thickness:** Rotate the dial on the side of the slicer to select your desired thickness (0.1mm to 8mm).
2. **Select Cutting Mode:** Use the levers/knobs to choose between julienne, matchstick, slicing, or dicing modes.
3. **Prepare Food:** Cut larger vegetables into pieces that fit comfortably into the transparent food feeder. For meat, ensure it is shaped to fit the feeder and is partially frozen for best results.
4. **Slice Food:** Place the food into the feeder. Press down on the handle to push the food against the blade, then release to allow the blade to rebound. Repeat this motion until all food is sliced.

EASILY CUT OUT , NO NEED REPLACE BLADES




Image: Visual guide to adjusting slicing thickness (0.1mm to 8mm) and selecting various cutting styles such as julienne, matchstick, and dicing.



✓ Slices

Thickness from
0.2mm to 8mm



✓ Strips

Potatoes,
sweet potatoes,
squash, etc



✓ Julienne

carrots, cucumbers,
cabbage, etc



✓ Dices

onions, carrots
potatoes, etc

Image: Examples of various cuts achievable with the slicer, including slices, julienne, strips, and dices, suitable for vegetables like carrots, cucumbers, potatoes, and onions.

Demonstration Videos

Your browser does not support the video tag.

Video: A demonstration of the ONCE FOR ALL Mandoline Slicer in action, showing fast and efficient meal preparation for various vegetables.

Your browser does not support the video tag.

Video: A short demonstration highlighting the ease and speed of slicing lemons with the safe mandoline slicer.

Your browser does not support the video tag.

Video: A preview video showcasing the QYKIC Safe Mandoline Slicer's capabilities in slicing various foods.

5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and performance of your mandoline slicer.

- **Immediate Cleaning:** It is best to clean the food cutter immediately after use to prevent food residues from drying and sticking.
- **Detachable Components:** All components are detachable for easy cleaning.
- **Rinsing:** You can easily remove food residues under running tap water.
- **Cleaning Brush:** Use the provided small brush to dislodge any stubborn food particles from the blades and crevices.
- **Dishwasher Safe:** The entire unit is dishwasher safe for convenient cleaning.



Image: Visual guide demonstrating how to clean the slicer with a brush under running water and its compact storage in a kitchen drawer.

6. TROUBLESHOOTING

If you encounter any issues with your mandoline slicer, please refer to the following common solutions:

- **Food not slicing evenly:** Ensure the food is properly centered in the feeder and the thickness setting is appropriate for the food's texture.
- **Difficulty pushing food:** Make sure the food is not too large for the feeder. For harder vegetables, apply steady, firm pressure. Partially freezing meat can also help.
- **Slicer instability:** Confirm that the legs are fully extended and locked into place, and the unit is on a dry, flat surface to allow the suction cups to adhere.
- **Food stuck in blades:** Use the provided cleaning brush or a non-metallic utensil to carefully remove any lodged food. Never use your fingers.

7. SPECIFICATIONS

Brand	ONCE FOR ALL
-------	--------------

Product Dimensions	13"L x 5"W x 6"H
Material	Acrylonitrile Butadiene Styrene (ABS)
Blade Material	Stainless Steel
Operation Mode	Manual
Item Weight	1.94 pounds
Item Model Number	JS01
Special Feature	Adjustable Thickness (0.1-8mm)
Product Care Instructions	Dishwasher Safe

8. WARRANTY AND SUPPORT

Warranty: ONCE FOR ALL provides a 24-month warranty for each vegetable slicer.

Customer Support: If you have any questions, concerns, or require assistance with your product, please feel free to contact ONCE FOR ALL customer service. Refer to your purchase documentation for specific contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question