Novogratz Regal 7347905COM

Novogratz Regal Double Wide Record Station/Accent Cabinet User Manual

Model: Regal 7347905COM

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Novogratz Regal Double Wide Record Station/Accent Cabinet. Please read these instructions carefully before assembly and use to ensure proper function and longevity of your product.

Safety Information

WARNING: This product can expose you to formaldehyde, a chemical known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, please visit www.P65Warnings.ca.gov.

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacities: Top surface up to 40 lbs (18.1 kg), each open cubby up to 15 lbs (6.8 kg).
- This product is designed for indoor use only.
- Keep small parts away from children during assembly.

Product Overview and Dimensions

The Novogratz Regal Double Wide Record Station/Accent Cabinet features an engineered wood top and a metal base, offering versatile storage with six open cubbies. The top two cubbies have an open back for cable management.



Image: Novogratz Regal Double Wide Record Station/Accent Cabinet in Walnut finish, showcasing its design and functionality in a living space.

Dimensions and Weight Capacity:



Image: Detailed diagram showing the dimensions and weight capacities of the Novogratz Regal Double Wide Record Station.

Assembled Dimensions: 27.25" H x 37.28" W x 16.14" D (69.2 cm H x 94.7 cm W x 41 cm D)

Item Weight: 56.2 lbs (25.5 kg)

Maximum Weight Recommendation: 165 lbs (74.8 kg) total

Top Surface Capacity: 40 lbs (18.1 kg)

Each Cubby Capacity: 15 lbs (6.8 kg)

Assembly Instructions

Your Novogratz Regal Double Wide Record Station/Accent Cabinet ships flat-packed and requires assembly. Two adults are recommended for assembly. Please refer to the detailed assembly guide included in your product packaging for step-by-step instructions and a complete list of parts and hardware.

General Assembly Tips:

- Unpack all components and verify against the parts list in your manual.

- Lay out all hardware and identify each piece.
- Use a flat blade and Phillips screwdriver for assembly. A hammer may be listed but is often not required for dowels.
- Follow the diagrams carefully. If a step seems unclear, re-read the instructions and examine the diagrams closely.
- Ensure all connections are secure but do not overtighten screws, which can damage the engineered wood.



Image: A close-up view of the Novogratz Regal Double Wide Record Station, highlighting the engineered wood construction and metal base.

Operating Instructions

This versatile cabinet can be used in various ways:

- **Record Station:** Place your record player on the top surface. Utilize the lower cubbies for vinyl record storage. The open back on the top two cubbies allows for easy routing of audio cables.
- **Accent Cabinet:** Use the cubbies to display decorative items, books, or other personal belongings.
- **Coffee Bar/Beverage Stand:** The top surface is suitable for a coffee machine or beverage dispensers, with cubbies for mugs, bottles, or accessories.



Image: The Novogratz Regal Double Wide Record Station configured as a record player stand, displaying a turntable and vinyl records.

Maintenance and Care

To maintain the appearance and longevity of your cabinet:

- **Cleaning:** Wipe surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood.
- **Placement:** Avoid placing the cabinet in direct sunlight or near heat sources to prevent warping or fading.
- **Stability:** Periodically check all screws and connections to ensure they remain tight. Re-tighten as needed.

Troubleshooting

If you encounter any issues with your Novogratz Regal cabinet, consider the following:

- **Wobbling/Instability:** Ensure the cabinet is placed on a level surface. Check all assembly screws and cam locks to confirm they are fully tightened.
- **Damaged Parts:** If any parts were damaged during shipping or assembly, do not attempt to force them. Contact customer support for replacement parts.
- **Assembly Difficulties:** Refer back to the included assembly manual. If a step is unclear, contact customer support for clarification.

Specifications

Feature	Detail
Brand	Novogratz
Model Name	Regal
Model Number	7347905COM
Color	Walnut
Product Dimensions	16.14"D x 37.28"W x 27.25"H
Item Weight	56.2 pounds
Maximum Weight Recommendation	165 pounds
Top Surface Capacity	40 lbs
Each Cubby Capacity	15 lbs
Frame Material	Engineered Wood
Furniture Finish	Danish Walnut
Number of Shelves	6 (cubbies)
Indoor/Outdoor Usage	Indoor
Product Care Instructions	Wipe with Dry Cloth
UPC	029986734709

Warranty Information

This Novogratz product includes a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. For specific terms and conditions, please refer to the warranty documentation included with your product or contact Novogratz customer support.

Customer Support

For assistance with assembly, missing parts, or any other inquiries regarding your Novogratz Regal Double Wide Record Station/Accent Cabinet, please contact Novogratz customer support. Refer to the contact information provided in your product packaging or visit the official Novogratz website.
Online Resources:

- Online replacement parts ordering

- Easy to read instruction manuals
- Assembly videos (if available)



Image: Novogratz customer support information, highlighting services like customer support, assembly videos, instruction manuals, online replacement parts, and warranty.

© 2024 Novogratz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question