

[Manuals.plus](#) /

> [HP](#) /

> HP Digital Stylus Pen (MPP 1.51) User Manual

HP 1FH00AAR#ABA

HP Digital Stylus Pen (MPP 1.51) User Manual

Model: 1FH00AAR#ABA

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your HP Digital Stylus Pen (MPP 1.51). Please read this manual thoroughly before using the device to ensure optimal performance and longevity.

The HP Digital Stylus Pen is designed for use with compatible HP Envy x360, Pavilion x360, and Spectre x360 2-in-1 laptops, offering precise input with pressure sensitivity.

PACKAGE CONTENTS

Verify that all items are present in the package:

- HP MPP Pen
- 1 additional pen tip
- Quick Start guide
- Warranty card

IN THE BOX



- ▶ HP MPP Pen
- ▶ 1 additional pen tip
- ▶ Quick Start guide
- ▶ Warranty card

Image: Contents of the HP Digital Stylus Pen package, showing the pen, an extra tip, a quick start guide, and a warranty card.

COMPATIBILITY

The HP Digital Stylus Pen (MPP 1.51) is compatible with specific HP 2-in-1 laptops that support Microsoft Pen Protocol (MPP). Before use, confirm your laptop's compatibility by checking its specifications on the official HP website.

Example Compatible Devices:

- HP ENVY x360 15-ewxxx
- HP ENVY x360 15-eyxxx
- HP ENVY x360 15-euxxx
- HP ENVY x360 15t-esxxx
- HP ENVY x360 15m-esxxx
- HP ENVY x360 15-dsxxx
- HP ENVY x360 15-cnxxx
- HP ENVY x360 15-bpxxx
- HP ENVY x360 15-arxxx

- HP ENVY x360 14t-esxxx
- HP ENVY x360 13-agxxx
- HP ENVY x360 13z-agxxx

- HP Spectre x360 16-fxxxx
- HP Spectre x360 15-dfxxx
- HP Spectre x360 15-chxxx
- HP Spectre x360 15-blxxx
- HP Spectre x360 15t-ebxxx
- HP Spectre x360 14-efxxx
- HP Spectre x360 14t-eaxxx
- HP Spectre x360 13-awxxx
- HP Spectre x360 13-apxxx
- HP Spectre x360 13-aexxx
- HP Spectre x360 13-acxxx

- HP Pavilion x360 15-dqxxx
- HP Pavilion x360 15-crxxx
- HP Pavilion x360 15-brxxx
- HP Pavilion x360 15t-erxxx
- HP Pavilion x360 14-dyxxx
- HP Pavilion x360 14-dwxxx
- HP Pavilion x360 14-ekxxx
- HP Pavilion x360 14-dhxxx
- HP Pavilion x360 14t-efxxx
- HP Pavilion x360 14t-dyxxx
- HP Pavilion x360 14m-baxxx
- HP Pavilion x360 14m-cdxxx
- HP Pavilion x360 11-adxxx
- HP Pavilion x360 11-apxxx
- HP Pavilion x360 11m-adxxx

COMPATIBLE DEVICES

HP ENVY x360 15-ewxxx

HP ENVY x360 15-eyxxx

HP ENVY x360 15-euxxx

HP ENVY x360 15t-esxxx

HP ENVY x360 15m-esxxx

HP ENVY x360 15-dsxxx

HP ENVY x360 15-cnxxx

HP ENVY x360 15-bpxxx

HP ENVY x360 15-arxxx

HP ENVY x360 14t-esxxx

HP ENVY x360 13-agxxx

HP ENVY x360 13z-agxxx

HP Spectre x360 16-fxxx

HP Spectre x360 15-dfxxx

HP Spectre x360 15-chxxx

HP Spectre x360 15-blxxx

HP Spectre x360 15t-ebxxx

HP Spectre x360 14-efxxx

HP Spectre x360 14t-eaxxx

HP Spectre x360 13-awxxx

HP Spectre x360 13-apxxx

HP Spectre x360 13-aexxx

HP Spectre x360 13-acxxx

HP Pavilion x360 15-dqxxx

HP Pavilion x360 15-crxxx

HP Pavilion x360 15-brxxx

HP Pavilion x360 15t-erxxx

HP Pavilion x360 14-dyxxx

HP Pavilion x360 14-dwxxx

HP Pavilion x360 14-ekxxx

HP Pavilion x360 14-dhxxx

HP Pavilion x360 14t-efxxx

HP Pavilion x360 14t-dyxxx

HP Pavilion x360 14m-baxxx

HP Pavilion x360 14m-cdxxx

HP Pavilion x360 11-adxxx

HP Pavilion x360 11-apxxx

HP Pavilion x360 11m-adxxx

Please check compatibility before purchasing



Image: A list of compatible HP Envy x360, Spectre x360, and Pavilion x360 laptop models for the HP Digital Stylus Pen, alongside images of three different HP 2-in-1 laptops.

SETUP

1. Battery Installation

The HP Digital Stylus Pen requires one AAAA battery (included in some packages, otherwise sold separately). To install the battery:

1. Gently twist the top part of the pen counter-clockwise to open the battery compartment.
2. Insert one AAAA battery with the positive (+) end facing the pen tip.
3. Twist the top part clockwise to securely close the compartment.

Note: Ensure the battery is inserted correctly. Incorrect insertion may prevent the pen from functioning.

2. Initial Connection

The HP Digital Stylus Pen connects automatically to compatible HP 2-in-1 laptops. No Bluetooth pairing is typically required.

1. Ensure your compatible HP laptop is powered on.
2. Simply tap the pen tip on the laptop screen. The cursor should appear, indicating a successful connection.

GET A PEN THAT GETS YOU.



A Microsoft compatible pen.*



Customize two buttons to your needs.



Pressure-sensitive writing and pen-point accuracy.



Converts handwriting to text.



Clip it anywhere.



Up to 18 months of battery life.*



*Supports HP consumer notebooks that are designed with MPP solution.

*Actual battery life will vary with use and environmental conditions, and will naturally decrease with time and usage.

Image: Infographic highlighting key features of the HP Digital Stylus Pen, such as Microsoft compatibility, customizable buttons, pressure-sensitive writing, handwriting-to-text conversion, portability, and battery life.

OPERATING INSTRUCTIONS

Writing and Drawing

The pen offers a natural writing and drawing experience with its precision tip and pressure sensitivity.

- **Precision Tip:** Use the pen for detailed editing, drawing, and writing.
- **Pressure Sensitivity:** Vary your pressure on the screen to achieve different line thicknesses and shading effects, similar to a traditional pen or pencil.
- **Ink to Text:** On compatible applications, your handwriting can be instantly converted to text.

DIMENSIONS

Weight
0.04 lb
(.02 kg)

Height
0.37"
(9.5 mm)

Length
5.5"
(139.7 mm)

Image: The HP Digital Stylus Pen being used on an HP 2-in-1 laptop screen, illustrating its functionality for writing and drawing within a digital document.

Customizable Buttons

The pen features two customizable buttons on its side. These buttons can be configured to perform various functions, such as right-click, erase, or launch specific applications, depending on your laptop's settings and installed software.

- Refer to your laptop's operating system settings or HP Pen Control software for customization options.




Image: A close-up view of the HP Digital Stylus Pen, highlighting the two side buttons designed for customizable functions.

MAINTENANCE

Cleaning

To maintain the pen's appearance and functionality:

- Wipe the pen body with a soft, dry, lint-free cloth.
- Avoid using harsh chemicals, abrasive cleaners, or solvents.

Pen Tip Replacement

The pen comes with one additional pen tip. If the current tip becomes worn or damaged, it can be replaced.

1. Gently pull the old pen tip straight out from the pen body.
2. Insert the new pen tip straight into the pen body until it is secure.

Battery Replacement

When the pen's performance diminishes or it stops responding, the AAAA battery may need replacement. Battery life can vary based on usage and environmental conditions.

1. Twist the top part of the pen counter-clockwise to open the battery compartment.
2. Remove the old AAAA battery.
3. Insert a new AAAA battery with the positive (+) end facing the pen tip.
4. Twist the top part clockwise to securely close the compartment.

Caution: Dispose of used batteries according to local regulations.

TROUBLESHOOTING

- **Pen is not responding:**
 - Ensure the AAAA battery is correctly installed and has sufficient charge. Replace the battery if necessary.
 - Verify that your laptop is compatible with MPP pens.
 - Try tapping the pen on the screen again to re-establish connection.
 - Restart your laptop.
- **Inaccurate or inconsistent input:**
 - Check if the pen tip is securely installed and not damaged. Replace if needed.
 - Ensure your laptop screen is clean and free of debris.
 - Calibrate the pen in your laptop's settings (if available).
- **Buttons are not working:**
 - Check your laptop's pen settings or HP Pen Control software to ensure the buttons are configured correctly.
 - Ensure the pen is connected to the laptop.
- **Pen freezes or becomes unresponsive temporarily:**
 - Retap the screen with the pen.
 - Remove and reinsert the battery.

- This can sometimes occur due to inactivity.

SPECIFICATIONS

Feature	Detail
Model Number	1FH00AAR#ABA
Product Dimensions (L x W x H)	5.43 x 0.37 x 0.37 inches (13.79 x 0.94 x 0.94 cm)
Item Weight	0.64 ounces (18.14 g)
Color	Dark Grey
Material	Plastic
Battery Type	1 x AAAA Alkaline battery
Compatible Devices	HP Envy x360, Pavilion x360, Spectre x360 2-in-1 Laptops (MPP compatible)
Pressure Sensitivity	Supported



Image: A diagram illustrating the dimensions and weight of the HP Digital Stylus Pen.

WARRANTY AND SUPPORT

This product comes with a warranty. Please refer to the included Warranty Card for details on coverage, terms, and conditions. For technical support, product information, or warranty claims, please visit the official HP support website or contact HP customer service.

HP Support Website: www.hp.com/support