

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MAIDeSITe](#) /

› [MAIDeSITe Electric Lift Chair Charger JC35M3 Instruction Manual](#)

MAIDeSITe JC35M3-003

MAIDeSITe Electric Lift Chair Charger JC35M3 Instruction Manual

Model: JC35M3-003

[Introduction](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your MAIDeSITe Electric Lift Chair Charger, model JC35M3. Please read this manual thoroughly before initial use and retain it for future reference. This charger is designed to provide power to compatible electric lift chairs, ensuring reliable operation.

2. SETUP

2.1 Unpacking

Carefully remove the charger from its packaging. Inspect the charger for any signs of damage. If any damage is observed, do not use the product and contact customer support.

2.2 Connecting the Charger

1. Ensure the lift chair is turned off and disconnected from any power source before connecting the charger.
2. Locate the charging port on your electric lift chair. This is typically a circular port designed to accept the charger's connector.
3. Connect the charger's output plug (the round connector) securely into the lift chair's charging port. Ensure a firm connection.
4. Plug the charger's power cord into a standard 110-220V AC electrical outlet.



Image 2.1: The MAIDeSITe Electric Lift Chair Charger JC35M3. This image displays the charger's main unit, the standard US plug, and the specific output connector designed for electric lift chairs. The connector is black and features a secure locking mechanism.

Once connected, the lift chair should begin charging. Refer to your lift chair's manual for specific charging indicators.

3. OPERATION

3.1 Charging Your Lift Chair

The MAIDeSITe JC35M3 charger is designed for automatic charging. Once properly connected to the lift chair and a power outlet, it will deliver the necessary power to recharge the chair's battery. There are no user-adjustable settings on the charger itself.

- Allow sufficient time for the lift chair's battery to fully charge. Charging times may vary depending on the battery's depletion level and capacity.
- It is recommended to charge the lift chair when not in use.
- Always ensure the charger is placed in a well-ventilated area during operation to prevent overheating.

3.2 Disconnecting the Charger

1. Unplug the charger from the electrical outlet first.
2. Gently disconnect the charger's output plug from the lift chair's charging port. Avoid pulling on the cable.

4. MAINTENANCE

4.1 Cleaning

To clean the charger, unplug it from the wall outlet and the lift chair. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners, aerosols, or solvents, as these can damage the unit or create a shock hazard.

4.2 Storage

When not in use, store the charger in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the cable is not kinked or wrapped too tightly to prevent damage.

4.3 Inspection

Periodically inspect the charger's cable and housing for any signs of wear, cuts, or damage. If any damage is found, discontinue use immediately and seek a replacement.

5. TROUBLESHOOTING

If you encounter issues with your MAIDeSITe Electric Lift Chair Charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lift chair not charging.	Charger not properly connected.	Ensure both ends of the charger are securely plugged in.
Lift chair not charging.	Power outlet is not active.	Test the outlet with another device or try a different outlet. Check circuit breaker.
Lift chair not charging.	Damaged charger or cable.	Inspect the charger and cable for visible damage. If damaged, discontinue use and replace.
Charger feels warm during use.	Normal operation.	A slight warmth is normal during charging. Ensure adequate ventilation around the charger. If it becomes excessively hot, disconnect immediately and contact support.

If the problem persists after attempting these solutions, please contact MAIDeSITe customer support.

6. SPECIFICATIONS

Feature	Detail
Model Number	JC35M3-003
Input Voltage	110~220V
Color	Black

Feature	Detail
Product Dimensions	3 x 4 x 2 inches (7.62 x 10.16 x 5.08 cm)
Item Weight	5.9 ounces (0.17 Kilograms)
Material	Steel
Manufacturer	MAIDeSITe

7. WARRANTY INFORMATION

The MAIDeSITe Electric Lift Chair Charger JC35M3 comes with a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation.

To claim warranty service, please retain your proof of purchase and contact MAIDeSITe customer support.

8. CUSTOMER SUPPORT

For any questions, concerns, or technical assistance regarding your MAIDeSITe Electric Lift Chair Charger, please refer to the contact information provided with your product packaging or visit the official MAIDeSITe website. When contacting support, please have your product model number (JC35M3-003) and purchase details ready.

We are committed to providing reliable products and excellent customer service.

© 2025 MAIDeSITe. All rights reserved.

Related Documents - JC35M3-003

 <p>Maidesite Chair Lift Instruction Manual: Safety, Operation, and Maintenance Guide</p> <p>Comprehensive instruction manual for the Maidesite Chair Lift, covering safety guidelines, charger and controller operation, product structure, technical specifications, and maintenance. Designed for home rehabilitation.</p>
 <p>MAIDeSITe AX05 Electric Lift Chair User Manual</p> <p>Comprehensive user manual for the MAIDeSITe Electric Lift Chair - AX05, detailing product description, safety warnings, assembly instructions, usage guidelines, maintenance, storage, moving, and after-sale service. Designed for elderly and disabled individuals to assist with sitting and standing.</p>




[MAIDESITE T1 Pro Standing Desk Frame User Guide](#)

This user guide provides instructions and safety information for the MAIDESITE T1 Pro standing desk frame, including assembly steps, part lists, and product specifications.



[Madesite Ergonomic Office Chair: Installation and Adjustment Guide](#)

Detailed instructions for assembling and adjusting your Madesite ergonomic office chair. Includes parts list, hardware guide, step-by-step assembly, and functional adjustments for optimal comfort and ergonomics.



[Madesite Electric Height Adjustable Desk User Manual](#)

User manual for the Madesite Electric Height Adjustable Desk, covering assembly, operation, and troubleshooting.



[Madesite Standing Desk T2 Pro/T2 Pro Plus User Guide](#)

Comprehensive user guide for the Madesite Standing Desk T2 Pro and T2 Pro Plus, covering safety, assembly, and control panel instructions.