



Manuals.plus /

- › Dazzle Bright /
- › Dazzle Bright 300 LED Curtain String Lights (Model B09T33HC7B) User Manual

Dazzle Bright B09T33HC7B

Dazzle Bright 300 LED Curtain String Lights (Model B09T33HC7B) - User Manual

Model: B09T33HC7B | Brand: Dazzle Bright

1. PRODUCT OVERVIEW

The Dazzle Bright 300 LED Curtain String Lights are designed to provide decorative illumination for various indoor and outdoor settings. This product features 300 purple LED lights spread across a 9.8ft by 9.8ft curtain, offering 8 distinct lighting modes. It is USB powered and includes a remote control for convenient operation. The lights are waterproof, making them suitable for diverse decorative applications.




Image 1.1: Overview of the Dazzle Bright Purple LED Curtain String Lights, including the remote control and USB power source.

2. PACKAGE CONTENTS

- 1 x Dazzle Bright 300 LED Curtain String Lights (Purple)
- 1 x Remote Control
- 10 x Installation Hooks
- 1 x USB Power Cable (integrated with lights)

300 window curtain led lights




Image 2.1: Diagram illustrating the components and dimensions of the curtain lights, including the USB power, remote, and hooks.

3. SAFETY INFORMATION

- Ensure the USB power source provides 5V output. Using an incorrect voltage may damage the lights or pose a safety risk.
- Do not cut or modify the light strings. This can damage the product and void the warranty.
- Keep the USB plug and remote control dry. While the lights are waterproof (IP44 rated), the power connection and remote are not.
- Avoid excessive pulling or tangling of the wires during installation to prevent damage.
- Unplug the lights from the power source when not in use or during maintenance.
- This product is not a toy. Keep out of reach of children.

4. SETUP INSTRUCTIONS

1. **Unpack Carefully:** Gently remove the lights from the packaging. The wires can tangle easily. It is recommended to uncoil

each vertical string one by one while the main horizontal string is already in place.

2. **Identify Main String:** Locate the main horizontal string from which the 10 vertical light strings hang. This string also contains the USB power cable.

3. **Mounting:**

- Use the provided hooks to hang the main horizontal string in your desired location (e.g., along a curtain rod, wall, or frame). Ensure the hooks are evenly spaced for optimal light distribution.
- The lights are designed to cover a 9.8ft (300cm) width and 9.8ft (300cm) height.

4. **Unfurl Vertical Strings:** Once the main horizontal string is securely mounted, carefully uncoil each of the 10 vertical light strings. Allow them to hang freely.

5. **Connect Power:** Insert the USB plug into a compatible 5V USB power adapter (not included) or a USB port on a device.



Image 4.1: Coiled lights, emphasizing the need for careful handling during setup to prevent tangling.

5. OPERATING INSTRUCTIONS

5.1 Using the Remote Control

The included remote control allows you to power the lights on/off, select lighting modes, adjust brightness, and set a timer.

- **ON/OFF:** Press the **ON** button to turn the lights on, and **OFF** to turn them off.
- **Mode Selection:** Press the numbered buttons (1-8) to cycle through the 8 different lighting modes. These modes include combinations like waves, sequential, slo-glo, chasing/flash, slow fade, twinkle/flash, and steady on.
- **Brightness Adjustment:** Use the **DIM** and **BRIGHT** buttons to increase or decrease the light intensity.
- **Timer Function:** Press the **2H**, **4H**, **6H**, or **8H** buttons to activate the timer. The lights will stay on for the selected duration and then turn off automatically. They will resume the next day at the same time.
- **Speed Adjustment:** Use the **SPEED+** and **SPEED-** buttons to adjust the speed of dynamic lighting modes.

5.2 Manual Control (USB Plug Button)

In case the remote control is unavailable or its battery is depleted, you can cycle through the lighting modes by pressing the button located on the USB plug.




Image 5.1: Key features of the Dazzle Bright Curtain String Lights, including remote control functionality.

6. MAINTENANCE

- **Cleaning:** To clean the lights, ensure they are unplugged. Gently wipe with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When storing the lights, carefully coil each vertical string individually to prevent tangling. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Remote Battery:** If the remote control stops responding, replace its battery (e.g., CR2025 button cell).

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	<ul style="list-style-type: none"> • No power to USB port. • Loose USB connection. • Faulty USB adapter. 	<ul style="list-style-type: none"> • Ensure USB power source is active. • Check that the USB plug is fully inserted. • Try a different USB power adapter or port.
Remote control is not working.	<ul style="list-style-type: none"> • Remote battery is dead or incorrectly inserted. • Obstruction between remote and USB receiver. • Remote is too far from the USB receiver. 	<ul style="list-style-type: none"> • Replace the remote battery (e.g., CR2025). • Ensure a clear line of sight to the USB receiver. • Move closer to the USB receiver. • Use the button on the USB plug to change modes manually.
Lights are tangled.	Improper unpacking or storage.	Carefully untangle the wires. For future use, uncoil each string individually during setup and coil them separately for storage.

8. SPECIFICATIONS

Feature	Detail
Model Number	B09T33HC7B
Brand	Dazzle Bright
Light Color	Purple
Number of LEDs	300
Dimensions	9.8ft (width) x 9.8ft (height)
Lighting Modes	8 (various combinations)
Power Source	USB (Corded Electric)
Voltage	5 Volts
Wattage	5 watts
Water Resistance	IP44 Waterproof (lights only)
Control Method	Remote Control, Button on USB Plug
Material	Copper wire
Item Weight	5.3 ounces
UPC	786552686502

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Dazzle Bright website. Please retain your proof of purchase for any warranty claims.

