Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FELICON B09T3LMWJX

User Manual

FELICON 60% Wired Mechanical Gaming Keyboard (68-key)

Product Overview

The FELICON 60% Wired Mechanical Gaming Keyboard is a compact 68-key keyboard designed for gaming and general use. It features RGB backlighting, anti-ghosting keys, and a detachable Type-C USB cable for portability. The keyboard utilizes mechanical blue switches, providing tactile feedback and an audible click sound.



Figure 1: FELICON 60% Wired Mechanical Gaming Keyboard with detachable cable and mouse pad.

Package Contents

- FELICON 60% Wired Mechanical Gaming Keyboard (68-key)
- Type-C USB Cable
- Keycap Removal Tool
- Additional Space and ESC keycaps

Setup

Connecting the Keyboard

1. Locate the Type-C port on the back or side of the keyboard.
2. Connect one end of the provided Type-C USB cable to the keyboard's Type-C port.

3. Connect the other end of the USB cable to an available USB port on your computer (PC, Laptop, Gaming Console).
4. The keyboard is plug-and-play and does not require additional drivers for basic functionality.



Figure 2: The detachable Type-C USB cable provides a stable connection and convenient storage.

System Compatibility

This keyboard is compatible with various operating systems, including:

- Windows XP
- Windows 7/8/10
- Android
- Mac OS
- Linux OS



Figure 3: The keyboard is compatible with Windows, Mac OS, and Linux operating systems.

Operating Instructions

Function Key Combinations (FN Keys)

The 68-key compact layout utilizes FN key combinations to access functions typically found on a full-size keyboard. Press and hold the **FN** key, then press the corresponding key to activate its secondary function.

- **FN + TAB**: Cycle through 18 different RGB backlight effects.
- **FN + P**: Adjust the light mode (likely brightness or specific pattern).
- **FN + W**: Toggle between WASD keys and arrow keys for navigation. This allows WASD to function as up, down, left, and right arrows.
- Other FN combinations for F1-F12, multimedia controls, and other functions are indicated on the keycaps.



Figure 4: The keyboard features FN key combinations to access a wide range of functions, including F1-F12 and arrow key toggling.



Figure 5: The keyboard offers 18 RGB backlight effects, adjustable via FN key combinations.

Anti-Ghosting

All keys on this keyboard feature anti-ghosting technology, ensuring that every keystroke is registered accurately, even when multiple keys are pressed simultaneously. This is particularly beneficial for fast-paced gaming and high-speed typing.

Maintenance

Cleaning the Keyboard

- Disconnect the keyboard from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe down the keycaps and keyboard surface.
- For dust and debris between keys, use compressed air or a small brush.

- The keyboard is designed to be waterproof, offering protection against accidental spills. However, avoid submerging the keyboard in liquid.

Keycap Replacement

The keyboard comes with a keycap removal tool and additional keycaps (Space and ESC) for customization. To replace a keycap:

1. Gently attach the keycap removal tool to the keycap you wish to remove.
2. Pull straight up with even pressure until the keycap detaches from the switch.
3. Align the new keycap with the switch stem and press down firmly until it clicks into place.



Figure 6: The keyboard features durable PBT keycaps and mechanical blue switches, which can be replaced if needed.

Troubleshooting

Problem	Possible Cause	Solution
Keyboard not responding	Loose USB connection; Incorrect USB port; System driver issue.	Ensure the USB cable is securely connected to both the keyboard and the computer. Try a different USB port. Restart your computer.
Backlight not working or stuck	Incorrect backlight setting; Software glitch.	Press **FN + TAB** to cycle through backlight modes. Press**FN + P** to adjust light mode. Disconnect and reconnect the keyboard.
WASD keys not functioning as arrow keys	WASD/Arrow key toggle is off.	Press **FN + W** to toggle between WASD and arrow key functionality.
Some keys not registering	Debris under keycap; Faulty switch.	Remove the keycap and clean around the switch using compressed air. If the issue persists, contact customer support.

If you encounter any issues not listed here or if the suggested solutions do not resolve the problem, please contact FELICON customer support for assistance.

Specifications

Brand	FELICON
Model	60% Wired Mechanical Gaming Keyboard (68-key)
Connectivity Technology	USB Type-C (Detachable)
Number of Keys	68
Switch Type	Mechanical Blue Switch
Key Rollover	All Keys Anti-Ghosting
Backlighting	RGB (18 effects)
Special Features	Waterproof, Ergonomic Design, PBT Color Blocking Keycaps
Compatible Devices	Gaming Console, Laptop, PC (Windows XP/7/8/10, Android, Mac OS, Linux OS)
Item Weight	1.89 pounds (approx. 857g)
Dimensions (L x W x H)	12.20 x 3.94 x 1.57 inches (approx. 31 x 10 x 4 cm)



Figure 7: Detailed dimensions of the FELICON 60% Mechanical Keyboard.

Warranty and Support

FELICON is committed to delivering high-quality products and customer satisfaction. If you encounter any issues or are unsatisfied with your product for any reason, please contact our after-sales service.
For support inquiries, please refer to the contact information provided with your purchase or visit the official FELICON store page on Amazon:

Visit the FELICON Store on Amazon

© 2024 FELICON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09T3LMWJX

More documents and user manuals: **https://manuals.plus/**