

[Manuals.plus](#) /

› [Weehom](#) /

› Weehom King Bed Frame 16 Inch Metal Platform Bed Frame Instruction Manual

Weehom King 16Inch

Weehom King Bed Frame 16 Inch Metal Platform Bed Frame Instruction Manual

Model: King 16Inch

1. INTRODUCTION

This manual provides detailed instructions for the assembly, usage, maintenance, and troubleshooting of your Weehom King 16 Inch Metal Platform Bed Frame. Please read all instructions carefully before assembly and retain this manual for future reference.

2. SAFETY INFORMATION

- Ensure all parts are present and undamaged before beginning assembly. Do not use if any parts are missing or broken.
- Assemble the bed frame on a soft, clean surface to prevent scratches.
- Tighten all bolts and screws securely. Periodically check and re-tighten fasteners to maintain stability.
- Do not exceed the maximum weight capacity of 770 LBS.
- Keep small parts away from children during assembly.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any items are missing, please contact Weehom customer support.

- Headboard/Footboard sections (if applicable)
- Side rails
- Center support beams
- Steel slats
- Support legs

- Hardware pack (bolts, washers, Allen wrench)
- Instruction manual

4. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward and typically takes less than an hour. It is recommended to have two people for easier assembly.

1. **Unpack and Identify Parts:** Carefully remove all components from the box and lay them out on a clean, soft surface. Refer to the parts list to ensure all pieces are present.
2. **Assemble Frame Sides:** Connect the side rails to the headboard and footboard sections using the provided bolts and Allen wrench. Do not fully tighten bolts yet.
3. **Install Center Support:** Attach the center support beam(s) and their respective legs to the frame. Ensure the legs are oriented correctly for maximum stability.
4. **Place Slats:** Position the steel slats across the frame. The slats are designed to fit into designated slots or attach with screws. Ensure even spacing for optimal mattress support.
5. **Final Tightening:** Once all components are in place, systematically tighten all bolts and screws. Ensure the frame is level and stable.



Figure 4.1: Isometric view of the assembled bed frame, illustrating its robust metal construction and slat support system.



Figure 4.2: Detail of a slat connection, highlighting the secure fastening mechanism for stability.



Figure 4.3: Detail of a bed frame leg, featuring a protective cap to safeguard flooring.

5. USAGE GUIDELINES

The Weehom King 16 Inch Metal Platform Bed Frame is designed for use with a King-sized mattress. No box spring is required due to the robust steel slat support system.

- **Mattress Placement:** Carefully place your King-sized mattress directly onto the steel slats. Ensure it is centered and evenly supported.
- **Under-bed Storage:** The frame provides 14 inches of clearance, offering ample space for under-bed storage containers or luggage.
- **Weight Distribution:** Distribute weight evenly across the bed frame to prevent undue stress on individual components.



Figure 5.1: The bed frame with a mattress and items stored underneath, demonstrating the generous 14-inch clearance.



Figure 5.2: Visual representation of the 14-inch under-bed storage capacity.



Figure 5.3: The bed frame's noise-free design contributes to a comfortable sleep environment.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Regular Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten as necessary to maintain the frame's stability and prevent squeaking.
- **Avoid Excessive Force:** Do not jump on the bed or apply excessive, uneven force, as this can bend components or loosen connections.

7. TROUBLESHOOTING

- Issue: Bed frame is wobbly or unstable.**
- Solution:** Ensure all bolts and screws are fully tightened. Check that all support legs are making firm contact with the floor. If the floor is uneven, consider using furniture pads or shims under the legs.
- Issue: Squeaking noises.**
- Solution:** Squeaking often indicates loose connections. Re-tighten all bolts and screws. If squeaking persists, apply a small amount of lubricant (e.g., silicone spray) to the joints where metal parts meet.
- Issue: Parts appear bent or damaged upon arrival.**
- Solution:** If you receive bent or damaged parts, do not attempt to force them into place. Contact Weehom customer support immediately for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Size	King
Product Dimensions (L x W x H)	82.28" x 77.56" x 16"
Under-bed Clearance	14 Inches
Material	Steel
Color	Black
Weight Capacity	770 LBS

Assembly Required	Yes
Box Spring Needed	No




Figure 8.1: Key dimensions and weight capacity of the bed frame.

9. WARRANTY AND SUPPORT

Weehom products are designed for durability and ease of use. For specific warranty information regarding your bed frame, please refer to the documentation included with your purchase or visit the official Weehom website. For any questions, missing parts, or assistance with assembly, please contact Weehom customer support directly.

Weehom Customer Support: Refer to your purchase receipt or the Weehom brand store for contact details.

Online Resources: [Visit the Weehom Store on Amazon](#)

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09T6D9354>

More documents and user manuals: <https://manuals.plus/>