

vidaXL 336251

vidaXL White Steel Wardrobe (Model 336251) Instruction Manual

1. PRODUCT OVERVIEW

The vidaXL White Steel Wardrobe is designed to help keep your interior organized and tidy. This durable steel wardrobe offers a perfect storage solution, adding a functional and chic touch to your home. It features 4 adjustable shelves and a large compartment with a hanging rail, providing ample space for various clothing items and accessories.



Image 1.1: The vidaXL White Steel Wardrobe, showcasing its design and how it fits into a living space.

2. SAFETY INSTRUCTIONS

WARNING: To prevent tipping, this product must be used with the provided wall attachment device. Failure to do so can result in serious injury.

Always ensure the wardrobe is placed on a level surface. Distribute weight evenly across shelves and the hanging rail. Do not allow children to climb on or play with the wardrobe.



Image 2.1: Detail of the rear of the wardrobe, indicating the wall attachment points for stability.

3. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	vidaXL
Model Number	336251
Color	White

Feature	Specification
Material	Steel
Dimensions (W x D x H)	90 x 50 x 180 cm (35.4 x 19.7 x 70.9 inches)
Item Weight	40 kg (88 lbs)
Load Capacity per Shelf	50 kg (110 lbs)
Total Load Capacity	100 kg (220 lbs)
Features	4 adjustable shelves, hanging rail, bottom levelers, ventilation openings on doors



Image 3.1: Dimensional diagram of the wardrobe, illustrating its width, depth, and height.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this wardrobe. Please follow these general steps carefully. It is recommended to have a second person assist during certain stages of assembly for ease and safety. Ensure you have adequate space and the necessary tools (e.g., screwdriver, hammer, level).

4.1. Preparation

- Unpack all components and lay them out on a clean, soft surface to prevent scratches.
- Verify that all parts listed in the packaging contents are present and undamaged.

4.2. Step-by-Step Assembly

1. **Assemble the Frame:** Connect the side panels to the top and bottom panels using the provided fasteners. Ensure all connections are secure.
2. **Install Shelves:** Insert the adjustable shelves into the desired positions. The wardrobe includes 4 adjustable shelves.
3. **Attach Hanging Rail:** Secure the hanging rail within the designated compartment.
4. **Mount Doors and Handles:** Attach the doors to the frame using the hinges. Then, install the handles onto the doors.
5. **Adjust Levelers:** Once assembled, adjust the levelers at the bottom of the wardrobe to ensure stability and proper door alignment.
6. **Secure to Wall:** Using the provided wall attachment device, secure the wardrobe to a sturdy wall to prevent tipping. Follow the instructions for your specific wall type.




Image 4.1: Detail of the adjustable levelers at the base, used for stabilizing the wardrobe on uneven floors.



Image 4.2: Detail of the door handles, which are installed during the final assembly steps.

5. OPERATING YOUR WARDROBE

This wardrobe is designed for versatile storage. Utilize the 4 adjustable shelves for folded garments, accessories, or storage boxes. The large compartment with a hanging rail is ideal for longer items such as coats, dresses, or suits. The doors feature ventilation openings to ensure air circulation within the wardrobe.



Image 5.1: Front view of the wardrobe, showing the four doors and overall structure.

6. CARE AND MAINTENANCE

The steel construction of this wardrobe makes it durable and easy to clean. To maintain its appearance and longevity:

- Wipe surfaces regularly with a soft, damp cloth.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- Promptly clean any spills to prevent staining.
- Periodically check all fasteners and connections to ensure they remain tight.

7. TROUBLESHOOTING

If you encounter any issues with your wardrobe, refer to the following common problems and solutions:

- **Wardrobe feels unstable:** Ensure the wardrobe is on a level surface. Adjust the bottom levelers until the unit is stable. Confirm that the wall attachment device is properly installed and secured.
- **Doors do not align or close properly:** Check that the wardrobe is level using the adjustable feet. Verify that all hinges are correctly installed and tightened. Slight adjustments to the hinges may be necessary.
- **Hanging rail detaches:** Ensure the hanging rail is fully seated in its supports. If it continues to detach, check for any obstructions or damage to the supports.
- **Scratches or dents:** While the steel is robust, minor cosmetic damage can occur. For small scratches, touch-up paint matching the wardrobe's color may be used.

8. WARRANTY AND SUPPORT

For warranty information or if you require further assistance, please contact vidaXL customer service. Keep your purchase receipt as proof of purchase. You can typically find contact details on the official vidaXL website or through your retailer.