

[manuals.plus](#) /

› [Airbition](#) /

› [Airbition 20000mAh Oscillating Rechargeable Fan User Manual](#)

## Airbition WH91

# Airbition 20000mAh Oscillating Rechargeable Fan User Manual

Model: WH91 | Brand: Airbition

## INTRODUCTION

Thank you for choosing the Airbition 20000mAh Oscillating Rechargeable Fan. This versatile fan is designed to provide powerful and quiet cooling for various environments, from your home and office to outdoor camping trips. Featuring a large-capacity rechargeable battery, remote control, and adjustable height, it offers convenience and comfort wherever you need it. Please read this manual thoroughly before use to ensure proper operation and maintenance.

## PRODUCT FEATURES

- High-Capacity Battery:** Integrated with two 10000mAh rechargeable batteries, providing up to 50 hours of operation on a full charge. Features a micro-USB charging port with 2A fast charging, requiring approximately 8 hours for a full charge.
- Versatile 2-in-1 Design:** Easily transforms from a compact desk fan to a full-sized pedestal fan with its extendable tripod stand, suitable for various settings.
- Convenient Remote Control:** Operate all fan functions from a distance, including power, speed, oscillation, and timer settings.
- Auto Oscillation:** Supports 45° and 90° automatic oscillation to distribute cool air across a wide area.
- 7-Speed Settings:** Customize airflow with 7 distinct speed levels to meet different cooling needs.
- Programmable Timer:** Set the fan to automatically turn off after 1, 2, 4, or 8 hours for energy saving and undisturbed sleep.
- Quiet Operation:** Operates at less than 60 dB even at the highest speed, ensuring a peaceful environment.
- Mobile Power Source:** The detachable batteries can also function as a power bank to charge your phone or other devices in emergencies.



The Airbition 20000mAh Oscillating Rechargeable Fan, shown with its remote control and extendable tripod stand.



The fan's 2-in-1 design allows it to be used as a table fan or a standing floor fan.



The 20000mAh massive battery provides extended comfort for outdoor activities like camping or barbecues.



The dual detachable 10000mAh batteries can fully charge a phone 3-5 times, serving as a mobile power source.

## SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Always place the fan on a stable, flat surface to prevent tipping.

- Do not insert fingers or any objects into the fan grille when it is operating.
- Keep the fan away from water or other liquids. Do not use it in wet environments.
- Unplug the fan before cleaning or performing any maintenance.
- Do not use the fan if the power cord or plug is damaged.
- Keep out of reach of children and pets.
- Use only the provided charging cable and adapter (if included) to charge the fan.
- Do not attempt to disassemble or repair the fan yourself. Contact qualified service personnel for assistance.
- Ensure proper ventilation when charging the batteries.

## PACKAGE CONTENTS

---

Please check the package for the following items:

- Airbition Fan Unit
- Extendable Tripod Stand
- Remote Control
- USB Charging Cable
- User Manual (this document)

## SETUP

---

### 1. Assembling the Fan

The Airbition fan can be used as a desk fan or a pedestal fan. Follow these steps for assembly:

1. **For Desk Fan Use:** Simply place the fan unit on a flat, stable surface. Ensure the base is secure.
2. **For Pedestal Fan Use:**
  - a. Unfold the legs of the tripod stand until they are fully extended and stable.
  - b. Extend the telescopic pole of the tripod stand to your desired height. Secure it by tightening the locking mechanism.
  - c. Carefully attach the fan unit to the top of the extended tripod pole. Ensure it clicks securely into place.



Securely attach the fan unit to the tripod stand for pedestal use.

## 2. Charging the Battery

Before first use, fully charge the fan's integrated batteries.

1. Locate the micro-USB charging port on the fan unit.
2. Connect the provided USB charging cable to the fan and a suitable USB power adapter (not included) or a computer USB port.
3. The charging indicator lights will illuminate, showing the charging status. All lights will be solid when fully charged.
4. A full charge takes approximately 8 hours.



The fan's dual 10000mAh batteries can be charged via the micro-USB port.

## OPERATING INSTRUCTIONS

---

### 1. Power On/Off and Speed Control

- **Power Button:** Press the power button on the fan unit or the remote control to turn the fan ON or OFF.
- **Speed Adjustment:** Use the rotary knob on the fan unit or the '+' and '-' buttons on the remote control to adjust between 7 speed settings.

### 2. Oscillation Function

- Press the oscillation button (45°/90°) on the fan unit or the remote control to activate or deactivate the automatic oscillation feature.
- The fan will oscillate between 45° and 90° depending on the setting.



The fan supports 45° and 90° auto oscillation for efficient air circulation.

### 3. Timer Setting

- Press the Timer button on the fan unit or the remote control to set the auto-off timer.
- Available timer settings are 1 hour, 2 hours, 4 hours, and 8 hours. The corresponding indicator light will illuminate.



The timer function allows you to set the fan to automatically shut down after 1, 2, 4, or 8 hours.

### 4. Using as a Power Bank

The fan's detachable battery unit can be used to charge other devices:

1. Gently pull out the battery pack from the fan unit.
2. Connect your device's charging cable to the USB output port on the battery pack.
3. The battery pack will begin charging your device.

### 5. Official Product Videos

This video demonstrates the features and versatility of the 10" Portable Pedestal Fan, including its adjustable height and oscillation.

This video provides an overview of the 20000mAh Oscillating Rechargeable Fan with Remote, highlighting its key functionalities and benefits.

## MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your fan.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the fan. For the fan blades, carefully remove the front grille (if detachable) and wipe the blades with a damp cloth. Ensure the fan is completely dry before reassembling and using. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the batteries frequently. Recharge them when the power indicator is low. If storing the fan for an extended period, charge the batteries to about 50% and recharge every 3-6 months.
- **Storage:** Store the fan in a cool, dry place away from direct sunlight and extreme temperatures. If using the tripod stand, collapse it for compact storage.

## TROUBLESHOOTING

If you encounter any issues with your Airbition fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted or not properly installed.	Charge the battery fully. Ensure the battery pack is securely inserted.
Weak airflow.	Fan speed is too low; fan grille/blades are dirty.	Increase the fan speed. Clean the fan grille and blades.
Remote control not working.	Remote battery is dead; obstruction between remote and fan.	Replace the remote control battery. Ensure no obstructions and point directly at the fan's receiver.
Fan makes unusual noise.	Obstruction in fan blades; fan not on a stable surface.	Turn off and unplug the fan, then check for any obstructions. Place the fan on a stable surface.

If the problem persists after trying these solutions, please contact customer support.

## SPECIFICATIONS


Feature	Specification
Model Name	WH91
Brand	Airbition
Battery Capacity	2 x 10000mAh (20000mAh total)
Max Operating Time	Up to 50 hours (soft wind)
Charging Time	Approx. 8 hours (with 2A fast charging)
Power Source	Battery Powered
Voltage	5.0 Volts
Fan Diameter	10 Inches
Speed Settings	7 Speeds
Oscillation	45° - 90° Auto Oscillation
Timer Settings	1H, 2H, 4H, 8H
Noise Level	Less than 60 dB (at highest speed)
Control Method	Remote, Manual
Item Weight	4.82 pounds (2.19 Kilograms)

## WARRANTY AND SUPPORT

Airbition products are manufactured to the highest quality standards. This product comes with a standard limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims.

For detailed warranty information, technical support, or customer service inquiries, please refer to the official user guide PDF available online or contact Airbition customer support through their official website or the retailer where you purchased the product.

**User Guide (PDF):** [Download Here](#)

	<p><a href="#"><b>WH91 20000mAh Tripod Fan User Manual: Setup, Operation &amp; Specifications</b></a></p> <p>Get detailed instructions for the WH91 20000mAh Tripod Fan. This manual covers assembly, fan operation, speed control, timer functions, oscillation, charging, troubleshooting, and warranty information.</p>
	<p><a href="#"><b>Airbition AIR301 Wall Mount Fan User Manual</b></a></p> <p>Comprehensive user manual for the Airbition AIR301 Wall Mount Fan, covering specifications, installation, operation, cleaning, troubleshooting, and warranty information.</p>