

EXTRASTAR KJ-1286-2

Extrastar LED Camping Lanterns (2-Pack)

MODEL: KJ-1286-2

Instruction Manual

1. Introduction

Thank you for choosing the Extrastar LED Camping Lanterns. This manual provides essential information for the safe and efficient use of your new lanterns. Please read these instructions carefully before use and retain them for future reference.

These portable, waterproof LED lanterns are designed for various outdoor and indoor activities, including camping, hiking, fishing, emergency lighting, and general utility.

2. Safety Information

- Do not look directly into the LED light source to avoid eye strain or temporary vision impairment.
- Keep batteries out of reach of children.
- Always insert batteries correctly, observing polarity (+/-) markings.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the lantern will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.
- Do not attempt to disassemble or modify the lantern. This will void the warranty and may cause damage or injury.
- While waterproof, avoid submerging the lantern in water for prolonged periods.

3. Package Contents

- 2 x Extrastar LED Camping Lanterns
- 1 x Instruction Manual

Note: 3 AAA batteries are required per lantern and are not included in the package.

4. Product Overview

The Extrastar LED Camping Lantern features a compact, lightweight, and collapsible design, making it easy to carry and store. It provides 360-degree illumination with bright LED lamp beads and is constructed from durable, waterproof plastic.



This image illustrates the compact and lightweight design of the lantern. When collapsed, it measures 95mm in height and 68mm in diameter. When fully extended for use, its height is 182mm. A smartphone is shown for size comparison, highlighting its portability.



This image provides a close-up of the lantern's key features. It highlights the sturdy portable handle for carrying or hanging, the bright LED lamp beads that provide 360-degree illumination, and the base where 3 AAA batteries are inserted (batteries not included).

5. Setup: Battery Installation

1. Ensure the lantern is in its collapsed (off) position.
2. Twist the bottom cap of the lantern counter-clockwise to open the battery compartment.
3. Insert 3 new AAA batteries into the compartment, ensuring the correct polarity (+/-) as indicated inside the compartment.

4. Replace the bottom cap by twisting it clockwise until securely fastened.

6. Operating Instructions

The Extrastar LED Camping Lantern is designed for simple operation:

- **To Turn On:** Gently pull the top section of the lantern upwards. The light will illuminate as it extends.
- **To Adjust Brightness:** The brightness is fixed at 350 lumens when fully extended.
- **To Turn Off:** Push the top section of the lantern downwards until it is fully collapsed. The light will turn off automatically.
- **Using the Handle:** The metal handles can be used to carry the lantern or to hang it from a hook, branch, or tent pole.



COMPACT AND PORTABLE DESIGN

Our collapsible can be hanged on the branch or tent pole
You can carry the lantern by hand or put it on the ground

This image shows the lantern in a typical camping scenario, illuminating the area around a campfire. It demonstrates how the lantern can be used to provide light for outdoor activities and social gatherings.



This image illustrates the versatility of the lantern, showing it hanging from a pole near a camping tent. This setup is ideal for illuminating the interior of a tent or a small outdoor area.

7. Maintenance

- **Cleaning:** Wipe the lantern with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace all 3 AAA batteries simultaneously when the light dims significantly. Follow the battery installation steps in Section 5.
- **Storage:** Store the lantern in a cool, dry place when not in use. Remove batteries if storing for extended periods.

8. Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lantern does not turn on.	Batteries are dead or incorrectly installed.	Replace batteries with new ones, ensuring correct polarity.
Light is dim.	Batteries are low.	Replace batteries with new ones.
Lantern does not collapse smoothly.	Debris or obstruction.	Check for any foreign objects obstructing the collapsing mechanism. Clean if necessary.

9. Specifications

Feature	Detail
Brand	EXTRASTAR
Model Number	KJ-1286-2
Light Source Type	LED (Chip on Board)
Maximum Light Output	350 Lumens
Beam Angle	360 Degrees
Power Source	Battery Powered
Battery Type	3 x AAA Alkaline (not included)
Material	Plastic
Color	Black
Waterproof Rating	Waterproof
Collapsed Dimensions (L x W x H)	6.8 x 6.8 x 9.5 cm (2.68 x 2.68 x 3.74 inches)
Extended Height	18.2 cm (7.17 inches)
Weight	235.87 grams (0.52 lbs)

10. Warranty and Support

Specific warranty information is not provided within this manual. Please refer to the product packaging, the retailer's return policy, or the official EXTRASTAR website for details regarding warranty coverage and customer support.

For technical assistance or inquiries, please contact EXTRASTAR customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question