

Vonesse CVN200

Vonesse CVN200 Gaming Chair User Manual

Model: CVN200

[Introduction](#) [Safety](#) [Contents](#) [Assembly](#) [Features](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [W](#)
& Support

1. INTRODUCTION

This manual provides instructions for the assembly, operation, maintenance, and troubleshooting of your Vonesse CVN200 Gaming Chair. Please read this manual thoroughly before use to ensure proper function and longevity of your product.



Figure 1: Vonesse CVN200 Gaming Chair (White/Black)

The Vonesse CVN200 Gaming Chair features an ergonomic design with a footrest, reclining function, and massage lumbar support, designed for extended periods of sitting.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury and ensure safe operation:

- This chair has a maximum weight recommendation of **300 pounds**. Exceeding this limit may cause damage to the chair or personal injury.

- Improper use of adjustable features can lead to injury; follow instructions carefully.
- For extended use, take regular breaks to maintain good posture and prevent discomfort.
- Ensure safe assembly by following the provided instructions precisely.

3. PACKAGE CONTENTS

Verify that all components are present in the package before beginning assembly:

- Gaming Chair Components
- Casters (Wheels)
- Installation Hardware (Screws, Allen wrench, etc.)
- User Manual (This document)

4. ASSEMBLY INSTRUCTIONS

For detailed, step-by-step assembly instructions, please refer to the official Installation Manual (PDF) provided by Vonesse. This document contains visual guides and specific instructions for each step of the assembly process.

[Download Installation Manual \(PDF\)](#)

Ensure all parts are correctly aligned and tightened according to the manual to guarantee stability and safety.

5. PRODUCT FEATURES

The Vonesse CVN200 Gaming Chair is equipped with several features designed for comfort and adaptability:



Figure 2: Multifunction Features Overview

This image illustrates the integrated padded headrest, thickened cushion, linkage armrests, retractable padded footrest,

adjustable massage lumbar cushion, and 360-degree swivel casters.

5.1. Adjustable Recline and Swivel

The chair features a reclining mechanism that allows the backrest to be locked at any position between 90° (upright for work) and 160° (for resting). The 360-degree swivel casters provide smooth and quiet movement.



Figure 3: Adjustable Back Angle and 360-Degree Swivel

This diagram shows the range of backrest recline and the chair's full rotational capability.

5.2. Adjustable Height

The chair's height can be adjusted to accommodate users of various heights, ensuring ergonomic alignment with your desk or workstation.

5.3. Lumbar Support with Massage Function

A detachable lumbar support cushion is included, featuring a built-in massage mode to enhance comfort during prolonged sitting.

5.4. Retractable Footrest

An integrated, retractable footrest provides additional comfort, allowing users to extend their legs and relax.

5.5. Integrated Padded Headrest

The chair includes an integrated padded headrest for enhanced neck and head support.

5.6. Linkage Armrests

The armrests are designed to move in conjunction with the chair's recline, providing continuous arm support.

LINKAGE ARMREST

Brings you a smoother and easier adjustment experience



Figure 4: Linkage Armrest Mechanism

This image demonstrates how the armrests adjust with the chair's recline for consistent support.

5.7. Advanced Cushion Technology

The seat cushion incorporates advanced pocket spring technology for enhanced comfort and durability. The chair's wingless seat design offers ample sitting space.



Figure 5: Elastic Comfort Pocket Spring Cushion

A cutaway view revealing the internal pocket spring structure of the seat cushion, designed for elastic comfort.



Figure 6: Wingless Widened Cushion and PU Leather

This image highlights the spacious, wingless design of the seat cushion and the durable, easy-to-clean PU leather material.

5.8. Durable Materials

The chair is constructed with high-quality PU and carbon fiber leather, which have undergone a 25,000 Martindale rub test, indicating high tensile strength, wear resistance, and excellent color fastness. High-density resilient sponge ensures durability.

6. OPERATION

6.1. Adjusting Chair Height

1. To raise the chair: While seated, lift the lever located under the seat on the right side. The chair will rise. Release the lever at the desired height.
2. To lower the chair: While seated, pull the lever located under the seat on the right side. The chair will lower. Release the lever at the desired height.

6.2. Adjusting Backrest Recline

1. Locate the recline lever on the right side of the chair, below the seat.
2. Pull the lever upwards to unlock the backrest.
3. Lean back or forward to achieve the desired angle (between 90° and 160°).
4. Release the lever to lock the backrest in position.

6.3. Using the Retractable Footrest

1. To extend the footrest: Pull the footrest handle located under the front of the seat outwards.
2. To retract the footrest: Push the footrest back under the seat until it is fully stored.

6.4. Activating Lumbar Massage

The detachable lumbar support cushion includes a massage function. Connect the USB cable from the cushion to a compatible USB power source (e.g., computer USB port, USB wall adapter) to activate the vibration massage.

7. MAINTENANCE AND CARE

7.1. Cleaning

The chair's PU and carbon fiber leather surfaces can be cleaned by wiping with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material.

7.2. General Care

- Regularly check and tighten all screws and bolts to ensure stability.
- Avoid exposing the chair to direct sunlight or extreme temperatures for prolonged periods, as this can cause material degradation.
- Keep sharp objects away from the chair's upholstery to prevent punctures or tears.

8. TROUBLESHOOTING

If you encounter issues with your Vonesse CVN200 Gaming Chair, consider the following common solutions:

8.1. Chair Does Not Adjust Height

- Ensure the gas lift lever is fully engaged or disengaged as required.
- Check if the gas lift cylinder is properly installed and not damaged.

8.2. Backrest Does Not Recline or Lock

- Verify that the recline lever is functioning correctly and not obstructed.
- Inspect the reclining mechanism for any visible damage or loose connections.

8.3. Squeaking Noises

- Tighten all assembly bolts.
- Apply a small amount of silicone lubricant to moving parts or joints if necessary.

If these steps do not resolve the issue, please contact Vonesse customer support.

9. SPECIFICATIONS




Figure 7: Product Dimensions and Load Capacity

This image provides a visual representation of the chair's key measurements and recommended user specifications.

Feature	Detail
Model Name	CVN200
Brand	Vonesse
Color	White/Black
Product Dimensions (D x W x H)	21"D x 28"W x 46"H
Max Load Capacity	300 lbs
Back Style	Solid Back
Special Features	Adjustable Height, Ergonomic, Foot Rest, Massage, Reclining
Product Care Instructions	Wipe Clean
Recommended Uses	Gaming, Office
Material	PU and Carbon Fibre Leather, High-density Sponge
Reclining Angle	90° to 160°
Swivel	360-degree
Item Weight	45.7 pounds

10. WARRANTY AND CUSTOMER SUPPORT

Vonesse is committed to customer satisfaction. Your CVN200 Gaming Chair comes with the following:

- **30-Day Replacement Policy:** If you encounter any issues within 30 days of purchase, a replacement may be provided.
- **1-Year Repair Service:** The chair is covered by a 1-year repair service for manufacturing defects.

For any questions, concerns, or to utilize your warranty, please contact Vonesse customer service. Our team is available to provide efficient and timely after-sales support.

You can visit the official Vonesse store for more information: [Vonesse Store](#)