

[Manuals.plus](#) /

› [JEDELEOS](#) /

› JEDELEOS Replacement Belts Instruction Manual

JEDELEOS 40201160

Instruction Manual

JEDELEOS REPLACEMENT BELTS FOR DIRT DEVIL STYLE 19

Model: 40201160

Product Overview

This manual provides instructions for the JEDELEOS Replacement Belts, designed for various Dirt Devil Total Pet Upright Vacuum models. These belts are essential components for maintaining the optimal performance of your vacuum cleaner's brush roll system.



Image: JEDELEOS Replacement Belts for Dirt Devil Style 19, showing two belts and a compatible vacuum cleaner.

Key Features:

- **Broad Compatibility:** Designed to fit Dirt Devil Aspire, FeatherLite, Dynamite Supreme, Total Pet, and Total Power upright vacuum models UD40000, UD40005, UD40270, UD40285, UD40350, UD70210, UD70212 Series, replacing Part 1LV1000000.
- **Durable Material:** Made from elastic rubber for long-lasting reliability and powerful vacuuming.
- **Easy Replacement:** Simple process to remove and install, restoring vacuum functionality.



Image: Infographic highlighting the high-quality, ease of replacement, durability, efficiency, and non-toxic nature of the belts.

Compatibility

These replacement belts are compatible with the following Dirt Devil upright vacuum cleaner models:

Dirt Devil Total Pet Upright Vacuum UD40000
Dirt Devil Total Pet Upright Vacuum UD40005
Dirt Devil Total Pet Upright Vacuum UD40270
Dirt Devil Total Pet Upright Vacuum UD40285
Dirt Devil Total Pet Upright Vacuum UD40350
Dirt Devil Total Pet Upright Vacuum UD70210
Dirt Devil Total Pet Upright Vacuum UD70212 Series

They replace Dirt Devil Part Number 1LV1000000.

UNIVERSAL COMPATIBILITY



For Dirt Devil Total Pet Upright Vacuum Cleaner

Model UD40000 UD40005 UD40270 UD40285 UD40350 UD70210 UD70212



*The display of the vacuum cleaners is only to illustrate the compatibility of the belts.

Image: Visual representation of universal compatibility with various Dirt Devil vacuum models.

Installation Instructions

Replacing the vacuum belt is a straightforward process. Follow these steps to install your new JEDELEOS replacement belt:


1. **Prepare the Vacuum:** Ensure the vacuum cleaner is unplugged from the power outlet before beginning any maintenance or installation.
2. **Access the Brush Roll:** Lay the vacuum cleaner down and locate the brush roll cover on the bottom of the vacuum head. You may need a screwdriver to remove screws securing the cover.
3. **Remove Old Belt:** Carefully remove the worn or broken belt from the brush roll and motor shaft. Note how the old belt was positioned.
4. **Clean Area:** While the brush roll is accessible, clean any accumulated hair, debris, or dust from the brush roll and belt pathway.
5. **Install New Belt:** Place the new JEDELEOS belt around the motor shaft and then stretch it around the brush roll.

Ensure the belt is properly seated in the grooves on both the motor shaft and the brush roll.

6. **Reassemble:** Reattach the brush roll cover and secure it with screws if applicable.

7. **Test:** Plug in the vacuum cleaner and test its operation to ensure the new belt is functioning correctly.

EASY TO REPLACE



- **Simply remove the broken or worn belt in the vacuum.**
- **Replace the new belt according to the original installation position.**

✓ **Let's reactivate your vacuum cleaner!**

*The display of the vacuum cleaners is only to illustrate the compatibility of the belts.

Image: Step-by-step visual guide for easy belt replacement.

Maintenance Tips

To ensure the longevity and optimal performance of your vacuum cleaner and its new belt, consider the following maintenance tips:

- **Regular Replacement:** It is recommended to replace your vacuum cleaner belts every 3 to 9 months. This frequency can vary depending on usage and the type of surfaces cleaned. Regular replacement helps maintain strong suction and brush roll effectiveness.
- **Inspect for Wear:** Periodically inspect the belt for signs of wear, cracking, stretching, or fraying. A worn belt can lead to reduced cleaning performance.

- **Clear Obstructions:** Before and after vacuuming, check the brush roll for tangled hair, strings, or other debris that could put strain on the belt and motor.



Image: Reminder to replace vacuum belts every 3 to 9 months for optimal performance.

Troubleshooting

If you encounter issues after replacing your vacuum belt, consider the following common troubleshooting steps:

- **Brush Roll Not Spinning:**
 - Ensure the belt is correctly installed and not twisted.
 - Check for any obstructions (e.g., large debris, tangled hair) preventing the brush roll from turning freely.
 - Verify the brush roll itself is not damaged or jammed.
- **New Belt Breaks Quickly:**
 - This can indicate an underlying issue with the vacuum cleaner, such as a seized brush roll bearing or a motor

issue.

- Ensure the brush roll spins freely by hand when the belt is removed. If it's stiff, the brush roll or its bearings may need replacement.
- Confirm you are using the correct belt style and size for your specific vacuum model.

- **Reduced Suction:**

- While a new belt helps brush roll performance, reduced suction can also be due to a full dustbin, clogged filters, or blockages in the hose or air pathways. Check these components as well.

Specifications

Brand	JEDELEOS
Model Number	40201160
Material	Rubber
Belt Style	Flat Belt
Color	Black
Compatible Devices	Dirt Devil Total Pet Upright Vacuum UD40000, UD40005, UD40270, UD40285, UD40350, UD70210, UD70212 Series
Package Dimensions	4.61 x 2.99 x 0.67 inches
Item Weight	0.63 ounces

What's in the Box

Each package contains:

- 2 x Replacement Belts for Dirt Devil Style 19

PACKAGE LIST



Image: Contents of the package, showing two replacement belts.

© 2024 JEDELEOS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09TJJNGP7>

More documents and user manuals: <https://manuals.plus/>