

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [ROCWARE](#) /
- › [ROCWARE RC08 2K Webcam with Speaker Instruction Manual](#)

ROCWARE RC08

ROCWARE RC08 2K Webcam with Speaker Instruction Manual

MODEL: RC08



Image of the ROCWARE RC08 2K Webcam with Speaker, showcasing its sleek design and integrated stand.

Introduction

The ROCWARE RC08 2K Webcam with Speaker is an advanced all-in-one communication device designed for high-quality video conferencing, streaming, and online education. It integrates a high-resolution camera, noise-canceling microphone, and a Harman-tuned speaker into a single, compact unit, offering a seamless and professional user experience.

Key Features

- **3A Noise-Canceling Mic & Harman Tuned Full-Range Speaker:** Advanced noise-reduction technology for clear audio pickup and a built-in Harman speaker for clear sound output.
- **0.2S Fast ToF Auto-Focus & Landscape/Portrait Mode:** Rapid auto-focus ensures sharp images even in low light. Supports both landscape and portrait orientations for versatile use.
- **Ultra 1080P Full HD & Built-In Privacy Cover:** Delivers superior video quality for professional communication and content creation. Integrated privacy cover for enhanced security.
- **Low-Light Correction & 4X EPTZ Zoom Features:** Maintains high-quality video in challenging lighting conditions with electronic pan, tilt, and 4x digital zoom capabilities.
- **Plug-and-Play and Widely Compatible:** Easy setup with laptops, desktops, Macs, and LCD monitors. Compatible with Windows XP (SP2/SP3), Windows Vista/7/8/10/11, and Mac OS.

INNOVATIVE 3 IN 1 WEBCAM

3A



2K HD

0.2S TOF Focus

3A Microphone

2W Hi-Fi Speaker



1080P HD

Auto Focus

Normal Microphone

No speaker



720P HD


Auto Focus

Normal Microphone

No speaker



Visual representation of the ROCWARE RC08's integrated 3-in-1 features: 2K HD video, 0.2S ToF focus, 3A microphone, and 2W Hi-Fi speaker.



A collage illustrating key features including 2K HD video, ToF laser focus, 2W stereo speaker, 3A noise-cancelling microphone, horizontal/vertical view switch, and 360-degree rotatable base.

Setup Guide

The ROCWARE RC08 webcam is designed for easy plug-and-play setup. Simply connect the USB-C cable from the webcam to a compatible USB-A port on your computer. The device will be automatically recognized by your operating system without requiring additional driver installation.

Official product video demonstrating the simple USB plug-and-play setup of the ROCWARE RC08 webcam, highlighting its integrated microphone and speaker for an all-in-one solution.

Operating Instructions

Once connected, the webcam is ready for use with your preferred video conferencing or streaming software. The 0.2S ToF auto-focus system will automatically adjust for clear images. The 3A noise-canceling microphone ensures your voice is heard clearly, while the Harman-tuned speaker provides excellent audio output.

- **Privacy Cover:** Slide the integrated cover over the lens when not in use to ensure privacy.
- **Landscape/Portrait Mode:** The webcam supports switching between landscape and portrait modes to suit different platform requirements. Refer to the product manual for specific instructions on how to activate this feature.
- **4X EPTZ Zoom:** Utilize the electronic pan, tilt, and zoom features through compatible software for flexible framing.

Demonstration of switching the ROCWARE RC08 webcam to portrait mode, showcasing its versatility for different video content needs.



Close-up view of the integrated sliding privacy cover on the ROCWARE RC08 webcam, emphasizing ease of use and enhanced privacy.

Maintenance

To ensure the longevity and optimal performance of your ROCWARE RC08 webcam, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the lens and body with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the webcam in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Handling:** Handle the device with care to prevent physical damage. Avoid dropping or subjecting it to strong impacts.

Troubleshooting

If you encounter issues with your ROCWARE RC08 webcam, consider the following:

- **No Video/Audio:** Ensure the USB cable is securely connected to both the webcam and your computer. Try a different USB port. Verify that the webcam is selected as the input device in your video conferencing software settings.
- **Blurred Image:** The ToF auto-focus should handle this automatically. Ensure the lens is clean and free from obstructions.
- **Poor Audio Quality:** Check your software's audio input settings to ensure the webcam's microphone is selected. Ensure the microphone is not muted. The 3A noise reduction should minimize background noise.
- **Intermittent Connectivity:** Try restarting your computer. Ensure no other applications are conflicting with the webcam's operation.

Technical Specifications

Feature	Detail
Brand	ROCWARE
Model Number	RC08
Item Weight	8.8 ounces
Product Dimensions	4.06 x 1.06 x 1.18 inches
Video Capture Resolution	1080p (Full HD)
Special Features	Microphone Input, Speakers, Low Light
Connectivity Technology	USB

Warranty and Support

The ROCWARE RC08 Webcam with Speaker comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions regarding coverage and duration.

For technical support, troubleshooting assistance, or warranty claims, please contact ROCWARE customer service directly. Contact information can typically be found on the product packaging, the quick start guide, or the official ROCWARE website.