

- [Manuals.plus](#) /
- › [Armocity](#) /
 - › Armocity Music Studio Desk Production Workstation - Instruction Manual

Armocity SD

Armocity Music Studio Desk Production Workstation -
Instruction Manual

Model: SD

PRODUCT OVERVIEW

The Armocity Music Studio Desk is a versatile production workstation designed for music producers, home studio enthusiasts, and anyone requiring an organized and functional workspace. This desk features a multi-tiered design, integrated power solutions, and a sturdy construction to support various studio equipment.



The Armocity Music Studio Desk in a typical setup, showcasing its multi-level design and ample space for equipment.

KEY FEATURES

- **Integrated Power Outlet:** Equipped with 3 USB ports and 2 AC outlets (120V/12A, 5V/2.1A) for convenient charging and powering of studio equipment.
- **Spacious Work Area:** Features a raised monitor shelf (47.3" L x 7.9" W), a main desktop (47.3" L x 19.5" W), and a pull-out keyboard tray (20.9" L x 11.8" W) to accommodate multiple devices.
- **Ergonomic Design:** The raised monitor shelf positions screens at eye level to help reduce neck strain during extended use.
- **Robust Construction:** Built with solid metal Z-shaped legs and a brace bar for enhanced stability and durability.
- **Cable Management:** Includes Velcro tape to help organize and secure cables, maintaining a tidy workspace.



Detailed view of the desk's integrated power outlets, cable management, pull-out keyboard tray, sturdy metal frame, and raised monitor shelf.

Official product video demonstrating the features and assembly of the Armocity 47" Music Studio Desk with Power Outlet.

SETUP AND ASSEMBLY

The Armocity Music Studio Desk is designed for straightforward assembly. All necessary parts are labeled, and detailed instructions are included in the packaging. An electric screwdriver can expedite the process.

Assembly Steps

1. **Unpack and Verify:** Carefully unpack all components and compare them against the parts list provided in your instruction manual to ensure all pieces are present.
2. **Assemble Frame:** Construct the main frame structure by attaching the Z-shaped metal legs and brace bars using the provided screws and tools.
3. **Attach Desktop and Shelf:** Secure the main desktop to the assembled frame, followed by the raised monitor shelf.

4. **Install Keyboard Tray:** Mount the pull-out keyboard tray slides and attach the tray itself underneath the main desktop.
5. **Connect Power Unit:** Integrate the built-in power outlet unit into its designated slot on the desktop and connect its main power cord.
6. **Cable Management:** Use the included Velcro tape to organize and secure any loose cables, ensuring a neat and safe setup.



Detailed dimensions of the desk components, including the monitor shelf, main desktop, and keyboard tray.

OPERATING INSTRUCTIONS

Power Outlets and USB Ports

The desk features a built-in power strip with 2 AC outlets and 3 USB ports, providing convenient power access for your electronic devices.

- **Main Power Connection:** Plug the desk's main power cord into a functional, grounded wall outlet.
- **AC Device Connection:** Connect your monitors, laptops, audio interfaces, and other AC-powered devices to the 120V/12A AC outlets.
- **USB Device Charging:** Use the 5V/2.1A USB ports to charge smaller devices such as smartphones, tablets, or USB-powered controllers.

Keyboard Tray Usage

The pull-out keyboard tray offers a dedicated space for your keyboard and mouse, helping to keep your main desktop clear.

- **Extend Tray:** Gently pull the tray forward to access your keyboard and mouse.

- **Retract Tray:** Push the tray back underneath the desktop when not in use to save space and maintain a clean look.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Armocity Music Studio Desk.

- **Cleaning Surfaces:** Wipe all desk surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Organization:** Periodically check and re-organize cables using the provided Velcro tape to prevent tangles, strain, and potential damage to wires or ports.
- **Hardware Inspection:** Regularly inspect all screws and connections to ensure they remain tight. Re-tighten any loose hardware as needed.
- **Weight Distribution:** Distribute the weight of your equipment evenly across the desktop and shelves. Avoid placing excessive weight on any single point, especially the monitor shelf and keyboard tray, to prevent structural stress.

TROUBLESHOOTING

Power Outlets/USB Ports Not Functioning

- **Verify Main Power:** Ensure the desk's main power cord is securely plugged into a functional wall outlet. Test the wall outlet with another device to confirm it has power.
- **Reset Power:** Unplug the desk from the wall, wait approximately 30 seconds, then plug it back in. This can sometimes reset the internal power unit.
- **Test Devices:** Try plugging a different device into the outlets or USB ports to determine if the issue lies with the desk's power unit or the specific device you are trying to power/charge.
- **Avoid Overload:** Ensure you are not exceeding the maximum electrical capacity of the power strip (120V/12A for AC outlets, 5V/2.1A for USB ports).

Keyboard Tray Feels Unstable or Flimsy

- **Check Assembly:** Re-examine all screws and connections securing the keyboard tray slides and the tray itself. Tighten any loose hardware.
- **Weight Limit:** The keyboard tray is designed for standard keyboards and mice. Avoid placing heavy items or applying excessive downward pressure, as this can affect its stability.

SPECIFICATIONS

Brand	Armocity
Model Number	SD
Product Dimensions (Overall)	22.8"D x 47.3"W x 40"H
Color	White
Style	Studio Desk with Outlet
Base Material	Metal
Top Material Type	Engineered Wood
Monitor Shelf Dimension	47.3" (Length) x 7.9" (Width)

Main Desktop Dimension	47.3" (Length) x 19.5" (Width)
Keyboard Tray Dimension	20.9" (Length) x 11.8" (Width)
Height from Monitor Shelf	40"
Height from Main Desktop	29.5"
Power Outlet (AC)	2 x 120V/12A
USB Ports	3 x 5V/2.1A
Maximum Weight Recommendation	16.78 Kilograms (approx. 37 lbs)
Required Assembly	Yes
Recommended Number of People for Assembly	2

WARRANTY INFORMATION

The Armocity Music Studio Desk is covered by a **2-year manufacturer's limited warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for any warranty claims. For detailed terms and conditions, or to initiate a warranty claim, please refer to the warranty documentation included with your product or contact Armocity customer support.

CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or encounter any issues with your Armocity Music Studio Desk, please do not hesitate to contact our customer support team.

- **Contact Information:** Please refer to the contact details provided in your product packaging or visit the official Armocity website for the most up-to-date support options.
- **Response Time:** Armocity is committed to responding to inquiries within 24 hours.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09TN6NPJW>

More documents and user manuals: <https://manuals.plus/>