

[Manuals.plus](#) /

› [Consfly](#) /

› Consfly Mini Soy Milk Maker User Manual - Model B09TN8D8SZ

Consfly B09TN8D8SZ

Consfly Mini Soy Milk Maker User Manual

Model: B09TN8D8SZ

INTRODUCTION

Thank you for choosing the Consfly Mini Soy Milk Maker. This appliance is designed for convenient preparation of soy milk, rice paste, corn juice, and other beverages. Please read this manual thoroughly before operating the device to ensure safe and efficient use.



Image: Front view of the Consfly Mini Soy Milk Maker, showcasing its compact design.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use.
- Ensure the voltage matches your power supply (110V).
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children.
- Always ensure the cover is correctly placed before operation. The machine will not work if the cover is misplaced.
- Avoid contact with moving parts during operation.

- Use only manufacturer-recommended attachments.
- Unplug from outlet when not in use and before cleaning.
- This appliance is not dishwasher safe. Hand wash only.

PRODUCT OVERVIEW AND FEATURES

The Consfly Mini Soy Milk Maker features a compact design with multiple functions for preparing various beverages. It includes a durable inner layer and an anti-scalding outer layer for safety.

Anti-scalding & heat preservation

- 1 Outer layer | Anti-scalding surface**
Heat insulation and scalding to avoid accidental scalding
- 2 Inner layer | 304 stainless steel**
Even heat conduction, more mellow taste



Image: Diagram illustrating the anti-scalding outer layer and 304 stainless steel inner layer for heat insulation and even heat conduction. The appliance is equipped with a four-bladed fine steel head for efficient blending, utilizing 4D spoiler technology to ensure thorough mixing at 27200 revolutions per minute.

CONSFLY

FOUR LEAF BLADE



Four-bladed
fine steel head



4D spoiler
technology



27200r/min



Image: Close-up view of the four-bladed fine steel head and the blending action inside the machine.

SPECIFICATIONS

Parameter	Value
Product Name	Mini Soy Milk Maker
Brand	Consfly
Model	B09TN8D8SZ

Parameter	Value
Voltage	110V
Capacity	350ML
Heating Power	500W
Stirring/Mixing Power	100W
Motor Speed	27200r/min
Heating Method	Base heating
Net Weight	1kg
Recommended Users	1-2 people
Special Feature	Portable
Product Care	Hand Wash Only

CONSFLY

PARAMETERS

Rated power

350ml

Motor speed

27200r/min

Rated voltage

110V

Mixing power

100W

Heating power

500W

Heating method

Heat at the bottom

Net weight

1KG

Applicable number

1-2 people



9.4in

5.5in

Image: Visual representation of the product's key parameters and dimensions.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the inner pot and lid with warm soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the appliance on a stable, flat, and heat-resistant surface.
4. **Power Connection:** Ensure the appliance is unplugged before adding ingredients. Once ingredients are added and the lid is securely in place, connect the power cord to a 110V electrical outlet.

OPERATING INSTRUCTIONS

The Consfly Mini Soy Milk Maker offers six functions: Soybean Milk, Cleaning, Rice Paste, Boil Water, Corn Juice, and Juice. Select the desired function using the control button on the front of the unit.

Six functions

One machine to get a variety of delicious, with automatic cleaning function, convenient and fast



Image: The control panel displaying the six available functions: Soybean Milk, Cleaning, Rice Paste, Boil Water, Corn Juice, and Juice.

General Operation Steps:

1. Add desired ingredients and water to the inner pot, ensuring not to exceed the maximum fill line.
2. Place the lid securely on the machine. Ensure it is correctly aligned; the machine will not operate if the lid is misplaced.

3. Plug the appliance into a 110V power outlet.
4. Press the control button to cycle through the functions and select your desired program.
5. The machine will begin operation. Once the program is complete, the machine will typically beep or indicate completion.
6. Unplug the appliance and carefully pour out the contents. Be cautious as the contents and internal parts will be hot.

Approximate Working Times:

- **Boil Water:** Approximately 4 minutes
- **Rice Paste:** Approximately 16 minutes
- **Corn Juice:** Approximately 12 minutes
- **Soy Milk:** Approximately 21 minutes



Image: Icons and text indicating the approximate processing times for boiling water, making rice paste, corn juice, and soy milk.

Examples of Beverages:

The machine can produce a variety of healthy drinks and pastes, including corn juice, soy milk, mung bean soy milk, pumpkin paste, and rice paste.



Image: A display of various beverages and pastes such as corn juice, soy milk, mung bean soy milk, pumpkin paste, and rice paste.

CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your Consfly Mini Soy Milk Maker.

Cleaning Steps:

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **One-Button Cleaning:** For convenient cleaning, add a small amount of water to the inner pot and select the "Cleaning" function. This will help rinse the interior.
3. **Manual Cleaning:** After the cleaning cycle or for thorough cleaning, carefully remove the lid. Wash the inner pot and lid with warm, soapy water using a soft brush or sponge. Rinse thoroughly.
4. **Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
5. **Drying:** Ensure all parts are completely dry before storing or next use.

Important: The appliance is *not* dishwasher safe. Hand wash only.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not start	Lid is not correctly placed. Appliance is not plugged in.	Ensure the cover is securely and correctly aligned on the machine. Check power connection to a 110V outlet.
Poor blending results (e.g., clumps)	Insufficient water or incorrect ingredient ratio. Ingredients not properly prepared (e.g., soaked).	Refer to recipes for recommended ingredient-to-water ratios. Ensure ingredients are pre-soaked if required for specific recipes (e.g., soybeans).
Unusual noise during operation	Overfilling the machine. Foreign object inside.	Do not exceed the maximum fill line. Unplug and inspect the inner pot for any foreign objects.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact Consfly customer service through your retailer. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question