

manuals.plus /

- › [Anker](#) /
- › [Anker 335 Wireless Charger \(A2598\) Instruction Manual](#)

Anker A2598

Anker 335 Wireless Charger (A2598) Instruction Manual

Foldable 3-in-1 Charging Station for iPhone, AirPods, and Apple Watch

1. INTRODUCTION

Thank you for choosing the Anker 335 Wireless Charger, Model A2598. This foldable 3-in-1 charging station is designed to conveniently power your iPhone, true wireless earbuds, and Apple Watch simultaneously. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and safety.

2. PRODUCT OVERVIEW

The Anker 335 Wireless Charger offers a compact and convenient solution for charging multiple devices. It features a foldable design for portability and an adjustable phone charging surface for optimal viewing angles.

3-in-1 Charging Station



Image: The Anker 335 Wireless Charger in use, charging an iPhone, AirPods, and Apple Watch.

Key Features:

- **3-in-1 Charging:** Simultaneously charges your phone, true wireless earbuds, and Apple Watch (Apple Watch charging cable not included).
- **Adjustable Phone Stand:** The phone's charging surface can be adjusted to 54° or 60° for comfortable viewing.
- **Foldable Design:** Compact and space-saving, ideal for travel.

- **Fast Charging:** Provides up to 7.5W max for iPhones, 10W max for Android phones, and 5W max for AirPods.
- **Safety Features:** Equipped with MultiProtect system including surge protection, short circuit prevention, and temperature control.
- **Sleep-Friendly LED:** Intuitive LED light indicates charging status and turns off after 3 seconds when an iPhone is charging for an undisturbed sleep environment.

3. WHAT'S IN THE BOX

- Anker 335 Wireless Charger (3-in-1 Station)
- 18W Quick Charge 3.0 Charger
- 5 ft (1.5 m) USB-A to USB-C charging cable
- Welcome Guide

4. SETUP INSTRUCTIONS

Follow these steps to set up your Anker 335 Wireless Charger:

1. **Connect Power Adapter:** Plug the provided 18W Quick Charge 3.0 Charger into a wall outlet and connect it to the Anker 335 Wireless Charger using the 5 ft (1.5 m) USB-A to USB-C charging cable.
2. **Install Apple Watch Charger (Not Included):**
 - Slide open the bottom cover of the charging station.
 - Thread your original Apple Watch USB-C charging cable (1 ft / 0.3 m or 3.3 ft / 1 m) through the designated hole.
 - Wrap the cable counterclockwise within the cable management channels.
 - Plug the USB-C end of your Apple Watch cable into the USB-C port inside the station.
 - Close the bottom cover securely.

Simple Setup

Use an original 1 ft (0.3 m) or 3.3 ft (1 m) USB-C charging cable to charge Apple Watch (not included).



Image: Detailed steps for installing the Apple Watch charging cable into the station's base.

5. OPERATING INSTRUCTIONS

Once set up, charging your devices is straightforward:

- **Charging Your Phone:** Place your phone on the adjustable stand. Ensure the phone's wireless charging coil is precisely aligned with the center of the upper or lower charging circle for optimized charging. The stand can be

adjusted to 54° or 60° for a comfortable viewing angle. Note: Use a phone case that is less than 5mm thick.

- **Charging Your Earbuds:** Place your true wireless earbuds (with a wireless charging case) on the flat charging pad.
- **Charging Your Apple Watch:** Place your Apple Watch on the installed charging module.

Adjust for the Perfect View



When charging with the stand flat, align your phone's wireless charging coil precisely on the center of the upper or lower circle for optimized charging.

Image: An iPhone charging on the adjustable stand, demonstrating the optimal viewing angle.

LED Indicator:

The intuitive LED light indicates the charging status. When your iPhone is charging, the LED will turn off after 3 seconds

to ensure a peaceful night's sleep. A blinking blue light indicates that something is not attached or charging properly.

6. COMPATIBILITY

The Anker 335 Wireless Charger is highly compatible with a range of devices:

Wide Compatibility

Phones:



iPhone 13 /
13 Pro Max



iPhone 13 mini
/ 13 Pro



iPhone 12 / 12
Pro Max



iPhone 12 mini
/ 12 Pro



iPhone 11 /
11 Pro Max



iPhone 11 Pro



Samsung
S20+ / S20



Samsung Note
10+ / Note 10



Google Pixel
4 / Pixel 4XL

Wireless Earbuds:



AirPods Pro



AirPods 2 (with wireless
charging case)



Samsung Galaxy
Buds Pro / Buds Live



Samsung Galaxy
Buds / Buds+

Apple Watch:



Apple Watch Series 7 /
Watch Series SE

Note: Use an original 1 ft (0.3 m) or 3.3 ft (1 m) USB-C charging cable to charge Apple Watch (not included).



Image: Visual representation of compatible devices including iPhones, AirPods, and Apple Watch models.

Phones:

- **10W Charging:** Samsung Note10+, 10, 9; Samsung S20+, S20, S20 Ultra, S10+, S10, S10e
- **7.5W Charging:** iPhone 13, 13 Pro Max, 12, 12 Pro, 12 Pro Max, 11 Pro, SE (2nd Generation), XS, XS Max, XR, X, 8, 8 Plus
- **5W Charging:** Google Pixel 6 Pro / 6 / 5 / 4 / 3 / 6XL / 5XL / 4XL / 3XL (Note: Phone's screen may display "Charging slowly"); LG V30, V30+, G7, V35, V40

Wireless Earbuds:

- AirPods (with a wireless charging case)
- AirPods Pro
- Samsung Galaxy Buds Pro / Buds Live / Buds+
- Other compatible earbuds with wireless charging cases.

Apple Watch:

- Apple Watch Series 7 / SE and earlier models.

Note: Not compatible with Samsung Watches.

7. ADVANCED SAFETY FEATURES

The Anker 335 Wireless Charger incorporates Anker's MultiProtect system to ensure safe and reliable charging for all your devices. This system includes:

Advanced Safety



Phone
Battery Safety



Radiation
Shielding



Foreign Object
Detection



Temperature
Control



Image: Visual representation of the charger's advanced safety mechanisms.

- **Phone Battery Safety:** Protects your phone's battery from overcharging and damage.
- **Radiation Shielding:** Minimizes electromagnetic radiation.
- **Foreign Object Detection:** Prevents charging when foreign metal objects are detected on the charging surface.
- **Temperature Control:** Regulates the charging temperature to prevent overheating.
- **Surge Protection:** Guards against power surges.

- **Short Circuit Prevention:** Protects against electrical shorts.

8. MAINTENANCE

To ensure the longevity and optimal performance of your Anker 335 Wireless Charger, follow these maintenance guidelines:

- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry cloth to wipe the surface. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, especially during travel, fold the charger flat to protect its components. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the charging cables excessively. Ensure the Apple Watch charging cable is properly routed within the internal channels to prevent damage.
- **Avoid Liquids:** Keep the charger away from water and other liquids.

9. TROUBLESHOOTING

If you encounter issues with your Anker 335 Wireless Charger, refer to the following common solutions:

- **Device Not Charging:**
 - Ensure the charger is properly connected to the power adapter and a working wall outlet.
 - Verify that your device (phone, earbuds, Apple Watch) is correctly placed and aligned on its respective charging area.
 - Check for any foreign objects (e.g., metal, coins) on the charging surface that might interfere with wireless charging.
 - If using a phone case, ensure it is less than 5mm thick. Thicker cases may prevent proper charging.
 - Restart your device and try again.
- **Blinking Blue LED Light:** A blinking blue LED light indicates that a device is not properly placed or there is a foreign object detected. Re-position your device or remove any obstructions.
- **Slow Charging:**
 - Ensure you are using the provided 18W Quick Charge 3.0 adapter and cable. Using a lower-power adapter may result in slower charging.
 - Confirm your device is compatible with the charger's fast charging capabilities.
 - Remove any thick phone cases.
- **Apple Watch Not Charging:** Ensure your original Apple Watch charging cable is securely plugged into the USB-C port inside the station and properly positioned in the module.

10. SPECIFICATIONS

Feature	Detail
Model Number	A2598
Input	9V 2A / 9V 3A
Wireless Output (Phones)	5W / 7.5W / 10W Max

Wireless Output (Earbuds)	5W Max
USB-C Output (Apple Watch)	5V=0.6A Max
Total USB Ports	1 (for internal Apple Watch cable)
Weight	0.89 Pounds
Material	Plastic
Color	Black
Special Feature	Travel, Foldable Design
Certification	Qi

11. WARRANTY AND CUSTOMER SUPPORT

Anker provides an 18-month warranty for this product. For any questions, issues, or support needs, please contact Anker's friendly customer service. Refer to the contact information provided in your product packaging or visit the official Anker website for assistance.

