

ASHATA B09TPN31RY

ASHATA Racing Wheel Instruction Manual

Model: B09TPN31RY

1. INTRODUCTION

Thank you for purchasing the ASHATA Racing Wheel. This manual provides essential information for setting up, operating, and maintaining your racing wheel. This device is designed to enhance your gaming experience on PlayStation 3, PlayStation 2, and PC platforms.

Please read this manual thoroughly before use to ensure proper functionality and to prevent damage to the product.



Image 1.1: The ASHATA Racing Wheel and pedal set, featuring a black steering wheel with blue accents and a separate black pedal unit.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Gaming Steering Wheel
- 1 x Pedal Unit
- 1 x Instruction Manual
- 1 x Driver CD (for PC installation)



Image 2.1: An illustration showing the included components: the racing wheel, pedal unit, instruction manual, and driver CD.

3. SETUP INSTRUCTIONS

Follow these steps to connect your ASHATA Racing Wheel to your gaming system:

1. **Connect the Pedal Unit:** Plug the cable from the pedal unit into the designated port on the racing wheel base.
2. **Connect to Console/PC:** Plug the USB cable from the racing wheel into an available USB port on your PlayStation 3, PlayStation 2, or PC.
3. **Power On:** Ensure your console or PC is powered on. The racing wheel should be automatically detected.
4. **PC Driver Installation (if necessary):** For PC use, if the device is not automatically recognized, insert the provided Driver CD and follow the on-screen instructions to install the necessary drivers.



Image 3.1: A visual representation of the racing wheel connected via USB to different gaming platforms, including Xbox, PlayStation, and a PC monitor.

4. OPERATING INSTRUCTIONS

The ASHATA Racing Wheel offers various features for an immersive racing experience:

- **Rotation Angle:** The steering wheel supports a rotation angle of up to 180 degrees (90 degrees left, 90 degrees right).
- **Control Buttons:** Features a D-pad and 10 independent fire buttons for comprehensive in-game control.
- **Gear Shift:** Utilize the integrated gear shift for manual transmission control in compatible games.

- **Foot Pedals:** The pedal unit includes spring-loaded acceleration and brake controls. In digital mode, these pedals function with analog sensitivity.
- **Vibration Feedback:** Built-in dual motors provide vibration effects, enhancing realism during gameplay.
- **Mode Selection:** The racing wheel supports digital, analog, and steering wheel modes. Refer to your game's settings for optimal configuration.




Image 4.1: The racing wheel with visual cues indicating the dual vibration effect, providing tactile feedback during gameplay.



Image 4.2: A close-up of the racing wheel and pedal unit, illustrating the foot pedal functionality and the 180-degree rotation capability of the steering wheel.

5. MAINTENANCE

To ensure the longevity and optimal performance of your ASHATA Racing Wheel, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the racing wheel and pedal unit. Avoid using abrasive cleaners or solvents, as these can damage the surface.
- **Storage:** When not in use, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or kinks in the cables. Do not pull on the cables to disconnect the device.

6. TROUBLESHOOTING

If you encounter issues with your ASHATA Racing Wheel, refer to the following common solutions:

- **Device Not Recognized:**

- Ensure all cables are securely connected.
- Try plugging the USB cable into a different port on your console or PC.
- For PC, verify that the drivers are correctly installed using the provided CD.
- Restart your console or PC.

- **No Vibration Feedback:**

- Check if the game you are playing supports vibration feedback.
- Ensure vibration settings are enabled within the game's options.
- Confirm the racing wheel is in a mode that supports vibration (e.g., analog or steering wheel mode).

- **Buttons or Pedals Not Responding:**

- Verify the device is properly connected and recognized by your system.
- Test the buttons and pedals in a different game or calibration utility (if available on PC).
- Ensure no debris is obstructing the movement of pedals or buttons.

7. SPECIFICATIONS

Item Type	Gaming Steering Wheel
Material	ABS
Compatibility	For PS3, for PS2, PC
Power Supply	USB Powered
Vibration Effect	Dual Vibration
Rotation Angle	180 Degrees (90° left, 90° right)
Controls	2 axes, D-pad, 10 independent fire buttons, gear shift, foot pedals
Product Dimensions	29 x 27 x 26 cm
Product Weight	1.84 kg

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.



[ASHATA 5 Keys Programmable Keypad: User Manual for USB-C and Bluetooth Dual Mode Operation](#)

Comprehensive user manual for the ASHATA 5 Keys Programmable Keypad, covering setup, custom key configuration via software, Bluetooth pairing, and operational features for USB-C and wireless dual-mode use.