

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sunbeam](#) /

› [Sunbeam Travel Steam Iron User Manual](#)

## Sunbeam 32610033

# Sunbeam Travel Steam Iron User Manual

Model: 32610033

Brand: Sunbeam

## 1. INTRODUCTION

---

The Sunbeam Travel Steam Iron is a compact and portable appliance designed for efficient wrinkle removal at home or while traveling. Its dual voltage capability makes it suitable for international use, and its powerful Shot of Steam feature allows for both horizontal and vertical steaming. With its non-stick soleplate and soft-touch handle, ironing becomes a comfortable and effective task.



Image: The Sunbeam Travel Steam Iron, showcasing its compact and ergonomic design.

## 2. SAFETY INFORMATION

---

- Always unplug the iron from the electrical outlet when filling with water, emptying, or when not in use.
- Do not immerse the iron in water or other liquids.
- Keep the iron out of reach of children.
- Use the iron only for its intended household use as described in this manual.
- Ensure the voltage selector switch is set to the correct voltage (120V or 240V) for the region you are in before plugging in.
- Never touch the hot soleplate. Allow the iron to cool completely before storing.

## 3. PRODUCT FEATURES

---

- **1080 Watt Power:** Provides quick heating and efficient performance.
- **Dual Voltage (120V/240V):** Ideal for international travel with a convenient selector switch.
- **Compact and Portable:** Lightweight at 1.2 pounds, designed for easy packing. Includes a travel bag.
- **Powerful Shot of Steam:** Delivers a burst of steam for stubborn wrinkles, usable horizontally or vertically.
- **Non-Stick Soleplate:** Glides smoothly over various fabric types, preventing sticking and scorching.

- **Soft Touch Handle:** Ergonomically designed for comfortable grip and control.
- **Fabric Select Dial:** Allows precise temperature control for different fabrics like linen, cotton, silk, and wool.



Image: Underside of the iron showing the non-stick soleplate and the 120V/240V dual voltage selector switch.



## EASY-FILL WATER TANK

Image: Easy-fill water tank for steam function.

### 4. SETUP

---

1. **Voltage Selection:** Locate the voltage selector switch on the back of the iron. Use a coin or screwdriver to set it to the correct voltage for your region (120V for North America, 240V for most other countries).
2. **Filling Water Tank (for Steam Ironing):** Ensure the iron is unplugged. Open the water fill cover located on top of the iron. Using a measuring cup, carefully pour distilled or tap water into the reservoir up to the 'MAX' fill line. Close the cover securely.
3. **Power Connection:** Plug the iron's 8-foot power cord into a suitable electrical outlet. The indicator light will illuminate, signaling that the iron is heating up.

### 5. OPERATING INSTRUCTIONS

---

1. **Temperature Control:** Rotate the Fabric Select dial to choose the appropriate temperature setting for your fabric type (e.g., Linen, Cotton, Silk, Wool). Allow a few minutes for the iron to reach the desired temperature.
2. **Steam Function:** For steam ironing, ensure the water tank is filled. Once the iron reaches the set temperature, press the 'Shot of Steam' button located on the handle to release a powerful

burst of steam. This is ideal for stubborn wrinkles.

3. **Dry Ironing:** To iron without steam, simply do not fill the water tank. Select the desired temperature setting and proceed with ironing.
4. **Vertical Steaming:** The Shot of Steam feature can also be used vertically. Hold the iron upright, close to hanging garments, upholstery, or drapery, and press the steam button to release steam and relax wrinkles.



## FABRIC TEMPERATURE SELECT

Image: Ironing a shirt, highlighting the fabric temperature select dial.



Image: Demonstrating the powerful Shot of Steam feature for vertical use.

## 6. MAINTENANCE

---

- **Cleaning the Soleplate:** To clean the non-stick soleplate, wipe it with a damp cloth after the iron has cooled down. Do not use abrasive cleaners or scouring pads.
- **Draining Water:** After each use, ensure the iron is unplugged and cooled. Empty any remaining water from the reservoir to prevent mineral buildup.
- **Storage:** Wrap the power cord neatly around the iron. Store the iron in its included travel bag in a dry, safe place.

## 7. TROUBLESHOOTING

---

| Problem          | Possible Cause   | Solution  |
|------------------|--|---|
| Iron not heating | Not plugged in; incorrect voltage setting; power outage. | Check power connection; verify voltage switch; check circuit breaker. |

| Problem       | Possible Cause  | Solution   |
|---------------|---|--|
| No steam      | Water tank empty; temperature too low; steam vents clogged. | Fill water tank; set to higher temperature; clean steam vents. |
| Water leaking | Overfilled water tank; temperature too low for steam.       | Do not overfill; ensure iron is hot enough before using steam. |

## 8. SPECIFICATIONS

---

- **Brand:** Sunbeam
- **Model Name:** 32610033
- **Wattage:** 1080W
- **Voltage:** Dual Voltage (120V/240V)
- **Product Dimensions:** 6.53"L x 3.96"W
- **Item Weight:** 1.67 pounds
- **Base Material:** Stainless Steel
- **Special Feature:** Manual

## 9. WARRANTY & SUPPORT

---

For detailed warranty information, product registration, and customer support, please refer to the official Sunbeam website or download the complete User Manual PDF.

[Download User Manual \(PDF\)](#)