

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [iJoy](#) /

> iJoy Disney AirTag Wristband (Model DWB) Instruction Manual

## iJoy DWB

# iJoy Disney AirTag Wristband (Model DWB) Instruction Manual

Your guide to setting up, using, and maintaining your AirTag wristband.

## INTRODUCTION

This manual provides essential instructions for the iJoy Disney AirTag Wristband, Model DWB. This product is designed to securely hold an Apple AirTag, allowing it to be worn on the wrist or attached to other items for tracking purposes. Please read these instructions carefully before use.

**Important:** An Apple AirTag is not included with this product and must be purchased separately.

## PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x iJoy Disney AirTag Silicone Wristband

*Note: Apple AirTag is sold separately.*

## SETUP AND INSTALLATION

### 1. Inserting the Apple AirTag

1. Locate the circular opening on the wristband designed for the AirTag.
2. Gently push the Apple AirTag into the circular opening until it is fully seated and secure. Ensure the AirTag is flush with the surface of the wristband to prevent it from falling out.



*Image: Two iJoy Disney AirTag wristbands, blue and purple, illustrating the circular slot where the AirTag is inserted.*

## **2. Wearing the Wristband**

The wristband is designed for universal fit and adjustability. To wear:

1. Wrap the wristband around the wearer's wrist.
2. Insert the tang buckle through the appropriate hole to secure the band. Ensure a snug but comfortable fit.
3. The wristband is adjustable to fit wrists from approximately 4.5 inches to 6.9 inches in circumference.

**SECURE AND PROTECT YOUR APPLE AIRTAG**  
**ADJUSTABLE, SOFT AND DURABLE, SECURE GRIP**



*Image: Wristband sizing guide showing minimum and maximum wrist circumference for proper fit.*



*Image: Example of the wristband being worn by a child.*

### 3. Looping to Other Items

The wristband can also be looped onto items such as backpacks or luggage. Secure the band using the tang buckle mechanism around a strap or handle.

## OPERATION WITH APPLE AIRTAG

Once your Apple AirTag is securely placed within the iJoy Disney AirTag Wristband, its functionality remains unchanged. You can use the Find My app on your Apple device to track the AirTag and, by extension, the wearer or item it is attached to.

- **Precision Finding:** For supported iPhone models, Precision Finding can guide you to the exact location of your AirTag when it's nearby.
- **Lost Mode:** If the AirTag is far away, you can place it in Lost Mode to be notified when it's detected by another device in the Find My network.



Image: iPhone screen showing the Find My app interface for tracking items.

# LOOP AND LINK

## KEEP EVERYONE SAFE AND STYLISH



Official © Disney Product

*Image: iPhone screen demonstrating the Precision Finding feature of the Find My app.*

### CARE AND MAINTENANCE

To ensure the longevity and cleanliness of your iJoy Disney AirTag Wristband:

- **Cleaning:** Wipe the silicone band with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and air drying.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the silicone material and printed designs.
- **Storage:** Store the wristband in a cool, dry place away from direct sunlight when not in use.

### TROUBLESHOOTING

- **AirTag falls out of the band:**

Ensure the AirTag is fully seated and flush within the circular opening. Apply gentle pressure around the edges to confirm it is securely in place. If the AirTag consistently falls out, inspect the band for any damage or stretching around the AirTag slot.

- **Wristband does not fit securely:**

Verify that the tang buckle is inserted into the smallest possible hole that still allows for a comfortable fit. If the wristband is too large for the wearer's wrist (e.g., for very small children), it may not provide a secure fit and could come off easily. The band is designed for wrists between 4.5 and 6.9 inches in circumference.

- **Band appears damaged or broken:**

Discontinue use if the band shows signs of significant wear, tearing, or if the AirTag securing mechanism is compromised. Refer to the Warranty Information section for details on product replacement.

## SPECIFICATIONS

Feature	Detail
Model Number	DWB
Material	Silicone
Clasp Type	Tang Buckle
Compatible Devices	Apple AirTag
Product Dimensions	10 x 0.1 x 0.5 inches (approximate length when laid flat)
Item Weight	3.53 ounces
Adjustable Features	Adjustable length for wrist circumference (approx. 4.5" - 6.9"), Durable, Scratch Resistant
Manufacturer	Quest USA Corp

## WARRANTY AND SUPPORT

### Warranty Information

This iJoy product is covered by a 90-day warranty from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, or normal wear and tear.

### Customer Support

For warranty claims, technical assistance, or any questions regarding your iJoy Disney AirTag Wristband, please contact the manufacturer, Quest USA Corp, or the retailer where the product was purchased. Please have your proof of purchase and product model number (DWB) ready when

contacting support.