

## GREECHO FS01

# GREECHO FS01 Electric Fondue Pot Set User Manual

Model: FS01

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before using the GREECHO FS01 Electric Fondue Pot Set.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the heating base, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- **Important Note:** Fondue ingredients (Chocolate, Cheese, or Broth) should be prepared on the stovetop

for first use of the stainless steel fondue pot. Do not overfill the fondue pot to avoid spillage or damage (maximum liquid quantity of 1.5L).

- It is recommended to preheat the heating plate for 2-5 minutes, depending on the fondue type, before placing the pot.

## 2. PRODUCT OVERVIEW

---

The GREECHO FS01 Electric Fondue Pot Set is designed for versatile fondue experiences, offering three preset modes and precise temperature control. It features a 2.6 Qt capacity stainless steel pot, a detachable heating base, and six color-coded forks.



Image: The GREECHO FS01 Electric Fondue Pot Set, showcasing the orange pot, black heating base with controls, and six fondue forks. A cheese fondue is visible in the pot, with various dipping items in the background.

### Components:

- **Stainless Steel Fondue Pot:** 2.6 Qt capacity, 304 stainless steel construction, detachable from the base.
- **Heating Base:** Features digital controls, 1200W power, and preset modes.
- **Splatter Guard:** Sits on top of the pot, designed to prevent splashes and hold fondue forks.

- **Color-Coded Fondue Forks:** Six forks for individual use, with distinct colors for identification.
- **Power Cord:** For connecting the appliance to an electrical outlet.

## Key Features:

- **3 Preset Modes:** Dedicated settings for Cheese, Chocolate, and Broth fondue.
- **Digital Temperature Control:** Offers precise temperature management for consistent results, including sous vide capability.
- **Detachable Pot:** The stainless steel pot can be separated from the heating base for stovetop use and easy cleaning.
- **2.6 Qt Capacity:** Suitable for serving up to 6 people.
- **304 Stainless Steel:** Durable and easy to clean, with a thickened pot body and bottom.



Image: An illustration showing the fondue pot detached from its heating base, highlighting the 2mm fence around the base designed to prevent the pot from moving during use.

## Multiple Applicable Scenarios



Image: A close-up view of the fondue pot with the removable hot splash protection ring in place, demonstrating how it holds the color-coded fondue forks and prevents splashes.

## 3. SETUP AND ASSEMBLY

Follow these steps to set up your GREECHO Electric Fondue Pot Set for first use:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or

transport.

2. **Initial Cleaning:** Before first use, wash the stainless steel fondue pot, splatter guard, and fondue forks with warm, soapy water. Rinse thoroughly and dry completely. Wipe the heating base with a damp cloth. Do not immerse the heating base in water.
3. **Assemble:** Place the heating base on a stable, heat-resistant, and dry surface. Ensure the power cord is not obstructing walkways.
4. Place the clean fondue pot onto the heating base. Ensure it is seated securely within the 2mm fence on the base.
5. Place the splatter guard onto the rim of the fondue pot.
6. Insert the power plug into a standard electrical outlet. The appliance is now ready for use.

## 4. OPERATING INSTRUCTIONS

The GREECHO FS01 offers three preset modes for optimal fondue preparation. Always ensure the fondue pot is securely placed on the heating base before operation.

### Using Preset Modes:



Image: A visual representation of the three preset modes (Chocolate, Cheese, Broth) with their respective temperature ranges and examples of fondue preparation.

1. **Power On:** Press the power button (**U**) on the heating base to turn on the appliance.
2. **Select Mode:** Choose your desired fondue mode by pressing the corresponding button: **Chocolate**, **Cheese**, or **Broth**. The selected mode indicator will illuminate.
3. **Preheat:** Allow the heating plate to preheat for 2-5 minutes before adding ingredients to the pot. This ensures efficient heating.
4. **Add Ingredients:** For best results, pre-melt cheese or chocolate on a stovetop in the fondue pot before transferring it to the electric base. For broth, add liquid and desired ingredients directly. Ensure the liquid level does not exceed the 1.5L maximum fill line.
5. **Temperature Adjustment:** While in a preset mode, you can fine-tune the temperature using the **+** and **-** buttons. The digital display will show the current temperature setting.
6. **Serving:** Use the color-coded fondue forks to dip food items into the fondue. The splatter guard helps prevent splashes and keeps forks organized.

# MORE PRECISE DIGITAL TEMP CONTROL

Even For Sous Vide

Chocolate



Sous Vide In Chocolate Mode  
149°F-203°F



Image: A hand interacting with the digital temperature control panel, illustrating the precise adjustment capability, including its use for sous vide cooking in 'Chocolate' mode (149°F-203°F).

## Sous Vide Functionality:

The precise digital temperature control allows the GREECHO FS01 to be used for sous vide cooking. Place your vacuum-sealed food item into the fondue pot filled with water, select a mode that aligns with your desired temperature range, and adjust as needed. Monitor the temperature for consistent results.

## 5. MAINTENANCE AND CLEANING

---

Proper cleaning and maintenance will extend the life of your fondue pot set.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Detachable Pot:** The stainless steel fondue pot, splatter guard, and fondue forks are dishwasher-safe. For handwashing, use warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry immediately to prevent water spots.
3. **Heating Base:** Wipe the heating base with a soft, damp cloth. Do not immerse the heating base in water

or any other liquid. Ensure no liquid enters the control panel or electrical components.

4. **Stubborn Residue:** For stubborn food residue in the pot, fill it with warm water and a small amount of dish soap, let it soak for a few minutes, then clean with a non-abrasive brush or sponge.
5. **Storage:** Store the clean and dry fondue pot set in a cool, dry place.



**TAKE CLEANING  
WORRIES AWAY**

**304 Stainless Steel**

Handwash-Friendly  
Dishwasher-Safe

Image: A visual guide demonstrating the ease of cleaning, showing the fondue pot being rinsed under a faucet and then placed in a dishwasher rack, emphasizing its dishwasher-safe design.

## 6. TROUBLESHOOTING

If you encounter issues with your GREECHO FS01 Electric Fondue Pot Set, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	No power supply.	Ensure the power cord is securely plugged into a working electrical outlet. Check household circuit breaker.

Problem	Possible Cause	Solution
Fondue is not heating or melting effectively.	Incorrect mode selected; insufficient preheating; ingredients too cold or dense.	Verify the correct preset mode (e.g., Cheese mode for cheese) is selected. Allow the heating plate to preheat for 2-5 minutes. For cheese or chocolate, pre-melt on a stovetop before transferring to the electric pot. Ensure ingredients are at room temperature if possible.
Fondue is burning or sticking to the bottom.	Temperature too high; insufficient stirring.	Reduce the temperature using the- button. Stir the fondue frequently, especially with thicker mixtures.
Splatter guard does not fit properly.	Incorrect placement.	Ensure the splatter guard is correctly aligned and seated on the rim of the fondue pot.

If the problem persists after attempting these solutions, please contact GREECHO customer support.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	FS01
Product Dimensions	11.8 x 9.8 x 7.1 inches
Item Weight	5.84 pounds
Capacity	2.6 Quarts (approx. 2.46 Liters)
Power	1200W
Material	304 Stainless Steel (Pot and accessories)
Preset Modes	Cheese, Chocolate, Broth
Manufacturer	GREECHO
Date First Available	March 28, 2022

## 8. WARRANTY AND SUPPORT

GREECHO is committed to providing high-quality products. For warranty information, product support, or any inquiries regarding your FS01 Electric Fondue Pot Set, please refer to the warranty card included with your

purchase or visit the official GREECHO website.

If you require assistance with troubleshooting or parts replacement, please contact GREECHO customer service directly. Have your model number (FS01) and purchase date ready when contacting support.