

[Manuals.plus](#) /

› [Sonew](#) /

› Sonew 2-in-1 Hair Dryer Brush & Straightener Brush Instruction Manual

Sonew B09TW9VLCW

Sonew 2-in-1 Hair Dryer Brush & Straightener Brush Instruction Manual

Model: B09TW9VLCW

1. INTRODUCTION

Thank you for choosing the Sonew 2-in-1 Hair Dryer Brush & Straightener Brush. This innovative styling tool is designed to efficiently dry, detangle, smooth, and straighten your hair, reducing frizz and static for salon-quality results at home. Please read this manual thoroughly before use to ensure safe and optimal performance.



Image 1.1: The Sonew 2-in-1 Hair Dryer Brush and Straightener Brush, showcasing its sleek design and paddle brush head.

2. SAFETY INFORMATION

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- Do not use this appliance near water, such as bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Keep the cord away from heated surfaces.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

- Do not use an extension cord with this appliance.
- Always check the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PRODUCT OVERVIEW

3.1 Components

The Sonew 2-in-1 Hair Dryer Brush features a streamlined design for comfortable handling and effective styling.

- **Paddle Brush Head:** Designed with an extra-large contact surface and bristles to detangle, dry, and smooth hair efficiently.
- **Handle:** Ergonomically designed for a comfortable and secure grip.
- **Temperature Control Dial:** Located at the base of the handle for selecting heat and speed settings.
- **360° Rotating Cord:** Prevents tangling and allows for flexible styling.



Comfortable Grip

Lightweight design for fatigue-free styling.

Three Temperature Levels

Easily adjust to your ideal heat.



360° Rotating Cord

Enhances maneuverability and prevents tangling.

Image 3.1: Detailed view of the Sonew Hair Dryer Brush highlighting its comfortable grip, three temperature levels, and 360° rotating cord for enhanced maneuverability.

3.2 Key Features

- **2-in-1 Design:** Combines the functions of a hair dryer and a straightener brush for efficient styling.
- **Efficient Rapid Drying:** High-speed airflow and large paddle brush cover more area for quicker drying and styling.
- **Ionic Conditioning:** Advanced negative ion technology reduces frizz, enhances shine, and promotes healthier-looking hair.
- **Ultra-Smooth Straightening:** Achieves salon-quality sleek hair with ease.
- **Three Temperature Levels:** Adjustable heat settings (HIGH, LOW, COOL) to suit different hair types and styling needs.
- **Comfortable Grip Handle:** Ensures ease of use and fatigue-free styling.
- **Extra Large Contact Surface:** Ensures fast, even styling and prevents overheating by distributing heat effectively.



Image 3.2: Illustrates the 2-in-1 functionality of the styling comb, combining hair drying and straightening capabilities.

Ionic Anti-Frizz Tech



- Reduces frizz
- enhances shine
- long-lasting results

Image 3.3: Demonstrates the Ionic Anti-Frizz Technology, showing how it reduces frizz and enhances shine for long-lasting results.

4. SETUP

1. **Unpack:** Carefully remove the Sonew 2-in-1 Hair Dryer Brush from its packaging. Retain packaging for storage or future transport.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if the cord or plug is damaged.
3. **Plug In:** Insert the power plug into a suitable electrical outlet. Ensure the voltage matches the appliance's requirements.

5. OPERATING INSTRUCTIONS

5.1 Preparing Your Hair

For best results, towel-dry your hair to remove excess water before using the brush. The brush works best on damp, not soaking wet, hair.

5.2 Powering On and Selecting Settings

1. Plug the appliance into an electrical outlet.
2. Rotate the temperature control dial to select your desired setting:
 - **OFF:** Turns the appliance off.
 - **COOL:** Provides cool air for setting styles.
 - **LOW:** Low heat and low speed for fine or damaged hair.
 - **HIGH:** High heat and high speed for thick or coarse hair, and for rapid drying.

5.3 Styling Your Hair

1. Divide your hair into manageable sections.
2. Place the brush close to the roots of a section of hair.
3. Slowly glide the brush downwards towards the ends, allowing the hot air to dry and smooth the hair. The paddle brush design helps detangle as you style.
4. Repeat for all sections until hair is dry and styled as desired.
5. For added volume, lift hair at the roots and hold the brush for a few seconds before gliding down.
6. Use the COOL setting at the end of your styling routine to set your hairstyle and add shine.

Fast Drying

High-speed airflow for quick drying



Image 5.1: Demonstrates the fast drying capability of the brush, showing hair before and after use.

Ultra-Smooth Straightening

Salon-quality sleek hair in minutes



Image 5.2: Illustrates the ultra-smooth straightening effect, showcasing hair transformation from wavy to sleek.

6. MAINTENANCE

6.1 Cleaning

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. Use a soft, damp cloth to wipe down the exterior of the brush and handle.
3. Remove any hair tangled in the bristles using a comb or your fingers.
4. Do not immerse the appliance in water or any other liquid.
5. Do not use abrasive cleaners or solvents.

6.2 Storage

When not in use, store the appliance in a cool, dry place, away from moisture and direct sunlight. Do not wrap the power cord around the appliance, as this can damage the cord.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; Power outlet issue; Appliance malfunction.	Ensure plug is fully inserted. Test outlet with another device. If still not working, contact customer support.
Low airflow or heat.	Air inlet/outlet blocked; Incorrect setting selected.	Check for and remove any obstructions (e.g., lint, hair) from the air inlet/outlet. Ensure the correct temperature setting (LOW/HIGH) is selected.
Hair is still frizzy after use.	Hair too wet; Not using ionic feature effectively; Hair type.	Ensure hair is towel-dried before use. Glide the brush slowly to allow ionic conditioning to work. For very coarse hair, multiple passes may be needed.
Burning smell.	Dust/hair accumulation inside; Overheating.	Immediately unplug the appliance. Allow it to cool down. Clean the air inlet/outlet. If the smell persists, discontinue use and contact customer support.

8. SPECIFICATIONS

Attribute	Detail
Product Name	Sonew 2-in-1 Hair Dryer Brush & Straightener Brush
Model Number	B09TW9VLCW
Manufacturer	Sonew
Product Dimensions	1.57 x 1.57 x 4.72 inches
Product Weight	1.1 Pounds
Power Source	Corded Electric
Temperature Settings	OFF, COOL, LOW, HIGH

PRODUCT SIZE



Image 8.1: Diagram illustrating the physical dimensions of the Sonew Hair Dryer Brush.

9. WARRANTY AND SUPPORT

The Sonew 2-in-1 Hair Dryer Brush & Straightener Brush comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact Sonew customer service. Contact information can typically be found on the product packaging or the official Sonew website.

Visit the [Sonew Store on Amazon](#) for more information and support resources.