Whirlpool W11047722

Whirlpool W11047722 Electric Range Radiant Surface Element

Official User Manual




Image of the Whirlpool W11047722 Electric Range Radiant Surface Element, showing its circular heating coil and terminal connections.

Product Overview

The Whirlpool W11047722 Electric Range Radiant Surface Element is a genuine OEM (Original Equipment Manufacturer) replacement part designed for electric ranges. This 2500-watt large heating element is installed under the cooktop, providing heat to the surface above it. It features easy-to-install 'plug-in' style terminals and is compatible with many electric range makes and models.

This part is essential for the proper functioning of your electric range's burner. If your range's burner is no longer heating up, replacing this element may resolve the issue.



The Whirlpool W11047722 element, highlighting its OEM authenticity with the 'W Parts' logo.

What's in the Box

- Whirlpool W11047722 Genuine OEM Electric Range Radiant Surface Element Replacement Part

Installation Instructions (Setup)

Safety First: Before beginning any installation or repair, always unplug the range from its power source or shut off the corresponding house circuit breaker to prevent electrical shock.

1. **Prepare the Appliance:** Open the oven door to access the underside of the cooktop.
2. **Remove Cooktop Screws:** Locate and remove the two screws that attach the cooktop to the body of the range.
3. **Carefully Lift Cooktop:** Gently lift and remove the cooktop. Be mindful of any attached wiring or components.
4. **Document Wiring:** Before disconnecting the old element, it is highly recommended to take a digital photo of the wires attached to the existing part. This will serve as a reference for correct reassembly.
5. **Disconnect Old Element:** Carefully disconnect the wires from the old radiant surface element.
6. **Remove Old Element:** Remove the old element from its position.
7. **Install New Element:** Position the new Whirlpool W11047722 element in place.
8. **Connect Wiring:** Using your digital photo as a guide, connect the wires to the new element's 'plug-in' style terminals. Ensure connections are secure.
9. **Reassemble Cooktop:** Carefully lower the cooktop back into place, ensuring all components align correctly.
10. **Secure Cooktop:** Reinsert and tighten the two screws that attach the cooktop to the range body.
11. **Restore Power:** Plug the range back into its power source or turn the house circuit breaker back on.

Required Tools: Basic hand tools such as a multi-screwdriver and needle-nose pliers are typically needed for this repair. Novice repair experience is recommended.



A detailed view of the element's 'plug-in' style terminals, showing where electrical connections are made.

Operation

Once installed, the Whirlpool W11047722 Electric Range Radiant Surface Element operates automatically as part of your electric range's heating system. When a burner is turned on, electrical current flows through the element's coil, causing it to heat up and transfer radiant heat to the cooking surface above. This element is designed to provide consistent and efficient heat for cooking.

Maintenance

The Whirlpool W11047722 Radiant Surface Element is a sealed component and does not require routine maintenance. If the element becomes damaged or ceases to function, it should be replaced. Regular cleaning of your range's cooktop will help maintain overall appliance hygiene and performance, but direct maintenance of the element itself is not necessary.

Troubleshooting

Symptom: The range burner no longer heats up or heats inconsistently.
Possible Cause: The radiant surface element may be faulty or has reached the end of its lifespan.
Solution: If other troubleshooting steps for your range have been exhausted and the burner still does not heat, replacing the Whirlpool W11047722 Electric Range Radiant Surface Element may resolve the issue. Refer to the "Installation Instructions" section for replacement steps.

Specifications

Attribute	Detail
Brand Name	Whirlpool
Model Info	W11047722
Item Weight	2.1 pounds
Product Dimensions	15.25 x 14.5 x 2.38 inches
Part Number	W11047722
Color	White and Chrome
Included Components	Whirlpool W11047722 Genuine OEM Electric Range Radiant Surface Element Replacement Part
Compatible Appliances	Multiple Whirlpool models, including WFE515S0ES, WFE320M0ES, WFE320M0JS, WFE510S0AS, and WFE515S0JS
Replaces Part Numbers	WP8273992, 8273992, W10248262



Top-down view of the radiant surface element, showing its circular heating coil and overall dimensions on a grid background.

Warranty Information

Whirlpool offers a **one-year warranty** on the W11047722 Genuine OEM Electric Range Radiant Surface Element. This warranty covers defects in material and workmanship under normal use and service. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or warranty claims regarding your Whirlpool W11047722 Electric Range Radiant Surface Element, please contact Whirlpool customer service. You can find contact information on the official Whirlpool website or through your product's original documentation.
For more information on genuine OEM parts, refer to the image below:



An informational graphic explaining what Original Equipment Manufacturer (OEM) parts are and listing brands under Whirlpool Corporation.

© 2024 Whirlpool Corporation. All rights reserved.
This manual is for informational purposes only. Always consult a qualified technician for complex repairs.