Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Oladance /
- > Oladance OWS1 Open Ear Headphones User Manual

Oladance OLA02

Oladance OWS1 Open Ear Headphones User Manual

Model: OLA02

Overview What's in the

Box Features Setup Operation Maintenance Troubleshooting Specifications Warranty &

Support

1. PRODUCT OVERVIEW

The Oladance OWS1 Open Ear Headphones offer a unique open-ear design for comfort and situational awareness. These wireless Bluetooth 5.2 headphones feature dual 16.5mm drivers for high-quality sound and extended battery life, making them suitable for various activities.



Image 1: Oladance OWS1 Open Ear Headphones and their carry case.

2. WHAT'S IN THE BOX

- 1 × Oladance Wearable Stereo (Pair of Open Ear Headphones)
- 1 × Non-charging Carry Case
- 1 × Type-C Cable
- 1 × User Manual

3. Key Features

- **True Open Ear Design:** Earbuds rest gently on top of the ear, avoiding insertion into the ear canal for enhanced comfort and situational awareness.
- 360° Superior Sound: Equipped with dual powerful 16.5mm dynamic drivers and bio-diaphragm

technology for rich, clear audio across all volume levels.

- **Anti-Hearing Loss Focus:** Designed to prevent common health issues associated with traditional earbuds by not blocking the ear canal, reducing pressure and potential hearing damage.
- Extended 16-Hour Playtime: Features a built-in 160mAh battery and low-consumption algorithms, providing up to 16 hours of continuous playback on a single charge. Note: A separate charging case is required for extended playtime beyond the included carry case.
- Secure and Comfortable Fit: Multi-point support system distributes weight evenly across the ear, ensuring a stable and comfortable fit for various activities.




Image 2: The Oladance OWS1 headphones are designed for a secure and comfortable fit, ideal for activities like yoga.

4. SETUP GUIDE

4.1 Initial Charging

Before first use, fully charge your Oladance OWS1 headphones. Connect the provided Type-C cable to the charging port on the headphones and a compatible USB power source. The LED indicator will show charging status.

4.2 Powering On/Off

- **To Power On:** Press and hold the power button (location typically on one of the earbud units) for approximately 2-3 seconds until you hear an audible prompt or see an LED indicator light up.
- **To Power Off:** Press and hold the power button for approximately 3-5 seconds until you hear an audible prompt or the LED indicator turns off.

4.3 Bluetooth Pairing

- 1. Ensure the headphones are powered off.
- 2. Press and hold the power button for approximately 5-7 seconds until the LED indicator flashes red and blue alternately. This indicates the headphones are in pairing mode.
- 3. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
- 4. Search for "Oladance OWS1" in the list of available devices.
- 5. Select "Oladance OWS1" to connect. Once connected, the LED indicator will typically flash blue slowly or turn off, and you will hear a confirmation tone.



Image 3: The Oladance OWS1 headphones are designed for an ergonomic and stable fit during various activities.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

Function	Action
Play/Pause Music	Single press the Multi-function button.
Next Track	Double press the Multi-function button.
Previous Track	Triple press the Multi-function button.
Volume Up	Single press the Volume + button.
Volume Down	Single press the Volume - button.
Answer/End Call	Single press the Multi-function button during an incoming call or active call.
Reject Call	Press and hold the Multi-function button for 2 seconds during an incoming call.
Activate Voice Assistant	Press and hold the Multi-function button for 2 seconds.

5.2 Multi-Point Connection

The Oladance OWS1 headphones support multi-point connection, allowing them to be connected to two Bluetooth devices simultaneously. This enables seamless switching between devices without re-pairing.

- 1. Ensure the headphones are paired with the first device.
- 2. Put the headphones into pairing mode again (usually by holding the power button until the LED flashes red and blue).
- 3. On the second device, search for "Oladance OWS1" in the Bluetooth settings and connect.
- 4. The headphones should now be connected to both devices. Audio will automatically switch to the device playing content or receiving a call.




Image 4: The open-ear design allows for comfortable extended wear, even during work or calls.

6. CARE AND MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the headphones. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the headphones in their provided non-charging carry case when not in use to protect them from dust and damage.
- Water Resistance: The headphones are water-resistant (IPX4 rated). Avoid submerging them in water or exposing them to high-pressure water jets. Dry thoroughly if they get wet.
- **Temperature:** Avoid exposing the headphones to extreme temperatures (hot or cold) or high humidity.



Image 5: The included carry case protects your Oladance OWS1 headphones during transport and storage.

7. TROUBLESHOOTING

Cannot Power On

Ensure the headphones are fully charged. Connect them to a power source using the Type-C cable.

Cannot Pair with Device

- Ensure the headphones are in pairing mode (LED flashing red and blue).
- Turn off and on your device's Bluetooth.
- · Clear previous Bluetooth connections on your device.
- Move the headphones closer to your device.

No Sound or Low Volume

- Check the volume levels on both the headphones and your connected device.
- Ensure the headphones are properly connected to your device.
- $\circ\,$ Try playing audio from a different application or source.

Intermittent Connection

- Ensure there are no obstructions between the headphones and your device.
- Avoid strong electromagnetic interference.
- Keep the headphones within the effective Bluetooth range (typically 10 meters).

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	OLA02
Brand	Oladance
Connectivity Technology	Wireless (Bluetooth 5.2)
Ear Placement	Open Ear
Form Factor	Open Ear
Driver Size	Dual 16.5mm Dynamic Drivers
Battery Life (Average)	Up to 16 Hours
Charging Time	Approximately 2 Hours
Water Resistance Level	Water Resistant (IPX4)
Microphone Format	Built-In
Control Type	Media Control (Buttons)
Material	Plastic
Product Dimensions	13 x 11 x 457.2 cm
Item Weight	260 g

ホームシアターのような 立体感ある音響体験。




Image 6: A close-up of the Oladance OWS1 headphones, highlighting their design and color.

9. WARRANTY AND SUPPORT

Oladance products are covered by a limited warranty. For detailed warranty information, product support, or service inquiries, please refer to the official Oladance website or contact their customer service directly. Keep your proof of purchase for warranty claims.

For further assistance, please visit: www.oladance.com

© 2023 Oladance. All rights reserved. Information in this manual is subject to change without notice.

Cluder to wear to force 11 Guick Start Guide	Oladance Wearable Stereo B1 Quick Start Guide A concise quick start guide for the Oladance Wearable Stereo B1 earbuds, detailing unboxing contents, product features, touch controls for music and calls, Bluetooth pairing, wearing instructions, technical specifications, safety warnings, and compliance information for models OLA02, 2A24K-OLA02L, 27690-OLA02L.
豆氨烷烷 000 里温光点点点 —	Oladance OWS Pro / OWS C1 Headphones: Quick Start Guide & Features Explore the Oladance OWS Pro and OWS C1 open-ear Bluetooth headphones. This guide covers wearing, pairing, controls, multipoint connection, app features, and important safety information.
Cludance vacuable Stere () 1 Quick Start Guide	Oladance Wearable Stereo B1 Quick Start Guide Get started quickly with your Oladance Wearable Stereo B1. This guide covers setup, controls, and features for your wireless earbuds.
豆壳肉类的含果是类点点是 -	Oladance OWS Pro User Manual: Features, Setup, and Specifications Comprehensive user manual for Oladance OWS Pro open-ear wireless headphones. Learn about setup, wearing, controls, connectivity, app integration, safety, and technical specifications.
Cladence CMC2 Quick Start Guille	Oladance OWS 2 Quick Start Guide Get started quickly with the Oladance OWS 2 Wearable Stereo. This guide provides essential information for setting up and using your new headphones.
Oladance OWS C1 产品说明书	Oladance OWS C1 Wireless Earbuds User Manual and Product Guide User manual and product guide for Oladance OWS C1 wireless earbuds, covering features, specifications, setup, connectivity, safety warnings, and compliance information.