Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schleich 42623

Instruction Manual

SCHLEICH 42623 Wild Life Outback Adventures Set

Product Overview

The SCHLEICH 42623 Wild Life Outback Adventures set brings the Australian wilderness to life with highly detailed and realistic figures. This set includes a ranger figure, a kangaroo with a removable joey, a dingo, a backpack, binoculars, a cup, and a tree trunk.





Image: The complete SCHLEICH Wild Life Outback Adventures set, including the ranger, kangaroo with joey, dingo, and accessories, shown in its retail packaging.



Image: Close-up view of the ranger figure, dingo, and kangaroo with joey, showcasing their detailed design.

What's Included

- 1 x Ranger Tom figure
- 1 x Kangaroo mother figure
- 1 x Kangaroo baby (joey) figure
- 1 x Dingo figure
- 1 x Backpack accessory
- 1 x Binoculars accessory
- 1 x Cup accessory
- 1 x Tree trunk accessory

Setup and Assembly

The SCHLEICH Wild Life Outback Adventures set requires minimal assembly. All figures are pre-assembled and ready for play. The joey can be placed inside or removed from the kangaroo's pouch.

1. Carefully remove all components from the packaging.
2. Attach the backpack to the ranger figure's back if desired.
3. Place the binoculars around the ranger's neck or hold them in his hand.
4. The cup can be held by the ranger figure.
5. The tree trunk serves as a seating accessory for the ranger or as part of the playset scenery.
6. To place the joey in the kangaroo's pouch, gently slide it into the opening. To remove, gently pull it out.



Image: The ranger figure seated on the tree trunk accessory, with the dingo figure nearby, demonstrating how accessories can be used.



Image: The kangaroo figure with its joey visible in the pouch, standing next to the ranger figure, illustrating the interactive feature.

Operating Instructions (Play)

This playset is designed for imaginative play, encouraging children to create their own Outback adventures. The figures are durable and suitable for various play environments.

- **Role-Playing:** Use the ranger figure to explore the wilderness, observe animals, and interact with the kangaroo and dingo.
- **Animal Interaction:** The kangaroo and dingo figures are designed to be realistic, allowing for educational play about Australian wildlife.
- **Accessory Use:** Integrate the backpack, binoculars, cup, and tree trunk into your play scenarios to enhance realism and storytelling.
- **Joey Feature:** The removable joey adds an extra layer of interactive play, simulating the natural behavior of kangaroos.



Image: A detailed view of the kangaroo figure, highlighting its texture and realistic appearance.





Image: A detailed view of the ranger figure, showing its uniform and backpack.

Maintenance and Care

To ensure the longevity of your SCHLEICH figures, follow these simple care instructions:

- **Cleaning:** Wipe figures with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow figures to air dry completely after cleaning.
- **Storage:** Store figures in a cool, dry place away from direct sunlight to prevent fading or material degradation.
- **Handling:** While durable, avoid excessive force or bending of delicate parts to prevent breakage.

Troubleshooting

Most issues with SCHLEICH figures are minor and can be resolved easily:

Problem	Possible Cause	Solution
Figure appears dirty or dusty.	Accumulation of dust or grime from play.	Wipe with a damp cloth and mild soap.
Paint fading or chipping.	Prolonged exposure to direct sunlight or harsh chemicals.	Store away from direct sunlight. Avoid harsh cleaners. This is normal wear over time.
Joey does not fit securely in pouch.	Incorrect alignment or minor manufacturing variation.	Ensure the joey is oriented correctly. Gently adjust if needed.

Specifications

- **Product Dimensions:** 7.48 x 2.36 x 5.91 inches
- **Item Weight:** 5.5 ounces
- **Item Model Number:** 42623
- **Manufacturer Recommended Age:** 3 years and up
- **Release Date:** July 1, 2022
- **Manufacturer:** Schleich
- **Material:** Durable, high-quality plastic (PVC-free)

Safety Information

Warning! Swallowable small parts. Choking hazard. Not for children under 3 years.

Always supervise young children during play to ensure safe use of all components, especially the smaller accessories like the joey, binoculars, and cup.

Official Product Video

Watch the official product video for a closer look at the SCHLEICH Wild Life Outback Adventures set and its features.

No official seller videos are available for embedding based on the provided criteria.

Warranty and Support

Schleich stands behind the quality of its products. For information regarding warranty, returns, or customer support, please visit the official Schleich website or contact their customer service department.

Official Schleich Website: www.schleich-s.com

Brand Store: Visit the Schleich Store on Amazon

© 2024 Schleich. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09V18RH98

More documents and user manuals: **https://manuals.plus/**