



[Manuals.plus](#) /

> [Alpine Corporation](#) /

> Alpine Corporation MLT134SL 72-inch Indoor Floor Bubble Wall Water Fountain Instruction Manual

Alpine Corporation MLT134SL

Alpine Corporation MLT134SL 72-inch Indoor Floor Bubble Wall Water Fountain Instruction Manual

Model: MLT134SL | Brand: Alpine Corporation

1. PRODUCT OVERVIEW

The Alpine Corporation MLT134SL Indoor Floor Bubble Wall Water Fountain is designed to bring tranquility and a modern aesthetic to your indoor space. This 72-inch tall decorative feature includes a clear bubble-filled panel, a durable silver-colored base, and an internal pump for continuous water flow. It features color-changing LED lights controllable via a remote, offering 16 color options and 6 lighting effects.

Key Features:

- **Indoor Bubble Wall:** Features water cascading down a clear bubble-filled panel into a stone-filled silver base with an interior pump that keeps the water flowing.
- **Customizable Colors and Light Effects:** A convenient remote allows selection from 16 color options and 6 lighting options (speed, brightness, flash, strobe, fade, smooth).
- **Versatile Accent Piece:** Ideal for enhancing ambiance in entryways, living rooms, offices, and other indoor areas.
- **Durable Construction:** Constructed with a durable stainless steel base and clear acrylic panel for long-lasting use.
- **Dimensions and Support:** Measures 20"L x 11"W x 72"H and includes a two-year manufacturer's support from the date of purchase.



Figure 1: Alpine Corporation MLT134SL 72-inch Indoor Floor Bubble Wall Water Fountain with remote control.

2. SETUP INSTRUCTIONS

Follow these steps to correctly set up your Alpine Corporation Bubble Wall Water Fountain:

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure all parts are present: the main bubble wall unit, base, pump, LED light, remote control, and decorative stones.
2. **Position the Fountain:** Place the fountain on a flat, stable surface indoors. Ensure it is near an electrical outlet and away from areas where water splashes could cause damage.
3. **Connect the Pump:** Attach the pump to the rubber hose located inside the base of the fountain. Ensure a secure connection to prevent leaks.
4. **Connect LED Light:** Connect the LED light wire to its corresponding power connection. Turn and tighten the connection to ensure it is secure and waterproof.

5. **Place Fountain Body into Basin:** Carefully lower the main fountain body into the base basin, ensuring the pump cord runs out the back of the basin through the designated opening.
6. **Add Decorative Stones:** Place the provided decorative river stones into the fountain base, arranging them around the LED light for aesthetic appeal.
7. **Fill with Water:** Fill the reservoir with approximately 0.6 gallons of distilled water. Ensure the water level is sufficient to completely cover the pump. Using distilled water helps prevent mineral buildup.
8. **Plug In:** Connect the power cords for both the pump and the LED lights to a suitable electrical outlet. The fountain will begin operating.

Gentle Flow, Warm Light



The Built-in LED lights enhance the fountain's appeal

High Performance Pump and Adapter



The Gentle Flow of Water Over The Stones Produces a Calming Sound

Figure 2: Visual guide for fountain maintenance, also illustrating the base and water flow.

Your browser does not support the video tag.

Video 1: Official Alpine Corporation video demonstrating the 72"H Indoor Bubble Wall Fountain with Color-Changing lights, showing its features and operation.

3. OPERATING INSTRUCTIONS

Once the fountain is set up and plugged in, the water flow will begin automatically. Use the included remote control to manage the lighting features.

Remote Control Functions:

- **Power On/Off:** Use the ON/OFF buttons to control the LED lights. The water pump operates independently when plugged in.
- **Color Selection:** Choose from 16 vibrant color options to match your mood or decor.
- **Lighting Effects:** Select from 6 different lighting modes:
 - **Speed:** Adjust the transition speed of dynamic lighting effects.
 - **Brightness:** Control the intensity of the LED lights.
 - **Flash:** Rapidly cycles through colors.
 - **Strobe:** Flashes a single color.
 - **Fade:** Smoothly transitions between colors.
 - **Smooth:** Provides a gentle, continuous color change.



Figure 3: The fountain showcasing its diverse color-changing LED light capabilities.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your water fountain.

- **Water Level:** Check the water level regularly (daily or every few days, depending on usage and environment) and refill with distilled water as needed. Ensure the pump remains fully submerged.

- **Cleaning:** Periodically clean the fountain to prevent algae buildup and mineral deposits.
 - Unplug the fountain before cleaning.
 - Drain the water from the reservoir.
 - Wipe down the acrylic panel and base with a soft cloth.
 - Clean the pump according to its specific instructions (usually involves disassembling and rinsing).
 - Replace the water with fresh distilled water.
- **Mineral Deposits:** If mineral deposits occur, use a mild descaling solution safe for fountain materials. Avoid harsh chemicals or abrasive cleaners.

Your browser does not support the video tag.

Video 2: A seller-provided video demonstrating the setup and maintenance of a similar indoor water fountain, including water filling and pump access.

5. TROUBLESHOOTING

If you encounter issues with your fountain, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
No Water Flow	Pump not plugged in; water level too low; pump clogged.	Ensure pump is plugged in. Add distilled water until pump is submerged. Unplug and clean the pump.
Weak Water Flow	Low water level; pump partially clogged; kink in tubing.	Check water level and refill. Clean the pump. Inspect tubing for kinks or obstructions.
Lights Not Working	LED light not plugged in; remote control battery dead; LED unit faulty.	Ensure LED light is plugged in. Replace remote control battery. Contact customer support if unit is faulty.
Excessive Noise	Low water level (pump running dry); pump vibrating against base; debris in pump.	Add water to cover the pump. Adjust pump position to prevent contact with base. Clean pump of any debris.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	MLT134SL
Brand	Alpine Corporation
Color	Silver - Color Changing
Material	Acrylic, Iron, Plastic
Product Dimensions (L x W x H)	20" x 11" x 72"

Feature	Detail
Item Weight	38 Pounds
Power Source	Corded Electric
Special Feature	Lighted (Color-Changing LED)
UPC	821559742193

7. WARRANTY AND SUPPORT

This Alpine Corporation MLT134SL Water Fountain includes a **two-year manufacturer's support** from the date of purchase. For any questions, technical assistance, or warranty claims, please contact Alpine Corporation customer service directly. Alpine Corporation is committed to providing fast and reliable support. Refer to the product packaging or the official Alpine Corporation website for the most current contact information.