

VIOMI V5 Pro

VIOMI V5 Pro LDS Robot Vacuum Mop Cleaner User Manual

Model: V5 Pro | Brand: VIOMI

INTRODUCTION

Thank you for choosing the VIOMI V5 Pro LDS Robot Vacuum Mop Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new robot vacuum. Please read this manual thoroughly before using the product and retain it for future reference.



Image: The VIOMI V5 Pro LDS Robot Vacuum Mop Cleaner, showcasing its sleek black design and top-mounted LDS sensor.

Key Features:

- **Advanced Obstacle Avoidance:** Equipped with four line lasers for enhanced anti-collision capabilities.
- **Powerful Suction:** Superior 4000Pa suction power effectively removes various types of debris and dust.
- **Optimized Cleaning Coverage:** Features an ultra-long main brush and longer side brush for maximized cleaning area, especially along walls and corners.
- **Versatile Control:** Supports both App Control and Voice Control for convenient operation.

1. SETUP

1.1 Unboxing and Components

Carefully remove all components from the packaging. Ensure all items listed below are present:

- 1 x VIOMI V5 Pro Vacuum Mop Cleaner
- 1 x Charging Dock
- 1 x Power Adapter
- 1 x Side Brush (pre-installed or to be installed)
- 1 x Main Brush (pre-installed)
- 1 x Dustbin/Water Tank
- 1 x Cleaning Tool
- User Manual (this document)

1.2 Charging Dock Placement

Place the charging dock against a wall in an open area. Ensure there is at least 0.5 meters (1.6 feet) of clear space on both sides of the dock and 1.5 meters (4.9 feet) in front of it. Connect the power adapter to the charging dock and plug it into a power outlet. Ensure the power outlet is always on.

1.3 Initial Charging

Before first use, fully charge the robot vacuum. Place the robot on the charging dock, ensuring the charging contacts align. The indicator light on the robot will show charging status. A full charge typically takes 4-6 hours.

1.4 App Installation and Connection

1. Scan the QR code in the quick start guide (if provided) or search for the "VIOMI Home" app (or similar, based on brand) in your mobile app store.
2. Download and install the app.
3. Register an account and log in.
4. Follow the in-app instructions to add your VIOMI V5 Pro device. This typically involves connecting to the robot's Wi-Fi hotspot temporarily and then connecting the robot to your home Wi-Fi network.



Image: Top view of the VIOMI V5 Pro, highlighting the LDS sensor and power button.

2. OPERATING THE ROBOT VACUUM

2.1 Power On/Off

- **Power On:** Press and hold the power button on the robot for a few seconds until the indicator light illuminates.
- **Power Off:** Press and hold the power button for a few seconds until the indicator light turns off.

2.2 Starting a Cleaning Cycle

- **Via Robot Button:** Briefly press the power button on the robot to start a standard cleaning cycle.
- **Via Mobile App:** Open the VIOMI Home app, select your device, and tap "Start Cleaning" or similar. The app offers more advanced options like selecting cleaning modes (e.g., Auto, Spot, Edge), setting no-go zones, and scheduling.
- **Via Voice Control:** If integrated with a smart home assistant (e.g., Google Assistant, Amazon Alexa), use voice commands like "Hey Google, start cleaning with VIOMI robot."

2.3 Pausing and Resuming

During a cleaning cycle, you can pause the robot by briefly pressing the power button or using the app. Press again to resume cleaning.

2.4 Returning to Charging Dock

The robot will automatically return to its charging dock when the battery is low or after completing a cleaning cycle. You can also manually send it back via the app or by briefly pressing the home button (if available) on the robot.

3. MAINTENANCE

Regular maintenance is crucial for optimal performance and longevity of your VIOMI V5 Pro. Perform these steps regularly based on usage.



Image: Angled view of the VIOMI V5 Pro, illustrating the side brush and overall compact design.

3.1 Emptying the Dustbin

It is recommended to empty the dustbin after each cleaning cycle, especially if cleaning large areas or heavily soiled floors.

1. Open the top cover of the robot.
2. Remove the dustbin/water tank module.
3. Open the dustbin compartment and discard collected debris.
4. Rinse the dustbin with water if necessary (ensure it is completely dry before reinserting).

3.2 Cleaning the Filter

The filter (cartridge type) should be cleaned weekly and replaced every 3-6 months, depending on usage.

1. Remove the filter from the dustbin.
2. Tap the filter gently over a trash can to remove loose dust.
3. Do not wash the HEPA filter with water unless specified by the manufacturer.
4. Reinsert the clean filter.

3.3 Cleaning Brushes

- **Main Brush:** Remove the main brush cover and the main brush. Use the provided cleaning tool to cut and remove tangled hair or debris. Reinstall the brush.
- **Side Brush:** Unscrew the side brush and remove any tangled hair or debris. Reattach the side brush.

3.4 Cleaning Sensors and Charging Contacts

Wipe the following components with a clean, dry cloth monthly:

- Cliff Sensors (located on the bottom of the robot)
- Wall Sensors (located on the side of the robot)
- Charging Contacts (on the robot and charging dock)
- LDS Sensor (top of the robot, ensure it rotates freely)

4. TROUBLESHOOTING

If you encounter issues with your VIOMI V5 Pro, refer to the following common problems and solutions:




Problem	Possible Cause	Solution
Robot does not power on.	Low battery; Power button not pressed long enough.	Place robot on charging dock; Press and hold power button for 3-5 seconds.
Robot does not charge.	Charging contacts dirty; Charging dock not powered.	Clean charging contacts on robot and dock; Ensure charging dock is plugged in and powered.
Robot gets stuck frequently.	Obstacles in path; Cliff sensors dirty.	Clear cables, rugs, or small objects; Clean cliff sensors.
Poor cleaning performance.	Dustbin full; Brushes tangled; Filter clogged.	Empty dustbin; Clean main and side brushes; Clean or replace filter.
Cannot connect to Wi-Fi/App.	Incorrect Wi-Fi password; Router too far; Robot not in pairing mode.	Verify password; Move robot closer to router; Reset Wi-Fi on robot and try pairing again.

If the problem persists, please refer to the "Warranty and Support" section for further assistance.

5. SPECIFICATIONS

The following table outlines the key specifications of the VIOMI V5 Pro LDS Robot Vacuum Mop Cleaner:

Feature	Detail
---------	--------

	Viomi Alpha 2 Pro Robot Vacuum User Manual This user manual provides comprehensive instructions for the Viomi Alpha 2 Pro robot vacuum, covering safety information, product introduction, installation, operation, maintenance, specifications, troubleshooting, and FAQs.
	Viomi Alpha 2 Pro Robot Vacuum-Mop User Manual Comprehensive user manual for the Viomi Alpha 2 Pro robot vacuum-mop, covering safety information, packing list, product introduction, installation, operation, maintenance, specifications, troubleshooting, and FAQs.
	Viomi S9 Alpha Robot Vacuum Cleaner with Self-Emptying Station (White) Detailed specifications and features of the Viomi S9 Alpha robot vacuum cleaner, including its self-emptying station, advanced LDS 2.0 navigation, 2700 Pa suction power, HEPA filtration, and smart home compatibility.

Documents - VIOMI – V5 Pro

Robot sprzątający Viomi V5 Pro

Wskaz: 199676Producent: ViomiKod producenta: V-RVCLM40B

Cena: 1,869.60 zł

Opis

Robot sprzątający Viomi V5 Pro

Producent: VIOMI

Parametry

Marka	Viomi
Model	V5 Pro
Kolor dominujący	czarny
Kod producenta	V5 Pro
EAN	695223625194
Moc	55
Pojemność zbiornika	0.2
Moc netto	
Filtr	HEPA
Czas ładowania	5
Czas pracy bezprzewodowej	220
Waga produktu	0.15
Waga	Netto

[pdf]

Robot sprzątający Viomi V5 Pro Sklep internetowy stylem.pl robot sprzątający viomi v5 pro 199676 upload files product |||

Robot sprzątający Viomi **V5 Pro** Indeks: 199676 Producent: Viomi Kod producenta: V-RVCLM40B Cena: 1,869.60 zł Opis Robot sprzątający Viomi **V5 Pro** Producent: VIOMI Parametry Marka Model Kolor dominujący Kod producenta EAN Moc Pojemność zbiornika na kurz Filtr Czas ładowania Czas pracy bezprzewodowej Waga produktu

lang: score:33 filesize: 19.97 K page_count: 1 document date: 2022-09-23

Please read this manual carefully before use and keep it properly.
This product shall be operated only in location at altitude below 2,000 meters.

Contents

- 1 Safety Information
- 2 Safety precautions
- 3 About child safety
- 4 About fire batteries
- 5 Scope of use of the product
- 6 Disclaimers
- 7 Package list
- 8 Product introduction
- 9 Robot Vacuum drag and sensor
- 10 Introduction on installation
- 11 Install the charging base
- 12 Operation Instruction
- 13 1 Switch on/off
- 13.1 Switching on
- 13.2 Automatic/manual recharging
- 13.3 Recharging when the charging base is full-way
- 13.4 Recharging when the charging base is full-way
- 13.5 Network configuration and firmware update
- 13.6 Pair
- 13.7 How to use
- 14 How to connect to Wi-Fi
- 15 Connect to Wi-Fi App
- 16 Maintenance
- 17 2-in-1 Dual Compartment with Water Tank
- 18 Specifications
- 19 1 Vacuum Map
- 19.1 Charging Time
- 19.2 Power Adapter
- 19.3 Troubleshooting
- 19.4 FAQ
- 19.5 Documents / Resources
- 19.6 Related Parts

Safety Information

- Please pay attention to the following basic safety precautions before using the product:
- Read the user manual carefully and follow the instructions in the user manual when using the product.
- Keep the user manual well for future reference.
- If you need to transfer the product to a third party, please attach the user manual along with the product.
- Any operation not in conformity to the instructions in the user manual may result in serious personal injury or damage to the product itself.

Warning: Instructions against incorrect product use that may lead to death or serious injury.

Caution: Instructions against incorrect product use that may lead to minor injury or product damage.

[pdf] User Manual Installation Guide Instructions Frequently Asked Questions Specifications

Safety Information v5 pro robot vacuum with 4000pa suction manual 2 19 teamplush by 2024 03 |||

Please read this manual carefully before use and keep it properly. This product shall be operated on ... Fi connection for pairing by following the instructions in the manual. Documents / Resources Viomi **V5 Pro** Robot Vacuum with 4000Pa Suction pdf User Manual **V5 Pro** Robot Vacuum with 4000Pa Suction, V...

lang:en score:30 filesize: 883.92 K page_count: 18 document date: 2024-03-27



[pdf]

ffff VIOMI V5 Pro PL files innpro pl s3 amazonaws Viomi |||

Robot sprzątajcy Viomi **V5 Pro** Instrukcja obsługi Przed uyciem należy dokładnie przeczytać niniejszą instrukcję i przechowywać ją w odpowiednim miejscu. Ten produkt moe by uywany tylko w miejscach poloonych na wysokoci poniej 2000 m.n.p.m. Informacje dotyczce bezpieczeŃstwa Instrukcja obsługi Prosz zwrci u... lang:pl score:27 filesize: 20.05 M page_count: 23 document date: 2023-05-12



[pdf]


Viomi V5 Pro CZ files innpro pl s3 amazonaws |||

klidov robot Viomi **V5 Pro** Uzivatelsk prucka Ped pouzitm si pečliv pectte tento nvod a uschovejte jej na vhodnm mst. Tento vrobek sm bt pouzvn pouze v nadmoskch vskch pod 2000 m n. m. Bezpecnostn informace Pokyny k obsluze Ped pouzitm vrobku dodrzuje nsledujc zkladn bezpecnostn opaten: - Pecliv si... lang:hr score:27 filesize: 20.7 M page_count: 24 document date: 2023-05-12

VIOMI

Čistiaci robot Viomi V5 Pro

Návod na obsluhu



Pred použitím si pozorne prečítajte tento návod a uschovajte ho na vhodnom mieste.
Tento výrobok sa môže používať len v nadmorskej výške do 2000 m.n.m.

[\[pdf\]](#)

ffff Čistiaci robot Viomi V5 Pro Návod na obsluhu 7 giorni fa — Pred použitím výrobku dodržiavajte nasledujúce základné bezpečnostné opatrenia Pozorne si prečítajte návod a pri používaní SK cdn files innpro pl |||

Cistiaci robot Viomi **V5 Pro** Nvod na obsluhu Pred použitím si pozorne prečítajte tento nvod a uschovajte ho na vhodnom mieste. Tento výrobok sa môže používať len v nadmorskej vske do 2000 m.n.m. Bezpečnostn informcie Nvod na obsluhu Pred použitím výrobku dodržiavajte nasledujúce základn bezpečnostn opatrenia...

lang:sk **score:21** filesize: 20.05 M page_count: 23 document date: 2023-07-26