

[manuals.plus](#) /› [PETZL](#) /› [PETZL POCHE Carry Case for TIKKA Series Headlamps - Instruction Manual](#)

PETZL POCHE Carry Case for TIKKA Series Large Single

PETZL POCHE Carry Case for TIKKA Series Headlamps - Instruction Manual

Brand: PETZL | Model: POCHE Carry Case for TIKKA Series Large Single

1. INTRODUCTION AND OVERVIEW

The PETZL POCHE Carry Case is a protective transport solution specifically designed for PETZL TIKKA series headlamps. This case ensures your headlamp is safeguarded from impacts, scratches, and accidental activation during transport and storage.

It is compatible with a wide range of PETZL headlamps, including TIKKID, TIKKINA, TIKKA, ACTIK, ACTIK CORE, SWIFT RL, TACTIKKA, TACTIKKA +, and TACTIKKA +RGB models.

The case also features space to carry a spare set of batteries alongside your headlamp, enhancing preparedness for your outdoor activities.



Image: The PETZL POCHE Carry Case, a compact, dark-colored protective shell with a zipper closure, featuring the PETZL logo on its top surface.

2. SETUP AND STORAGE

2.1 Storing Your Headlamp in the Case

1. Unzip the PETZL POCHE Carry Case completely.
2. Fold the headlamp strap neatly to ensure it fits compactly within the case.
3. Place your PETZL headlamp inside the main compartment of the case.
4. Utilize the internal mesh pocket or designated space to store spare batteries, if applicable.
5. Carefully close the zipper, ensuring no part of the headlamp or strap is caught.

2.2 Attaching the Case

The case is designed for versatile attachment. It can be attached to a belt or the strap of a backpack using its integrated webbing. Alternatively, it can be clipped on with a carabiner (not included) through the reinforced eyelet.

2.3 Headlamp Battery Installation (for compatible headlamps like ACTIK CORE)

For headlamps compatible with the PETZL POCHE case, such as the ACTIK CORE, battery installation typically involves:

1. Rotate the lamp body 180 degrees to access the battery compartment.
2. Insert the CORE rechargeable battery or three AAA batteries, ensuring correct polarity as indicated by the graphics inside the compartment.
3. Close the battery compartment securely and rotate the lamp body back to its original position.

Your browser does not support the video tag.

Video: This video demonstrates the battery installation and various operating modes of the PETZL ACTIK CORE headlamp, which is compatible with the POCHE Carry Case. It shows how to open the battery compartment, insert the CORE rechargeable battery or AAA batteries, and close it securely. The video also illustrates how to cycle through brightness levels, activate red light mode, and use the lock feature.

3. OPERATING YOUR HEADLAMP (FOR COMPATIBLE HEADLAMPS)

The PETZL POCHE Carry Case is designed to protect your headlamp, and understanding your headlamp's operation is key to maximizing its utility. Below are general operating instructions for compatible PETZL headlamps, as demonstrated in the provided video:

3.1 Power On/Off and Brightness Levels

- Press the main button once to turn the headlamp on at the lowest brightness level.
- Press the button again to cycle through medium and maximum brightness levels.
- To turn off: If the lamp has been on for 5 seconds or more, a single press will turn it off. Otherwise, you must cycle through all brightness levels until it turns off.

3.2 Red Light Mode

- To activate red light mode, press and hold the button for a couple of seconds when the lamp is on.
- A single press will cycle between solid red light and strobe red light.
- The lamp will remain in red light mode even after turning it off until you switch it back to white light mode by pressing and holding the button again for a couple of seconds.

3.3 Lock Mode

- To prevent accidental activation in your bag or pocket, activate lock mode. When the headlamp is off, press and hold the button for 4 seconds until the light flashes, indicating it is locked.
- To unlock, either hold the button for 4 seconds or press it quickly four times.

3.4 Energy Gauge

Compatible headlamps feature an energy gauge to help you monitor remaining burn time:

- **Green Light:** 100% - 50% battery remaining.
- **Orange Light:** 50% - 10% battery remaining.
- **Red Light:** Less than 10% battery remaining, indicating reserve mode. The lamp will provide just enough brightness to navigate a dark situation.

3.5 Headband Adjustment

The headlamp's headband is easily adjustable even while wearing it. Slide the adjusters together to make it smaller or apart to make it larger for a comfortable and secure fit.

3.6 Versatility

The full tilt lamp body allows for various uses: traditionally on your head, hanging from your neck, suspended from above, or sitting on a solid surface. The included storage pouch can also diffuse the light, turning your headlamp into a camp lantern.

4. MAINTENANCE

4.1 Case Care

- Wipe the exterior of the case with a damp cloth to remove dirt and debris.
- Ensure the case is completely dry before storing to prevent mold or mildew.
- Avoid exposing the case to extreme temperatures or sharp objects that could cause damage.

4.2 Headlamp Care (for compatible headlamps)

- Regularly clean the headlamp lens with a soft, lint-free cloth.
- If the headlamp strap is removable, wash it as needed according to manufacturer instructions.
- Always ensure the battery compartment is clean and dry before inserting batteries.

5. TROUBLESHOOTING

5.1 Case Issues

- **Zipper sticking:** Ensure no fabric or debris is caught in the zipper. Apply a small amount of zipper lubricant if necessary.
- **Headlamp not fitting:** Ensure the headlamp strap is folded compactly and the headlamp is positioned correctly within the case.

5.2 Headlamp Issues (for compatible headlamps)

- **Light not turning on:** Check battery installation and ensure batteries are charged or replaced. Verify the headlamp is not in lock mode.
- **Dim light:** Batteries may be low. Recharge or replace batteries.
- For detailed troubleshooting specific to your PETZL headlamp model, please refer to the individual headlamp's instruction manual or the official PETZL website.

6. SPECIFICATIONS

- **Product Type:** Headlamp Carry Case
- **Compatibility:** PETZL TIKKID, TIKKINA, TIKKA, ACTIK, ACTIK CORE, SWIFT RL, TACTIKKA, TACTIKKA + and TACTIKKA +RGB headlamps.
- **Features:** Protective shell, zipper closure, internal storage for spare batteries, external attachment points (webbing, eyelet for carabiner).
- **Material:** Durable, semi-rigid material designed to protect against impacts and scratches.
- **Color:** Typically dark (e.g., black/grey).

7. WARRANTY AND SUPPORT

For information regarding the warranty of your PETZL POCHE Carry Case or compatible PETZL headlamp, please refer to the official PETZL website or the documentation included with your product. PETZL provides comprehensive support and resources for its products.

You can visit the official PETZL website for product registration, FAQs, and customer service contact information: www.petzl.com