

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Aureday](#) /
- › [Aureday Flexible Phone Tripod \(Model AB Shutter3\) User Manual](#)

### Aureday AB Shutter3

# Aureday Flexible Phone Tripod (Model AB Shutter3) User Manual

Your guide to setting up and using your Aureday Flexible Phone Tripod.

## 1. INTRODUCTION

Thank you for choosing the Aureday Flexible Phone Tripod. This versatile accessory is designed to enhance your mobile photography and videography experience, offering stability and flexibility for various shooting scenarios. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.





Image 1.1: Aureday Flexible Phone Tripod with phone and remote.

## 2. PACKAGE CONTENTS

---

Please verify that all items are present in your package:

- Aureday Flexible Phone Tripod
- Adjustable Spring-Loaded Phone Clip
- Wireless Remote Shutter (with 1 Lithium Metal battery included)

## 3. PRODUCT FEATURES

---

- **Versatile Design:** Functions as a handle grip, monopod stick, or flexible tripod.
- **Lightweight & Compact:** Weighs only 87g (3.07 ounces) and measures 9.4 inches in height for easy

portability.

- **Durable & Stable:** Constructed from premium metal with reinforced foam legs and non-slip rubber feet.
- **Flexible & Rotatable:** Bendable legs for various surfaces and a 360° rotatable ball head for precise angle control.
- **Extendable & Compatible:** Adjustable phone clip accommodates devices from 2.3 to 5.5 inches. Compatible with iPhones, Android phones, GoPro, and other cameras with a 1/4" standard screw.
- **Wireless Remote:** Operates up to 33 ft/10 m for hands-free photography.



Image 3.1: The tripod's lightweight design, weighing only 87 grams.

## 4. SETUP GUIDE

---

### 4.1 Attaching Your Device

1. Ensure the phone clip is securely screwed onto the tripod's 1/4" standard screw mount.
2. Gently expand the spring-loaded phone clip.
3. Insert your smartphone into the clip, ensuring it is held firmly and centered.
4. For other devices like GoPro or cameras, directly screw them onto the 1/4" standard screw mount.

### 4.2 Pairing the Wireless Remote Shutter

The wireless remote allows you to capture photos and videos from a distance.

1. **Power On:** Locate the power switch on the side of the remote and slide it to the 'ON' position. The indicator light will flash.
2. **Activate Bluetooth:** On your smartphone, go to 'Settings' and enable Bluetooth.
3. **Connect:** Look for 'AB Shutter3' (or similar) in the list of available Bluetooth devices and select it to pair. The indicator light on the remote will stop flashing once successfully paired.
4. **Test:** Open your phone's camera app and press the appropriate button on the remote (iOS or Android) to take a photo.

# Wireless Remote Shutter

Working range up to 30 feet/10m



- 1 Turn the remote on with the power switch located at the side



- 2 Turn on your device's Bluetooth setting and connect to the remote



Image 4.2: Step-by-step guide for pairing the wireless remote shutter.

## 5. OPERATING INSTRUCTIONS

### 5.1 Adjusting the Tripod Legs

The flexible legs can be bent and wrapped around various objects to secure your device in unique positions. Ensure the legs are firmly gripping the surface or object to prevent accidental falls.

- **Tabletop Use:** Bend the legs to create a stable base on flat or uneven surfaces.
- **Wrapping:** Wrap the legs around poles, branches, or railings for elevated or unique angles.
- **Handheld:** Keep the legs straight and together to use the tripod as a comfortable handheld grip or selfie stick.



Image 5.1: Demonstrating the flexible legs wrapped around a bar for stable mounting.

## 5.2 Adjusting the Ball Head

The 360° rotatable ball head allows for precise control over your device's angle and orientation.


1. Loosen the locking knob on the side of the ball head.
2. Adjust your device to the desired angle (e.g., landscape or portrait).
3. Tighten the locking knob firmly to secure the device in place.





# 360°

Adjustable Ball Head for Best Shooting Angle



2.3in-5.5in

Get your desired angle simply by rotating the ball head locking knob



Image 5.2: The 360° adjustable ball head for optimal shooting angles.




Image 5.3: Switching between landscape and portrait modes.

## 5.3 Device Compatibility

The Aureday Flexible Phone Tripod is designed for broad compatibility:

- **Smartphones:** The adjustable phone clip supports iPhone and Android phones ranging from 2.3 to 5.5 inches in width.
- **Cameras:** The standard 1/4" screw mount allows direct attachment of most compact cameras and

DSLRs (within the weight limit).

- **Action Cameras:** Compatible with GoPro and similar action cameras using their standard mounting accessories.

# Compatible with multiple devices

Suitable for devices equipped with  $\frac{1}{4}$ " standard screw



For GoPro



For Camera



For Cell Phone



Image 5.4: Compatibility with multiple devices including GoPro, cameras, and cell phones.

# GoPro

## Accessories Included



Image 5.5: GoPro camera mounted on the tripod, highlighting accessory inclusion.

## 6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** If the wireless remote is not used for extended periods, consider removing the battery to prevent leakage.
- **Avoid Overloading:** Do not exceed the specified weight limit (6.6 pounds) to prevent damage to the tripod or your device.

## 7. TROUBLESHOOTING

- **Remote Not Pairing:**
  - Ensure the remote is powered on and within 10 meters (33 feet) of your phone.
  - Check your phone's Bluetooth settings to ensure it's enabled and discoverable.
  - If previously paired, try 'forgetting' the device in your phone's Bluetooth settings and re-pairing.



- Replace the remote's battery if the indicator light does not illuminate.

• **Tripod Instability:**

- Ensure the legs are bent and positioned to create a stable base on the chosen surface.
- Verify that the ball head locking knob is fully tightened after adjusting the angle.
- Confirm your device's weight does not exceed the tripod's maximum weight limit.

• **Phone Not Fitting in Clip:**

- Check that your phone's width is within the 2.3 to 5.5-inch range supported by the clip.
- Remove bulky phone cases if they prevent proper seating.

8. SPECIFICATIONS

Feature	Detail
Brand	Aureday
Model Number	AB Shutter3
Product Dimensions	7.09 x 0.79 x 2.76 inches
Item Weight	3.07 ounces (87 Grams)
Material	Premium Metal
Compatible Devices	iPhone, Android Cell Phones (2.3-5.5 inches), GoPro, Cameras with 1/4" screw
Weight Limit	6.6 Pounds
Minimum Height	24 Centimeters
Maximum Height	130 Centimeters (when used as a monopod/selfie stick, not tripod height)
Tripod Head Type	Ball Heads
Remote Battery	1 Lithium Metal battery (included)
Wireless Remote Range	Up to 33 ft / 10 m







9. WARRANTY AND SUPPORT

Aureday products are manufactured with quality and customer satisfaction in mind. For any product-related inquiries, technical support, or warranty information, please refer to your purchase documentation or visit the official Aureday store:

[Visit the Aureday Store on Amazon](#)

Please retain your proof of purchase for any warranty claims.

Related Documents - AB Shutter3

	<p><a href="#">AB Shutter3 Wireless Remote Shutter Owner's Manual</a></p> <p>User manual and specifications for the AB Shutter3 Wireless Remote Shutter, detailing setup, usage, compatible devices, and FCC compliance for iOS and Android smartphones.</p>
	<p><a href="#">Wireless Remote Shutter Owner's Manual</a></p> <p>This manual provides instructions for setting up and using the Wireless Remote Shutter, compatible with Android and iOS devices. It includes product illustrations, specifications, and safety warnings regarding battery usage.</p>
	<p><a href="#">AB Shutter3 Wireless Remote Control User Guide</a></p> <p>Comprehensive guide for the AB Shutter3 Bluetooth remote control, including setup, usage, specifications, warnings, and FCC compliance information.</p>
	<p><a href="#">Magnetic Phone Vlog Selfie Screen - ETG_X397 User Manual</a></p> <p>User manual for the ETG_X397 Magnetic Phone Vlog Selfie Screen. Features a 3.97-inch screen, magnetic attachment, Bluetooth connectivity, and TYPE-C connection for easy selfie and video recording with smartphones.</p>
	<p><a href="#">AB Shutter3 Wireless Remote Shutter Owner's Manual</a></p> <p>User manual and specifications for the AB Shutter3 Wireless Remote Shutter, detailing setup, usage, compatible devices, and FCC compliance for iOS and Android smartphones.</p>
	<p><a href="#">M8 Mobile Phone Selfie Monitor User Guide</a></p> <p>This guide provides information on the M8 Mobile Phone Selfie Monitor, including its features, specifications, and wireless connection instructions for screen mirroring and Bluetooth shutter functionality.</p>