

Letaya WGYWJG1

Letaya Metal Locker Instruction Manual

Brand: Letaya | Model: WGYWJG1

1. INTRODUCTION AND OVERVIEW

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Letaya Metal Locker. Designed for versatile storage, this steel cabinet offers durability and security for various environments including offices, homes, schools, and garages.

Key Features:

- Upgraded Materials: Constructed from 0.8mm reinforced full-steel frame with environmentally powder-coated finish for corrosion and rust resistance.
- Larger Storage Space: Dimensions of 72"H x 36"W x 18"D, featuring adjustable shelves and a hanging rod.
- Weight Capacity: Each shelf can hold up to 120 lbs.
- Multiple Uses: Suitable for office, home, school, archives, garages, basements, and other secure storage needs.
- Easy Assemble: Comes unassembled with detailed instructions for straightforward setup.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always follow assembly instructions carefully.
- Do not exceed the weight limit of 120 lbs per shelf.
- Keep fingers away from the lock mechanism when locking or unlocking.
- Always use the key to lock and unlock the cabinet to prevent accidental injury.
- Ensure the cabinet is placed on a level surface to prevent tipping.
- For added stability, consider anchoring the cabinet to a wall, especially in areas with high traffic or seismic activity.

3. PACKAGE CONTENTS

Verify all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.




Figure 3.1: All components included in the package for assembly.

The package typically includes: side panels, back panels, top and bottom panels, shelves, hanging rod, door handles, lock mechanism, keys, and various screws and fasteners. A detailed list with quantities is provided in the assembly instructions PDF.

For a complete list of parts and hardware, please refer to the official Installation Manual (PDF) available [here](#).

4. SETUP AND ASSEMBLY

Assembly typically requires two people and takes approximately 30 minutes. Ensure you have a Phillips head screwdriver and a clear, flat workspace.

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and identify each part using the provided parts list.
2. **Assemble Base Frame:** Connect the bottom panels and side panels using the designated screws. Ensure all connections are secure.
3. **Install Back Panels:** Slide the back panels into the grooves of the side panels and secure them with screws.
4. **Attach Top Panel:** Secure the top panel to the assembled frame.
5. **Insert Adjustable Shelves:** Place the shelf clips into the desired slots on the side panels. Insert the shelves onto the clips.
6. **Install Hanging Rod:** If using, insert the hanging rod into the designated holes.
7. **Attach Doors:** Carefully align the door hinges with the pre-drilled holes on the cabinet frame and secure them.
8. **Install Handles and Lock:** Attach the door handles and ensure the lock mechanism is properly installed and functional.
9. **Adjust Leveling Feet:** Twist the leveling feet on the bottom of the cabinet to ensure stability on uneven surfaces.

Assembly Video:

Your browser does not support the video tag.

Video 4.1: Official installation guide for the Letaya Metal Locker. This video demonstrates the step-by-step assembly process.

5. OPERATING INSTRUCTIONS

Adjusting Shelves:

The shelves are adjustable to accommodate items of various heights. To adjust, remove all items from the shelf. Lift the shelf slightly and remove the shelf clips from their current slots. Reinsert the clips into the desired slots at the new height, ensuring they are level, then place the shelf back onto the clips.



Figure 5.1: Detail of the adjustable shelf mechanism.

Locking Mechanism:

The metal locker is equipped with a key lock for secure storage. Insert the key into the lock on the right door and turn to lock or unlock. Ensure both doors are fully closed before attempting to lock.



Figure 5.2: The lockable door with included keys for security.

6. MAINTENANCE

To ensure the longevity and appearance of your Letaya Metal Locker, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the powder-coated finish.
- **Rust Prevention:** The cabinet is designed to resist corrosion. However, avoid prolonged exposure to moisture or high humidity. If scratches occur, touch up with appropriate metal paint to prevent rust.
- **Load Management:** Distribute weight evenly on shelves and do not exceed the maximum weight capacity of 120 lbs per shelf.
- **Door Alignment:** Periodically check door alignment. If doors become misaligned, adjust the leveling feet or hinge screws as needed.



Figure 6.1: The powder-coated finish is designed to be waterproof and easy to clean.

7. TROUBLESHOOTING

If you encounter issues with your metal locker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Doors do not close properly or are misaligned.	Uneven floor; improper assembly of hinges or frame; items inside obstructing closure.	Adjust leveling feet to ensure the cabinet is stable and level. Check hinge screws for tightness and adjust if necessary. Ensure no items are blocking the doors.
Cabinet feels wobbly or unstable.	Uneven floor; loose assembly screws.	Adjust leveling feet. Tighten all assembly screws, especially those connecting the main frame components.
Lock mechanism is stiff or not working.	Misaligned doors; debris in lock; key not fully inserted.	Ensure doors are properly aligned and fully closed. Check for any obstructions in the lock. Ensure the key is fully inserted and turn gently. Do not force the key.

Customer-reported issues:

Some users have reported issues with door damage or doors not closing completely upon arrival. While the manufacturer states robust packaging, inspect all parts upon delivery. If damage is present, contact customer support immediately.

Your browser does not support the video tag.

Video 7.1: Customer video demonstrating door damage and difficulty closing. This highlights the importance of checking for transit damage.

8. SPECIFICATIONS

Feature	Detail
Brand	Letaya
Model Number	WGYWJG1
Color	White
Product Dimensions	18"D x 36"W x 72"H

Feature	Detail
Material	Metal (Steel)
Weight Limit per Shelf	120 Pounds
Number of Shelves	4 (Adjustable)
Special Feature	Lockable
Mounting Type	Floor Mount (Freestanding)
Finish Type	Powder Coated
Item Weight	92 Pounds

9. WARRANTY AND SUPPORT

Letaya is committed to providing high-quality products and excellent customer service. For any inquiries, support, or warranty claims, please contact the seller directly.

- **Returns:** This product is eligible for 30-day easy returns.
- **Customer Support:** For assistance, please refer to the customer support options provided by your retailer or visit the official [Letaya Store on Amazon](#).
- **Protection Plans:** Extended protection plans may be available for purchase. Check with your retailer for details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09V5BQYZF>

More documents and user manuals: <https://manuals.plus/>